

gimi mt. 3

gimi mt. 3 Portable Clothes Dryer Instruction Manual

Model: mt. 3

1. INTRODUCTION

Thank you for choosing the gimi mt. 3 Portable Clothes Dryer. This manual provides essential information for the safe and efficient use of your new clothes dryer. Please read these instructions carefully before assembly and operation, and retain them for future reference.

The gimi mt. 3 is designed for drying delicate clothing items such as undergarments, sweaters, and blouses, offering a convenient and space-saving solution for indoor air drying.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Do not overload the dryer. The maximum weight limit is 5 kilograms (11 pounds).
- Ensure the dryer is securely hung on a stable overhang before placing clothes on it.
- Keep out of reach of children and pets to prevent accidental injury.
- Do not use the dryer near open flames or heat sources.
- This product is intended for indoor use only.
- Regularly inspect the dryer for any signs of damage or wear. Discontinue use if damaged.

3. PACKAGE CONTENTS

Please check the package to ensure all components are present:

- gimi mt. 3 Portable Clothes Dryer unit

4. SETUP INSTRUCTIONS

The gimi mt. 3 Portable Clothes Dryer is designed for quick and easy setup.

1. **Unfold the Dryer:** Carefully remove the dryer from its packaging. Unfold the drying racks until they are fully extended and locked into position.
2. **Identify Hanging Points:** Locate the integrated hooks or hanging mechanisms on the dryer.
3. **Choose a Location:** Select a suitable location with a stable overhang, such as a balcony railing, radiator, or shower curtain rod. Ensure the surface is clean and capable of supporting the dryer's weight plus the weight of wet clothes (up to 5 kg).
4. **Hang the Dryer:** Securely hang the dryer onto the chosen overhang. Ensure it is balanced and stable before proceeding.



Image 1: The gimt mt. 3 Portable Clothes Dryer in its unfolded state, showing the hanging mechanism. This image illustrates the product's design for easy placement on various overhangs.

5. OPERATING INSTRUCTIONS

Using your gimt mt. 3 Portable Clothes Dryer is straightforward:

1. **Prepare Clothes:** Wring out excess water from your laundry before hanging to reduce drying time and prevent dripping.
2. **Hang Clothes:** Distribute clothes evenly across the drying rods. Avoid overcrowding to allow for proper air circulation, which speeds up drying.

3. **Monitor Drying:** Allow adequate time for clothes to air dry. Drying time will vary depending on humidity, temperature, and fabric type.
4. **Remove Clothes:** Once clothes are dry, remove them from the dryer.

6. MAINTENANCE AND CARE

To ensure the longevity of your gimi mt. 3 Portable Clothes Dryer, follow these care instructions:

- **Cleaning:** Wipe the dryer with a damp cloth and mild detergent as needed. Do not use abrasive cleaners or harsh chemicals.
- **Drying:** Ensure the dryer is completely dry before folding and storing to prevent rust or mildew.
- **Storage:** When not in use, fold the dryer flat and store it in a dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check all joints and rods for stability and signs of wear.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Dryer is unstable:**
 - Ensure the dryer is fully unfolded and all locking mechanisms (if any) are engaged.
 - Verify that the overhang chosen is sturdy and the dryer is balanced.
 - Reduce the load if it exceeds the 5 kg weight limit.
- **Clothes are not drying efficiently:**
 - Ensure clothes are well-wrung before hanging.
 - Do not overcrowd the drying rods; allow space for air circulation.
 - Improve ventilation in the room (e.g., open a window).
 - Consider the ambient humidity and temperature, which affect drying time.

8. SPECIFICATIONS

Model Number	mt. 3
Brand	gimi
Material	Carbon Steel
Color	White
Mounting Type	Freestanding (designed for hanging on overhangs)
Item Weight	0.46 Kilograms (approx. 1 pound)
Weight Limit	5 Kilograms (approx. 11 pounds)
Product Dimensions (L x W x H)	5.51 x 12.99 x 20.47 inches
Special Feature	Portable

9. WARRANTY AND SUPPORT

Specific warranty information for the gimi mt. 3 Portable Clothes Dryer is not provided in this manual. Please refer to the retailer or the official gimi website for details regarding warranty coverage and terms.

For product support, technical assistance, or to inquire about replacement parts, please contact gimi customer service through their official website or the retailer from whom you purchased the product.