Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HP 10bII+

HP 10bII+ Financial Calculator User Manual

Introduction

This manual provides comprehensive instructions for the HP 10bII+ Financial Calculator. Designed for students and professionals, this calculator simplifies business, financial, statistical, and mathematical computations. It features dedicated keys for quick access to common functions, ensuring accurate and efficient problem-solving.






Figure 1: Front view of the HP 10bII+ Financial Calculator, displaying its LCD screen and key layout.

Setup

Battery Installation

The HP 10bII+ Financial Calculator requires two CR2 batteries, which are included with the product. To install or replace batteries:

1. Locate the battery compartment cover on the back of the calculator.
2. Remove the cover by sliding it or unscrewing it, depending on the model.
3. Insert the two CR2 batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover securely.

Initial Power On

After installing the batteries, press the **ON** key located at the bottom left of the keypad to turn on the calculator. The display should illuminate, showing a default value or previous calculation.

Operating Instructions

General Operation

- **Power On/Off:** Press **ON** to turn on. Press **OFF** (usually a secondary function accessed via a shift key) to turn off. The calculator also features an auto power-off function to conserve battery life.
- **Display:** The calculator features a 1-line, 12-character LCD display.
- **Shift Keys:** Many keys have secondary functions, typically indicated by text above the primary key label. These are accessed by pressing a designated shift key (e.g., blue or orange key) before the desired function key.






Figure 2: Close-up view of the HP 10bII+ keypad, highlighting the various function keys.

Financial Functions

The HP 10bII+ is equipped with a comprehensive set of financial functions:

- **Time Value of Money (TVM):** Loans, Savings, Leasing.
- **Amortization:** Calculate payment schedules.
- **Cash Flow Analysis:** Up to 45 cash flows, including Internal Rate of Return (IRR), Net Present Value (NPV), and Net Future Value (NFV).
- **Depreciation:** Straight-Line (SL), Sum-of-Years'-Digits (SOYD), Declining Balance (DB).
- **Bonds:** Bond price and yield calculations.
- **Interest Conversion:** Convert between nominal and effective interest rates.
- **Margin, Cost, Sell:** Profitability calculations.
- **Break-Even Analysis:** Determine break-even points.
- **Date Calculations:** Number of days between dates.

Statistical Functions

Perform various statistical analyses:

- **Statistical Analysis:** Mean, standard deviation.
- **Prediction and Correlation:** Linear regression.
- **Probability:** Combinations and permutations.

Math Functions

Standard mathematical operations are supported:

- **Trigonometric and Inverse Trigonometric Functions:** SIN, COS, TAN, and their inverses.
- **Hyperbolic and Inverse Hyperbolic Functions.**
- **Square Root.**
- **Logarithms:** Natural (LN) and common (LOG).
- **Exponents.**

Maintenance

Cleaning

To clean your HP 10bII+ calculator, use a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the display or casing.

Storage

When not in use, store the calculator in its protective sleeve to prevent scratches and damage. Avoid exposing the calculator to extreme temperatures, humidity, or direct sunlight for extended periods.

Troubleshooting

Calculator Does Not Turn On

- Ensure batteries are correctly installed with proper polarity.
- Replace batteries with new ones if the current batteries are old or depleted.

Display Issues

- If the display is dim, replace the batteries.
- If the display shows unusual characters, try turning the calculator off and on again.

Incorrect Calculations

- Verify that you are using the correct function keys and inputting values accurately.
- Ensure the calculator is in the correct mode (e.g., degrees/radians for trigonometric functions).
- Clear any previous calculations or memory registers if necessary.

Specifications

Feature	Detail
Brand	HP
Model Name	HP 10bII+
Model Number	NW239AA
Calculator Type	Financial
Power Source	Battery Powered (2 x CR2 batteries included)
Display Type	LCD
Screen Size	2 inches (1 line x 12 character)
Item Weight	3 ounces
Item Dimensions (L x W)	6"L x 3"W
Enclosure Material	Plastic






Figure 3: HP 10bII+ Financial Calculator illustrating its physical dimensions.

Warranty Information

The HP 10bII+ Financial Calculator comes with a Standard 1-Year Manufacturer's Warranty. Please refer to the warranty card included in your product packaging for full terms and conditions, or visit the official HP website for more details.

Support Information

For technical support, product inquiries, or service, please contact HP customer support. You can find contact details on the official HP website or refer to the documentation provided with your calculator.
Manufacturer Contact Information: Delray Beach, FL 33445-9044, US.
Visit the official HP Store for more products and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B006FUXAGU

More documents and user manuals: **https://manuals.plus/**