

[Manuals.plus](#) /

› [Poolmaster](#) /

› Poolmaster 17-1/2-Inch Aluminum Swimming Pool Brush Instruction Manual

Poolmaster 18105

Poolmaster 17-1/2-Inch Aluminum Swimming Pool Brush Instruction Manual

Model: 18105

Brand: Poolmaster

PRODUCT OVERVIEW

The Poolmaster 17-1/2-Inch Aluminum-Back Swimming Pool Brush is designed for efficient cleaning of all pool and spa surfaces. Its wide brush head allows for extensive coverage with each stroke, making pool maintenance more effective.



Image: The Poolmaster 17-1/2-inch Aluminum Swimming Pool Brush, featuring a blue and silver design with white bristles.

Key Features:

- Designed for cleaning all pool and spa surfaces.
- Features a 17-1/2-inch wide die-cast aluminum back and handle for enhanced durability and strength.
- Equipped with polypropylene bristles for long-lasting performance and a curved-body design for effective cleaning.
- Includes an ease-adapt handle for simple on-off functionality with standard pool poles.
- For use with standard pool poles (sold separately).

SETUP

The Poolmaster 17-1/2-Inch Aluminum Swimming Pool Brush is designed for quick and easy attachment to a standard pool pole. No tools are required for assembly.

1. Ensure your pool pole is a standard size compatible with pool accessories.
2. Align the ease-adapt handle of the brush with the end of your pool pole.
3. Push the brush handle firmly onto the pole until it clicks securely into place. Verify that the brush is stable and does not wobble before use.

OPERATING INSTRUCTIONS

Regular brushing is essential for maintaining a clean and healthy pool. This brush effectively removes algae, dirt, debris, and grime from various pool surfaces.



Image: A Poolmaster brush attached to a pole, being used to clean the bottom of a swimming pool, shown from a side angle.



Image: A Poolmaster brush attached to a pole, being used to clean the bottom of a swimming pool, shown from a front angle.

1. Begin by brushing the pool walls, starting from the shallow end and working towards the deep end. Use steady, overlapping strokes to ensure thorough cleaning.
2. Pay close attention to areas where algae or dirt tend to accumulate, such as corners, steps, and around fittings.
3. After brushing the walls, proceed to brush the pool floor. Work in sections, moving the brush slowly to dislodge debris without stirring it up excessively.
4. Once brushing is complete, allow the dislodged debris to settle to the bottom of the pool for a few hours before vacuuming. This ensures maximum removal of contaminants.

MAINTENANCE

Proper maintenance of your Poolmaster brush will extend its lifespan and ensure optimal cleaning performance.

- **Rinsing:** After each use, thoroughly rinse the brush with fresh water to remove any pool chemicals, dirt, or debris trapped in the bristles. This is especially important for salt water pools to prevent aluminum corrosion.
- **Storage:** Store the brush in a cool, dry place away from direct sunlight when not in use. Prolonged exposure to UV rays can cause the bristles to become brittle and degrade the material.
- **Inspection:** Periodically inspect the bristles for wear or damage. While durable, bristles can wear down over time, especially with frequent use on rough surfaces. Replace the brush if bristles are significantly worn or missing to maintain cleaning effectiveness.

TROUBLESHOOTING

If you encounter issues with your Poolmaster brush, consider the following common solutions:

Problem	Possible Cause	Solution
Bristles wearing quickly or falling out	Excessive force during brushing. Prolonged exposure to direct sunlight/UV rays. Harsh pool chemicals not rinsed off. Normal wear and tear over time.	Use gentle, consistent strokes. Store the brush out of direct sunlight. Rinse thoroughly with fresh water after each use. Consider replacing the brush if bristles are significantly worn.
Brush not effectively cleaning surfaces	Bristles are too soft or worn. Insufficient brushing technique.	Check bristle condition; replace if worn. Ensure overlapping strokes and adequate pressure.

SPECIFICATIONS

- **Brand:** Poolmaster
- **Model Number:** 18105
- **Color:** Silver (Aluminum back)
- **Handle Material:** Aluminum
- **Bristle Material:** Polypropylene
- **Product Dimensions:** 2.25 x 17.5 x 7 inches
- **Item Weight:** Approximately 0.01 Ounces (Note: This weight seems unusually low, likely a data entry error in source. Actual weight would be higher.)
- **UPC:** 085334181052
- **Country of Origin:** China

WARRANTY AND SUPPORT

For information regarding warranty coverage, product support, or to purchase replacement parts, please contact Poolmaster customer service directly. Refer to the product packaging or the official Poolmaster website for the most current contact information.

Poolmaster is committed to providing quality products and support for your pool and spa maintenance needs.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question