Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 3270

Braun Silk Epil 3 Epilator (Model 3270) Instruction Manual

Model: 3270

Brand: Braun

Introduction

This manual provides detailed instructions for the safe and effective use of your Braun Silk Epil 3 Epilator, Model 3270. Designed for efficient hair removal on legs and body, this device offers a combination of epilation, shaving, and trimming functionalities. Please read all instructions carefully before first use and retain this manual for future reference.

Important Safety Information

- Always ensure the appliance is dry before connecting it to a power source.
- Do not use the appliance on irritated skin, open wounds, moles, or varicose veins. Consult a doctor if you have any skin conditions or concerns.
- Keep the appliance away from children.
- This appliance is not water resistant. Do not use it in the shower or bath, or immerse it in water.
- The appliance is designed for hair removal on legs and body. Do not use it for other purposes.
- If the appliance is damaged, do not use it. Contact an authorized service center for repair.

Product Overview

The Braun Silk Epil 3 (Model 3270) is a versatile hair removal device featuring multiple attachments for epilation, shaving, and trimming. Key components include:

- **Main Unit:** Ergonomically designed for comfortable handling.
- **Epilation Head:** Equipped with 20 tweezers and SoftLift Tips to effectively remove hair from the root.
- **Massaging Rollers:** Integrated into the epilation head to stimulate and relax the skin, reducing discomfort.
- **Smartlight:** Illuminates even the finest hairs for thorough removal.
- **Shaver Head:** For a close shave.
- **Trimmer Comb:** For precise trimming.

- **Power Cord:** For continuous operation.



Figure 1: Braun Silk Epil 3 Epilator with its epilation head, shaver head, and trimmer comb, alongside its retail packaging.



Figure 2: The Braun Silk Epil 3 Epilator being held and used on the skin, demonstrating its ergonomic design.



Figure 3: A visual representation highlighting the 2-in-1 functionality of the device, showing both epilation and shaving heads.



Figure 4: The Braun Silk Epil 3 Epilator displayed with its interchangeable epilation head, shaver head, and trimmer comb.

Setup

1. **Attach Head:** Select the desired head (epilation, shaver, or trimmer) and gently press it onto the main unit until it clicks into place.
2. **Connect Power:** Plug the power cord into the appliance and then into a suitable electrical outlet. The device supports dual voltage (110-220 Volts).
3. **Clean Skin:** Ensure your skin is clean and dry before use.

Operating Instructions

1. Epilation (with Epilation Head)

- **Power On:** Slide the switch to position 'I' for gentle epilation or 'II' for extra efficient epilation. The Smartlight will illuminate.
- **Positioning:** Hold the epilator at a 90-degree angle to your skin.
- **Movement:** Move the epilator slowly against the direction of hair growth, ensuring the massaging rollers are in contact with the skin.

Do not press too hard.

- **Results:** The SoftLift Tips will lift flat-lying hairs, guiding them to the tweezers for effective removal from the root, providing smooth skin for up to 4 weeks.

2. Shaving and Trimming (with Shaver Head and Trimmer Comb)

- **Attach Head:** Replace the epilation head with the shaver head. For trimming, attach the trimmer comb over the shaver head.
- **Shaving:** Move the shaver head gently over the skin in the direction of hair growth for a close shave.
- **Trimming:** Use the trimmer comb to shorten hair to a desired length.

Your browser does not support the video tag.

Video 1: An official product video demonstrating the features and usage of the Braun Silk Epil 3 Epilator, including its dual voltage capability and various attachments for legs and body.

Maintenance

- **Cleaning the Epilation Head:** After each use, remove the epilation head and use the provided cleaning brush to remove any trapped hairs. For thorough cleaning, the epilation head can be rinsed under running water. Ensure it is completely dry before reattaching.
- **Cleaning the Shaver/Trimmer Head:** Use the cleaning brush to remove hair from the shaver and trimmer heads. The shaver foil should be handled with care to avoid damage.
- **Storage:** Store the appliance in a dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not properly plugged in or power outage.	Check power connection. Ensure the outlet is functional.
Reduced performance.	Hair accumulation in the head or dull blades.	Clean the epilation/shaver head thoroughly. Consider replacing the head if performance does not improve.
Skin irritation after use.	Incorrect usage or sensitive skin.	Ensure you are moving the epilator slowly against hair growth. Apply a soothing lotion after use. If irritation persists, consult a dermatologist.

Specifications

- **Model Number:** 3270 (SE3270)
- **Brand:** Braun
- **Power Source:** Corded Electric (Dual Voltage 110-220 Volts)
- **Dimensions:** 7.09 x 2.56 x 7.76 inches
- **Item Weight:** 0.33 Kilograms (11.61 ounces)
- **Water Resistance Level:** Not Water Resistant
- **Features:** 20-tweezer epilation system, SoftLift Tips, Massaging Rollers, Smartlight, 2 speed settings.

Warranty and Support

For warranty information, product registration, or technical support, please refer to the warranty card included in your product packaging or visit the official Braun website. Keep your proof of purchase for any warranty claims.
You can also visit the Braun Store on Amazon for additional product information and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B006J1SA6A

More documents and user manuals: **https://manuals.plus/**