Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mr. Coffee AMZCTS

Mr. Coffee Mug Warmer AMZCTS Instruction Manual

Product Overview

The Mr. Coffee Mug Warmer is designed to keep your beverages, such as coffee, tea, or hot chocolate, warm for extended periods. Its compact design makes it suitable for use in various settings, including offices and homes. This device ensures your drink maintains a pleasant temperature, enhancing your enjoyment.

Key features include:

- Keeps cups, mugs, and teapots warm.
- Features an adequate cord length for convenient placement.



This image shows the Mr. Coffee Mug Warmer, a compact black device with a heating plate, power cord, and an indicator light.

Important Safety Information

Please read all instructions before using this appliance. Failure to follow these safety guidelines may result in fire, electric shock, or injury.

- Do not immerse the warmer, cord, or plug in water or other liquids.
- Always unplug the warmer from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only on a flat, stable, heat-resistant surface.
- Keep out of reach of children. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not touch hot surfaces. Use handles or knobs.
- Do not use outdoors.

Package Contents

Upon unpacking, please ensure all items are present and in good condition:

- Mr. Coffee Mug Warmer (Model AMZCTS)
- Instruction Manual

Setup

1. **Unpack the Warmer:** Carefully remove the mug warmer from its packaging. Retain packaging for future storage or transport.
2. **Choose a Location:** Place the mug warmer on a flat, stable, and heat-resistant surface, away from flammable materials and water sources. Ensure there is adequate space around the unit for ventilation.
3. **Connect to Power:** Plug the power cord into a standard electrical outlet. The warmer is designed for 100-120V AC power.

Operating Instructions

1. **Prepare Your Beverage:** Pour your desired hot beverage into a flat-bottomed, heat-safe mug or cup. Ceramic or glass mugs with flat bases work best for optimal heat transfer.
2. **Place the Mug:** Carefully place the mug onto the center of the warming plate.
3. **Turn On:** Locate the ON/OFF switch, usually indicated by a red light, and slide it to the 'ON' position. The indicator light will illuminate, signifying the warmer is active.
4. **Maintain Temperature:** The warmer will begin to maintain the temperature of your beverage. For best results, place the mug on the warmer immediately after pouring your hot drink.
5. **Turn Off:** When you are finished, slide the ON/OFF switch to the 'OFF' position. The indicator light will turn off.
6. **Unplug:** For safety and energy conservation, unplug the warmer from the electrical outlet when not in use.



This image provides a closer look at the warming plate and the power switch with its red indicator light.

Maintenance

Proper care and maintenance will ensure the longevity of your mug warmer.

- **Cleaning:** Always unplug the warmer and allow it to cool completely before cleaning. Wipe the warming plate and exterior with a damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the surface. Do not immerse the unit in water.
- **Storage:** When not in use, store the mug warmer in a dry place, away from direct sunlight and extreme

temperatures. You may wrap the cord neatly around the base if a cord wrap feature is present.

Troubleshooting

If you encounter any issues with your Mr. Coffee Mug Warmer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Warmer is not heating.	Not plugged in; power switch is off; power outlet is not functioning.	Ensure the warmer is securely plugged into a working electrical outlet. Check that the ON/OFF switch is in the 'ON' position and the indicator light is illuminated. Test the outlet with another appliance.
Indicator light is not on.	Power switch is off; no power to the unit.	Verify the ON/OFF switch is in the 'ON' position. Check the power connection and the electrical outlet.
Beverage is not staying warm enough.	Mug material or base is not suitable; mug is not centered; initial beverage temperature was too low.	Use a flat-bottomed ceramic or glass mug for best results. Ensure the mug is centered on the warming plate. Start with a hot beverage, as the warmer is designed to maintain temperature, not rapidly heat cold liquids.

If the problem persists after trying these solutions, please contact customer support.

Specifications

- **Brand:** Mr. Coffee
- **Model Number:** AMZCTS
- **ASIN:** B006K7SIE2
- **Color:** Black
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Tray Count:** 1
- **Power:** Designed for 100-120V AC (Specific wattage not provided, but typical for mug warmers is 17-24W)

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official Mr. Coffee website. Keep your purchase receipt as proof of purchase for any warranty claims.

You can typically find support contact information on the manufacturer's official website or by searching for "Mr. Coffee customer support" online.

© 2023 Mr. Coffee. All rights reserved. Information is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B006K7SIE2

More documents and user manuals: **https://manuals.plus/**