

[Manuals.plus](#) /

› [Mega Bloks](#) /

› Mega Bloks Moshi Monsters Moshling Zoo and Horrods Shop 80636 Instruction Manual

Mega Bloks 80636

Mega Bloks Moshi Monsters Moshling Zoo and Horrods Shop 80636 Instruction Manual

Brand: **Mega Bloks** | Model: **80636**

PRODUCT OVERVIEW

The Mega Bloks Moshi Monsters Moshling Zoo and Horrods Shop building set allows you to construct a vibrant Moshling environment. This set includes unique Moshling characters and accessories, designed for imaginative play and collection.

Key Features:

- Includes 1 Furi character and 2 Moshlings, one of which is a surprise.
- Designed for assembly, providing an engaging building experience.
- Comes with additional character-specific accessories.
- The buildable Moshling Zoo can be expanded by connecting with other Moshling Zoo sets (sold separately).
- Officially licensed Moshi Monsters product.

Product Contents:



Figure 1: The Mega Bloks Moshi Monsters Moshling Zoo and Horrods Shop set, model 80636, in its original blister card packaging. The image displays the main Furi character, a visible Moshling, and indicates the presence of a surprise Moshling egg. The packaging also highlights the "Collect Them All!" theme and a choking hazard warning for small parts, not suitable for children under 3 years.

This set contains 13 pieces, including building blocks, character figures, and accessories, as indicated on the packaging.

SETUP AND ASSEMBLY

Some assembly is required to construct the Moshling Zoo and Horrods Shop. Follow the included visual instructions (not provided in this digital manual) for step-by-step guidance.

General Assembly Guidelines:

1. **Unpack Components:** Carefully remove all pieces from the packaging. Verify that all 13 pieces are present.
2. **Identify Pieces:** Sort the building blocks and character accessories. Refer to the product image for visual identification of key components.
3. **Connect Blocks:** Interlock the Mega Bloks pieces firmly to form the base structure of the Moshling Zoo and Horrods Shop. Ensure connections are secure.
4. **Place Characters:** Position the Furi character and the visible Moshling within the constructed environment. Open the surprise Moshling egg to reveal the third character and place it as desired.
5. **Add Accessories:** Attach any additional character-specific accessories to enhance the play scene.

For detailed visual instructions, please refer to the assembly guide included in your product packaging.

OPERATION AND PLAY

Once assembled, the Mega Bloks Moshi Monsters Moshling Zoo and Horrods Shop is ready for imaginative play. The set is designed for children aged 4 and up.

Interactive Features:

- **Character Interaction:** Engage with Furi and the Moshlings in various scenarios within the constructed zoo and shop.
- **Expandable Design:** The Moshling Zoo is designed to connect with other Mega Bloks Moshling Zoo sets (sold separately), allowing for the creation of a larger, more elaborate Moshling world.
- **Collectible Moshlings:** The set includes a surprise Moshling, encouraging collection and discovery.

Encourage creative storytelling and role-playing with the characters and environment.

MAINTENANCE AND CARE

Proper care will ensure the longevity of your Mega Bloks set.

- **Cleaning:** To clean the blocks and figures, wipe them with a damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and air drying. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the set in a clean, dry place away from direct sunlight and extreme temperatures to prevent warping or discoloration of the plastic.
- **Handling:** Handle the pieces with care to avoid breakage, especially smaller accessories.

Regular inspection for any damaged parts is recommended.

TROUBLESHOOTING

This section addresses common issues you might encounter with your building set.

Common Issues and Solutions:

Problem	Possible Cause	Solution
Pieces do not fit together	Incorrect orientation or foreign material in connection points.	Ensure pieces are oriented correctly. Check for and remove any debris from the studs and holes. Apply gentle, even pressure.
Missing pieces	Pieces may be overlooked during unpacking or lost.	Thoroughly check all packaging materials and the play area. If pieces are genuinely missing, contact Mega Bloks customer support (see Support section).

Problem	Possible Cause	Solution
Figures or accessories are loose	Normal wear or slight manufacturing variation.	Ensure they are fully inserted into their designated slots. If a piece is consistently loose, it may be due to wear; consider contacting support if it significantly impacts play.

PRODUCT SPECIFICATIONS

Attribute	Detail
Model Number	80636
Product Dimensions	8 x 3 x 6 inches
Item Weight	1.6 ounces
Manufacturer Recommended Age	14 years and up
Number of Pieces	13
Brand	Mega Bloks
Manufacturer	Mega Brands America, Inc.

Note: The manufacturer recommended age on some listings may differ from the age indicated on the product packaging (typically 4+ for this type of building toy). Please refer to the physical product packaging for the most accurate age guidance.

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

This product contains small parts which may pose a choking hazard. Keep all small components away from children under 3 years of age. Adult supervision is recommended during play, especially with younger children.

WARRANTY INFORMATION

Specific warranty details for Mega Bloks products are typically provided with the product packaging or can be found on the official Mega Bloks website. Please retain your proof of purchase for any warranty claims. For general information regarding product quality and potential defects, please refer to the manufacturer's official support channels.

CUSTOMER SUPPORT

For assistance with missing parts, product defects, or general inquiries, please contact Mega Bloks customer support.

- **Manufacturer:** Mega Brands America, Inc.
- **Website:** Visit the official Mega Bloks website for support resources, FAQs, and contact information.
- **Contact:** Refer to the contact details provided on the product packaging or the manufacturer's website for direct support.

When contacting support, please have your product model number (80636) and purchase details ready.

© 2023 Mega Bloks. All rights reserved. Moshi Monsters ™ and © Mind Candy Ltd.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question