

[Manuals.plus](#) /

› [Hape](#) /

› Hape Gourmet Kitchen Play Set Instruction Manual E3100B

Hape E3100B

Hape Gourmet Kitchen Play Set Instruction Manual

Model: E3100B

1. INTRODUCTION

The Hape Gourmet Kitchen Play Set is designed to inspire imaginative play and creative thinking in children. This wooden play kitchen features a sink, stovetop, oven with a transparent window, cabinet, spice shelf, and turnable clicking knobs. It encourages the development of fine motor skills and basic cooking techniques through engaging role-play scenarios. Crafted from durable, child-safe wood with non-toxic, water-based paint, this play set is built to provide years of enjoyment.



Figure 1: Hape Gourmet Kitchen Play Set

2. SAFETY INFORMATION

- Not suitable for children under 36 months due to small parts.
- Adult assembly required. Please ensure all fasteners are securely tightened before use.

- Regularly inspect the play set for any loose parts or damage. Discontinue use if any damage is found.
- Use on a flat, stable surface to prevent tipping.
- Keep away from open flames or direct heat sources.

3. PARTS LIST

The Hape Gourmet Kitchen Play Set requires some assembly. Please refer to the detailed parts list and hardware included in your product packaging to ensure all components are present before beginning assembly.

4. SETUP AND ASSEMBLY

Some easy assembly is required for the Hape Gourmet Kitchen Play Set. Please follow the step-by-step instructions provided in the separate assembly guide included with your product. Ensure all screws and connectors are tightened securely to maintain the structural integrity and safety of the play set.

5. OPERATING INSTRUCTIONS

The Hape Gourmet Kitchen Play Set is designed for interactive pretend play. Here's how to use its features:

5.1. Stovetop and Knobs

- The stovetop features two burners for pretend cooking.
- Turn the red knobs located on the front panel to simulate turning the burners on or off. These knobs produce a satisfying clicking sound for realistic play.



Figure 2: Turning the Stove Knobs

5.2. Sink and Faucet

- The sink area includes a removable basin and a faucet with turnable hot and cold water handles.
- Children can pretend to wash dishes or vegetables in the sink.



Figure 3: Pretend Play at the Sink

5.3. Oven and Cabinet

- The oven features a transparent window, allowing children to see their pretend creations baking inside.
- The cabinet provides storage space for play food, pots, pans, and other kitchen accessories.

6. MAINTENANCE AND CARE

- Clean the play set with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- Wipe dry immediately after cleaning to prevent moisture damage.
- Store the play set in a dry environment, away from direct sunlight or extreme temperatures, to preserve the wood and paint finish.
- Periodically check all screws and fasteners and tighten them if necessary.

7. SPECIFICATIONS

Product Dimensions	21.65 x 12.6 x 27.76 inches (55 x 32 x 70.5 cm)
Item Weight	17.69 pounds
Model Number	E3100B
Recommended Age	36 months - 12 years

Material	Durable Wood (Baltic Birch plywood)
Finish	Child-safe, non-toxic water-based paint



Figure 4: Product Dimensions

8. PRODUCT FEATURES

- **Fully Equipped Gourmet Kitchen:** Includes a sink, stove, oven with window, cabinet, spice shelf, and turnable clicking knobs for a complete play experience.
- **Master Chef Dreams:** Stimulates creative thinking and storytelling, allowing children to engage in imaginative cooking.
- **Realistic Features:** Encourages kinesthetic development with clickable, turnable knobs, a transparent oven window, and functional handles.
- **High Quality Construction:** Made from durable wood, child-safe materials, and non-toxic water-based paint for lasting play.
- **Expandable Play:** Designed to be combined with other Hape play food sets and appliances (sold separately) to enhance

the play experience.

9. MEDIA GALLERY

9.1. Additional Product Images



Children engaging in
imaginative play with the
kitchen set.



Kids enjoying the kitchen's
features.



Interactive play with the kitchen
set.



Detailed view of the functional
stove knobs.



Engaging with the removable sink basin.

9.2. Official Product Videos

Your browser does not support the video tag.

This video showcases the Hape Gourmet Kitchen Play Set in action, highlighting its various features and how children interact with them during play. It demonstrates the functional knobs, sink, and storage areas, as well as the compatibility with other Hape accessories.

10. WARRANTY AND SUPPORT

Hape products are known for their high quality and durability. This play set is constructed with solid wood and child-safe finishes, designed to withstand years of active play. For specific warranty details or customer support, please refer to the contact information provided in your product packaging or visit the official Hape website. All Hape products sold in North America meet or exceed applicable safety standards.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

