

Perfect Aire 4PMC5000

PerfectAire 4PMC5000 Window Air Conditioner User Manual

Model: 4PMC5000

INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your PerfectAire 4PMC5000 Window Air Conditioner. Please read this manual thoroughly before using your air conditioner and retain it for future reference.

The PerfectAire 4PMC5000 is a 5,000 BTU window air conditioner designed to cool rooms ranging from 100 to 150 square feet. It features an EER of 11.1, ensuring efficient cooling. Key features include adjustable temperature settings, a slide-out washable filter, 2-speed rotary dials, and 2-way air direction control.



Figure 1: Front view of the PerfectAire 4PMC5000 Window Air Conditioner, showing the control dials and air vents.

SAFETY INFORMATION

To prevent injury to the user or other people and property damage, the following instructions must be followed. Incorrect operation due to ignoring instructions may cause harm or damage.

- Always connect to a grounded power outlet. Do not use extension cords or adapter plugs.
- Ensure the electrical supply matches the specifications of the unit (115V, 15 Amp outlet configuration).
- Do not operate the air conditioner with wet hands or when standing in water.
- Do not block air inlets or outlets.
- Keep flammable materials away from the unit.
- Unplug the unit before cleaning or servicing.
- Do not attempt to repair or modify the unit yourself. Contact qualified service personnel.

SETUP AND INSTALLATION

The PerfectAire 4PMC5000 is designed for window installation and comes with a window mounting kit. Proper installation is crucial for optimal performance and safety.

Choosing the Right Location:

- Select a window that can securely support the weight of the unit (approximately 40 lbs).
- Ensure the window opening dimensions are suitable. The unit dimensions are approximately 15.5 x 16 x 12 inches (Width x Depth x Height).
- The window should be free from obstructions that could block airflow.
- Ensure a grounded 115V, 15 Amp electrical outlet is nearby.

Installation Steps:

Refer to the detailed instructions provided in the window mounting kit for specific installation procedures. The general steps include:

1. Prepare the window opening by cleaning the area.
2. Install the top rail and side panels according to the kit instructions.
3. Carefully lift and place the air conditioner into the prepared window opening.
4. Secure the unit using the provided screws and brackets.
5. Extend the accordion panels to fill the window gap and seal them.
6. Ensure the unit is slightly tilted outwards to allow for proper condensate drainage.



AIR CONDITIONER

5,000 BTU WINDOW AC




WINDOW AC FEATURES

- Adjustable temperature settings
- Slide-out washable filter
- 2-speed rotary dials
- 2-way air direction control
- Window mounting kit

CHOOSING

THE RIGHT SIZE AIR CONDITIONER FOR YOUR ROOM


1 MEASURE AREA OF THE ROOM




2 MATCH ROOM SIZE WITH CORRECT BTUs

ROOM SIZE (sq. ft.)	BTUs
150 10' x 15'	5,000
250 15.5' x 16'	6,000
350 17.5' x 20'	8,000
450 18' x 25'	10,000
550 22' x 25'	12,000
700 25' x 28'	15,000
1,000 31.25' x 32'	18,000
1,500 37.5' x 40'	25,000
2,000 40' x 50'	28,500

3 CONFIRM WINDOW OPENING SIZE



4 CHECK ELECTRICAL REQUIREMENTS



	4PMC5000
UPC CODE	8-42149-02532-8
COOLING CAPACITY (BTU)	5,000
COVERAGE (sq. ft.)	100-150
EER	11.1
ENERGY STAR RATED	No
FAN SPEEDS (Cool/Fan)	2/2
AMPS	4.0
WATTS	446
DECIBELS (Hi/Lo)	55/51
WINDOW WIDTH (Min./Max.) (in.)	23/36
WINDOW HEIGHT (Min.) (in.)	13
UNIT DIMENSIONS (WxHxD) (in.)	16 x 12 x 15 ^{1/2}
PKG. DIMENSIONS (WxHxD) (in.)	18 x 14 ^{3/4} x 17 ^{1/4}
STUFFING QTY. (20'/40'/40' HQ)	389/809/944
WEIGHT (Net/Gross) (lbs.)	40/45
REFRIGERATION	R410A
OUTLET CONFIGURATION	15 AMP 115V



PA/SS_4PMC5000/05022017

5401 Dansher Road
Countryside, IL 60525

866.996.9255
630.323.2301

www.perfectaire.us
support@perfectaire.us

Figure 2: Diagram illustrating window measurement and installation considerations for the PerfectAire 4PMC5000.

OPERATING INSTRUCTIONS

Familiarize yourself with the control panel for efficient operation of your air conditioner.



Figure 3: Close-up view of the control panel on the PerfectAire 4PMC5000, showing temperature and fan speed dials.

Control Dials:

- **Temperature Dial:** Adjusts the desired cooling temperature. Rotate the dial to select a temperature setting from 1 (least cool) to 7 (most cool).
- **Cooling/Fan Speed Dial:** This 2-speed rotary dial controls both the fan speed and the cooling mode.
 - *Low Fan:* Operates the fan at a low speed without cooling.
 - *High Fan:* Operates the fan at a high speed without cooling.
 - *Low Cool:* Activates cooling with the fan at a low speed.
 - *High Cool:* Activates cooling with the fan at a high speed.

Air Direction Control:

The unit features 2-way air direction control. Adjust the horizontal louvers to direct airflow left or right as desired for optimal room coverage.

Important Note:

Wait Three Minutes Before Restarting:

If you turn off the air conditioner or switch from cooling to fan mode, wait at least three minutes before restarting the cooling function. This allows the compressor to stabilize and prevents damage to the unit.

MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your PerfectAire air conditioner.

Air Filter Cleaning:

The unit is equipped with a slide-out washable filter. Clean the air filter every two weeks, or more frequently depending on usage and air quality, to maintain optimal performance.

1. Unplug the air conditioner from the power outlet.
2. Gently slide out the air filter from its slot.
3. Wash the filter with warm, soapy water. Rinse thoroughly.
4. Allow the filter to air dry completely before reinserting it. Do not use hot water or dry with direct heat.
5. Slide the dry filter back into its original position.

General Cleaning:

- Wipe the exterior of the unit with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure the drainage area at the back of the unit is clear of debris.
- For long-term storage, clean the unit thoroughly, allow it to dry, and cover it to protect from dust.

TROUBLESHOOTING

Before contacting customer support, please refer to the following common issues and their solutions:

Problem	Possible Cause	Solution
Air conditioner does not turn on.	No power, tripped circuit breaker, unit unplugged.	Check power cord connection, reset circuit breaker, ensure outlet is functional.
Unit not cooling effectively.	Dirty air filter, blocked airflow, room too large, temperature setting too high.	Clean air filter, ensure no obstructions, verify room size is within 100-150 sq. ft. range, lower temperature setting.
Water dripping from unit (indoors).	Unit not tilted properly, drain blocked.	Ensure unit is slightly tilted outwards for drainage. Check and clear any blockages in the drain pan/hose.
Unusual noise.	Loose parts, unit not level, foreign object inside.	Check for loose screws, ensure unit is level, unplug and inspect for foreign objects. If noise persists, contact support.

SPECIFICATIONS

Feature	Specification
Model Name	4PMC5000
Cooling Capacity	5,000 BTU
Energy Efficiency Ratio (EER)	11.1
Coverage Area	100-150 sq. ft.
Voltage	115 Volts
Amps	4.0

Feature	Specification
Watts	446
Decibels (Hi/Lo)	55/51
Product Dimensions (L x W x H)	39.37 x 40.64 x 30.48 cm (approx. 15.5 x 16 x 12 inches)
Item Weight	40 Pounds (18.14 kg)
Special Feature	Dehumidifier function
Filter Type	Slide-Out Washable Filter
Certifications	C/UL/us Listed, EER Certified

WARRANTY AND SUPPORT

Your PerfectAire 4PMC5000 Window Air Conditioner comes with a **Limited Warranty**. Please refer to the warranty card included with your product for specific terms and conditions.


For product support, technical assistance, or warranty inquiries, please contact Perfect Aire customer service:

- **Phone:** 866-996-9255
- **Email:** supportatperfectaire.US

When contacting support, please have your model number (4PMC5000) and purchase information ready.

© 2023 Perfect Aire. All rights reserved.

Related Documents

	Perfect Aire 4PNC12000 Window Air Conditioner 12,000 BTU Electronic Detailed specifications and features for the Perfect Aire 4PNC12000 electronic window air conditioner, including cooling capacity, dimensions, energy efficiency, and guidance on selecting the right unit for your room.
	Perfect Aire PAC6000 Window Air Conditioner Specifications and Features Detailed specifications and features for the Perfect Aire PAC6000 window air conditioner, including cooling capacity, EER, dimensions, and energy efficiency ratings.

	Perfect Aire Window Air Conditioner User Manual: Models 4PAC6000-4PAC12000 Comprehensive user manual for Perfect Aire window air conditioners, covering safety precautions, installation, features, operation, care, and troubleshooting for models 4PAC6000, 4PAC8000, 4PAC10000, and 4PAC12000.
	Perfect Aire Window Air Conditioner Owner's Manual with Supplemental Electric Heat Comprehensive owner's manual for Perfect Aire window air conditioners (Models 4PACH8000, 4PACH12000) with supplemental electric heat, covering safety, installation, operation, maintenance, and troubleshooting.

Documents - Perfect Aire – 4PMC5000



[\[pdf\]](#) Guide

4PMC5000 1 1/4 Energy Guide 5 000 BTU Star Window Air Conditioner Perfect Aire prap1022

4PMC5000PerfectAire 4PMC5000v1secure img1 ag wfcdn dm document a06e7712 770d 457f 8d77

4be5ec00f0d9 energy guide |||

41 42 11.1 **4PMC5000** 5,000 BTUs 48 ...

lang: score:37 filesize: 218.78 K page_count: 1 document date: 2016-02-02



[\[pdf\]](#) User Manual Instructions

PA Manual 4PMC5000 LR 10172017 END globalindustrial site images perfectair |||

WINDOW AIR CONDITIONER USER MANUAL FOR MODEL: **4PMC5000** Before using your air conditioner, please read this manual carefully and keep it for future reference, along with your receipt. CONSUMER PRODUCT INFORMATION For your own records, please attach a copy of your sales receipt to this manual and co...

lang:en score:28 filesize: 3.73 M page_count: 16 document date: 2017-11-08

[\[pdf\]](#) Specifications Dimension Guide Warranty

4PMC5000 Global Industrial UPC Code 8 42149 02532 Cooling Capacity BTU 5 000 Coverage sq ft 100

150 EER Certified 11 1 Energy Star Rated No Fan Speeds cool fan4PMC5000

SpecificationSheetglobalindustrial site images perfectair SpecificationSheet srsItid

AfmBOopKY3s3q7SRwFJvz9dHCPU6m6sEmthzxyTaFDBYZHG d dwUe4 Industrial4PMC5000 fanUPC

SpecificationSheet4PMC5000 dwUe4globalindustrial

AfmBOooL5caNqIP63euLIHyuddH31eqz3dapGPmAfkIH3EgxFBWKqgIZ Specifications Window Air

Conditioner Perfect Aire prap1022 4PMC50004PMC5000 IndustrialPerfectAire 4PMC5000UPC

fanspecifications4PMC5000 SpecificationSheetsecure img1 ag wfcdn dm document 59c0df25 d8ab 4248

b43f 3a11e6f1cd77 specificationsglobalindustrial |||


WINDOW AIR CONDITIONERS **4PMC5000** UPC Code: Cooling Capacity: BTU

Coverage: sq. ft EER Certified: Energy Star Rated: Fan Speeds: cool/fan Amps:

Watts: Decibels: Hi/Lo Window Width: min/max in. Window Height: min. in. Unit

Dimensions: WxHxD in. Pkg Dimensions: WxHxD in. Stuffing Qty: ...

lang:en score:18 filesize: 897.34 K page count: 1 document date: 20



[Perfect Aire HVAC Product Catalog: Mini-Splits, PTACs, Dehumidifiers & Air Conditioners](#)

Explore the comprehensive range of Perfect Aire HVAC solutions, including energy-efficient mini-split systems, PTAC units, commercial and residential dehumidifiers, and various window, thru-the-wall, and portable air conditioners, designed for comfort, reliability, and quality.

lang:en score:17 filesize: 9 M page count: 25 document date: 2017-07-15



[\[pdf\]](#) Dimension Guide Warranty Catalog

QUICK CONNECT MINI SPLIT HVAC Direct GOLDEN FIN corrosion coated coils withstand corrosive outdoor elements The Perfect Aire 12 000 BTU Quick Connect Single Zone Mini Split provides maximum perfect aire catalog srsItId AfmBOorsEEj0VJD4IZZhVnKoYbUmU N2YDroYaZSmHtAmgOB1 NJh0 hvacdirect media hvac |||

QUICK CONNECT MINI-SPLIT 15 SEER FUL L REPLACEM 30 MONTH
WARRANTY ENT SECURE MECHANICAL CONNECTI ... PKG. DIMENSIONS
WxHxD in. STUFFING QTY. 20/40/40 HQ WEIGHT Net/Gross lbs. REFRIGERATION
4PMC5000 8-42149-02532-8 5,000 100150 11.1 No 2/2 4.0 446 55/51 23/36 13 16 x
12 x 151/2 18 x 143/4 ...

lang:en score:16 filesize: 10.1 M page count: 25 document date: 2017-07-15

[\[pdf\]](#) Installation Guide Frequently Asked Questions Dimension Guide Warranty Catalog

QUICK CONNECT MINI SPLIT HVAC Direct GOLDEN FIN corrosion coated coils withstand corrosive outdoor elements The Perfect Aire 12 000 BTU Quick Connect Single Zone Mini Split provides maximum perfect aire catalog hvacdirect media hvac srsitid

AfmBOogVrP2qnQmM7ttKKdjf4ZT8SF0RGDNMkqtQTpR2 7 SogiDM M AIR CONDITIONER

DEHUMIDIFIER OFFERING A COMPREHENSIVE MIX OF PORTABLE WITH ELECTRIC HEATER Pq

15 PORTH12000 450 AfmBOoowKA46SKg9hIXzd zdoUqqQenReCaN8r30BIWeDf2wwQxeYkYY

DirectQUICK DirectAIR 450 M POWER SUPPLY V 115 COOLING CAPACITY h HEATING 11 500 AMPS

5 SEER EER Btu W 8 HSPF Whvacdirect Mhvacdirect

zdoUggQenReCaN8r30BIWeDf2wwQxeYkYYhvacdirect AfmBOoq8WbloahQ9

P1vEX62bxo8KWyLnB4wxaCXajERTWW7Xf6fAgvt WRemote control with built in room temperature sensor regulates PERFECT AIRE® HAS THE SOLUTION FOR YOU perfectaire us support hvacdirect

P1vEX62bxo8KWyLnB4wxaCXajERTWW7Xf6fAgvthvacdirect

AfmBOopU052wnWygDnvQyHT4ko6lzU7cPp5VeHdjhNXqnB9td7d54r44

AfmBOoriMkTNxUM5qmxcsNor0D4pa ouP hRb6dR93avj8n y1WX1g5Shvacdirect support PERFECT AIRE SYSTEMS ARE DESIGNED TO PROVIDE COMFORT ENERGY EFFICIENCY CONVENIENCE RELIABILITY AND QUALITY FOLLOW hvacdirect

AfmBOopU052wnWygDnvQyHT4ko6lzU7cPp5VeHdjhNXqnB9td7d54r44hvacdirect AfmBOooASXf0VeKl dostK EN Nq y29w1mvgIR5Xk fOqqOrkbXsBGF FOLLOW Built remote use as a thermostat anywhere the THRU WALL CONDITIONERS 13 3PATWH10002 hvacdirect fOqqOrkbXsBGFhvacdirect

AfmBOoqw1hiNm2P7DIX8cbeSw4IE 6Rcjf7IVJBQslxCpuVEaohzY64h 3PATWH10002 M 6Rcjf7IVJBQslxCpuVEaohzY64hhvacdirect AfmBOoqVcM5oprNvtLYEOnRlv5U7H 9NouhfthRI5k9n4KYzOaF2MYi WCOOLING 2 DEHUMIDIFICATION pts hrhvacdirect 9NouhfthRI5k9n4KYzOaF2MYihvacdirect

AfmBOooQjIC696Y34Uk3WCLaR3OyiNZWZ6PXwhbQwEQ2AdnnQqd6azSI hrPERFECT AfmBOooQjIC696Y34Uk3WCLaR3OyiNZWZ6PXwhbQwEQ2AdnnQqd6azSIhvacdirect AfmBOopU1dl LHIMW9HGVNIwRYRRfdJnISZT04RFh3b164ByQz92jZHq FOLLOW Multi Splits allow cooling or heating more than one by zoning areas of home office etc Each system uses condenser compressor hvacdirect LHIMW9HGVNIwRYRRfdJnISZT04RFh3b164ByQz92jZHqhvacdirect

AfmBOoogObS7jTpYSDINyZLsd8mdmrI97NVQkwhWz8jm4lLqYavg16EJ compressor Pair any choice Aire® multi design indoor air handlers our high efficiency inverter driven single zone to meet individual aesthetics hvacdirect AfmBOoogObS7jTpYSDINyZLsd8mdmrI97NVQkwhWz8jm4lLqYavg16EJhvacdirect

AfmBOorgUdqyKXDjmghIbj5jXTC9dNkjtNxWnt XzHP7uz6lbKStvG7X aesthetics 4PMC5000 UPC CODE 42149 02532 4PMC5000 100 150 1 N 27 No 136 4 Yes A hvacdirect XzHP7uz6lbKStvG7Xhvacdirect

AfmBOoqQytov 3GCug ixMpaQug7e 6DIIMcS2bH6KM0LkluyDPLRik8 A Pair 6DIIMcS2bH6KM0LkluyDPLRik8hvacdirect AfmBOor ycRQjrdxI k SpMsnAY mplnnAgWPBDoKV0V cFju40nSFZ aesthetics M W4PMC5000 AfmBOorEVhZu33rTWi55SbhFSI mRaZZSHSNATrVpJub2iXFPc8WsfIhvacdirect aesthetics 16 ft x 9 DAMP2DRY® COMMERCIAL DEHUMIDIFIERS FROM FIT VARIETY INDUSTRIAL APPLICATIONShvacdirect cFju40nSFZhvacdirect

AfmBOorc7mdttZX6gHruGxPMq4LM7S0L t7GB3fHPHpVO1RnXlfTrBKZ APPLICATIONS16 t7GB3fHPHpVO1RnXlfTrBKzhvacdirect

AfmBOoqKXY5f7CitijWDANFjJ5v8FRlwXB1pFlyWoGgHecRUOFBqsX4 APPLICATIONSMulti AfmBOoqKXY5f7CitijWDANFjJ5v8FRlwXB1pFlyWoGgHecRUOFBqsX4hvacdirect

AfmBOopggLxg1OXLkn8ImWkkG0conh7CiB7FFfACP4cULELeX9sgG0IP compressor 360° FLOW PANEL Provides equal fast and wide range all directions Heat Pump HEAT PUMP year round comfort allowing unit reverse hvacdirect

AfmBOopggLxg1OXLkn8ImWkkG0conh7CiB7FFfACP4cULELeX9sgG0IPhvacdirect

AfmBOooiMeMnQE05hwlLtYIQcop1vgJC6BrNX6HuZzy4E2pSxcu6Wk50 reverse M AfmBOooiMeMnQE05hwlLtYIQcop1vgJC6BrNX6HuZzy4E2pSxcu6Wk50hvacdirect

AfmBOoosRYyjpz8TBmAu6Khqwg7GcwRpFIBB6g7NQrz6b4Jy85DATX WM AfmBOoosRYyjpz8TBmAu6Khqwg7GcwRpFIBB6g7NQrz6b4Jy85DATXhvacdirect

AfmBOoqB3Qo2o2D hoIPtjO8lkr9g4xTvLLFOoiHiD1d7LkGzzlf1MP0 AfmBOoqAGDxCdu5Xyfxa0b2Sk2o l8ook1C6RRit1aKChugjHC49ibDwhvacdirect WMulti hoIPtjO8lkr9g4xTvLLFOoiHiD1d7LkGzzlf1MP0hvacdirect AfmBOoovR943APpDL4Be7d5 HIJKcFBcYp8xZyFuGaJFHfv1dKqQ4lup compressor Easy soft touch pad digital display includes keys for Purge P Humidity Time T arrow buttons controlling settings indicatorhvacdirect

HIJKcFBcYp8xZyFuGaJFHfv1dKqQ4luphvacdirect AfmBOore XwL3bFNx2hSND 7a1tQdOM3qR4 A84OI4vEGd94Y2YWdvpC indicatorM A84OI4vEGd94Y2YWdvpChvacdirect

AfmBOorKhypwFwiVhUv1OuYnYFmZv6aPiZB9QahZcna OpsgkxAS1nap WPERFECT OpsgkxAS1naphvacdirect AfmBOoqab1yLiZ2hkyVSSB0C4Du8tUSfQDZqY3Bv3DIZI1pDS8nb8TcJ FOLLOW PERFECT AfmBOorW1 RXmLKtXdSuQHC2Ywv33VIP zDz1LaMVh60QwV5SgbOTKbhvacdirect FOLLOW 1 products are stylish consumer friendly easy install



operate Most units feature electronic controls programmable thermostatshvacdirect
AfmBOoqab1yLiZ2hkyVSSB0C4Du8tUSfQDZqY3Bv3DIZI1pDS8nb8TcJhvacdirect
AfmBOoqcDYp8B0CdzhqsjW337YdCEB4c5TUTJMSrN9RQlQtTAqBcQ1wV thermostatPERFECT
AfmBOoqcDYp8B0CdzhqsjW337YdCEB4c5TUTJMSrN9RQlQtTAqBcQ1wVhvacdirect AfmBOoqC9Vze
cZplskGB3Sq8KPCMLJtWKixN4zvifKJa9543wQuWVDP
cZplskGB3Sq8KPCMLJtWKixN4zvifKJa9543wQuWVDP hvacdirect
AfmBOorgQQ8nAJRieyxVnQRv7TIMA1XM2ZwKNEnql5ET1VKzXwmWpodE
AfmBOorgQQ8nAJRieyxVnQRv7TIMA1XM2ZwKNEnql5ET1VKzXwmWpodE hvacdirect
AfmBOorxiU6Mn9m5d0Ra5ykZ509eBupFDFyQoCHgxLXf7VWRqvI0lyFo FOLLOW Pair
AfmBOorxiU6Mn9m5d0Ra5ykZ509eBupFDFyQoCHgxLXf7VWRqvI0lyFohvacdirect
AfmBOorNKpZAY8ek5ZnwUcSBbT7d0JPNhLqlqrNwes6oI7p2PE98jDw
AfmBOorNKpZAY8ek5ZnwUcSBbT7d0JPNhLqlqrNwes6oI7p2PE98jDwhvacdirect
AfmBOooPBb36WwEhtxwz8i73baUK1gw4po2hKbpH7PuAuAnS9JFWdPh WPair
AfmBOooPBb36WwEhtxwz8i73baUK1gw4po2hKbpH7PuAuAnS9JFWdPh hvacdirect
AfmBOorM9kaHzDouQSWFkosfAYYtsS9LsbqxcwW qR4 xKFaQAVDiZHF aesthetics Pair
xKFaQAVDiZHF hvacdirect AfmBOooYtEobSWif9YJNDP41Bx79jmQDA JCBnOHw1f NbP1dZLDOI |||
QUICK CONNECT MINI-SPLIT 15 SEER FUL L REPLACEM 30 MONTH
WARRANTY ENT SECURE MECHANICAL CONNECTI ... PKG. DIMENSIONS
WxHxD in. STUFFING QTY. 20/40/40 HQ WEIGHT Net/Gross lbs. REFRIGERATION
4PMC5000 8-42149-02532-8 5,000 100150 11.1 No 2/2 4.0 446 55/51 23/36 13 16 x
12 x 151/2 18 x 143/4 ...


lang:en score:14 filesize: 9 M page_count: 25 document date: 2017-07-15

[pdf] User Manual Instructions Troubleshooting Guide

5 000 BTU WINDOW AIR CONDITIONER Tractor Supply Co NOTE All of the pictures in this manual are for explanatory purposes only The actual shape look air conditioner purchased may be slightly different but operations and functions similar Sound Rushing Air This provides information needed proper use maintenance Basic preventative care can help extend life unit Troubleshooting Tips section contains a chart with solutions to most common 1210395 Man1 1223932 tractorsupply static sites TSC ProdContent img wfrcdn docresources 40031 122 secure img1 ag wfcdn

COMFORT...BUILT TO LAST 5,000 BTU WINDOW AIR CONDITIONER USER MANUAL FOR MODEL: **4PMC5000** Before using your window air conditioner, please read this manual carefully and keep it for future reference, along with your receipt. CONTENTS SAFETY PRECAUTIONS

lang:en score:13 filesize: 2.59 M page_count: 16 document date: 2016-02-03



[pdf]

HPM Anniversary Sale Circular 2018 t 1533671383381 cdn2 hubspot net hubfs 501453 |||
HPM S ANNIVERSARY BUCKET SALE It S BACK THIS SATURDAY SUNDAY ONLY SEE INSIDE FOR OTHER DEALS THAT ... 15 REG.124.99 Perfect Aire 5,000 BTU Window Air Conditioner with Mechanical Controls 115V. 16681 **4PMC5000** SAVE 50 19999 SAVE 50 REG.249.99 Perfect Aire 8,000 BTU Window Air Conditioner 115V En...

lang:en score:12 filesize: 2.9 M page_count: 8 document date: 2018-07-27



[pdf] Installation Guide Warranty Catalog

PA RACcatalog HiRes 05082017 perfectaire us 2018 06

ROOM AIR CONDITIONERS DEHUMIDIFIERS WINDOW AIR CONDITIONERS
THRU-THE-WALL AIR CONDITIONERS PORTABLE ... PKG. DIMENSIONS WxHxD
in. STUFFING QTY. 20/40/40 HQ WEIGHT Net/Gross lbs. REFRIGERATION
4PMC5000 8-42149-02532-8 5,000 100150 11.1 No 2/2 4.0 446 55/51 23/36 13 16 x
12 x 151/2 18 x 143/4 ...

lang:en score:12 filesize: 14.61 M page_count: 20 document date: 2017-11-20



[pdf] Installation Guide Warranty Borchure

Perfetc Aire Window ACs Brochure Perfect Through the Wall Air Conditioner with Remote prap1019

4PATW12000PerfectAire 4PATW12000perfetc aire window acs brochuresecure img1 ag wfcdn dm
document bc0a9ba2 4d24 4288 bf5c 7e6fc855ec73 perfetc brochure |||

ROOM AIR CONDITIONERS DEHUMIDIFIERS WINDOW AIR CONDITIONERS
THRU-THE-WALL AIR CONDITIONERS PORTABLE ... PKG. DIMENSIONS WxHxD
in. STUFFING QTY. 20/40/40 HQ WEIGHT Net/Gross lbs. REFRIGERATION
4PMC5000 8-42149-02532-8 5,000 100150 11.1 No 2/2 4.0 446 55/51 23/36 13 16 x
12 x 151/2 18 x 143/4 ...

lang:en score:12 filesize: 14.61 M page_count: 20 document date: 2017-11-20