

[Manuals.plus](#) /

› [SOUNDLOGIC](#) /

› SoundLogic XT USB Soft Flexible Silicone Wired Travel Keyboard User Manual

SOUNDLOGIC FKB-12/4931

SoundLogic XT USB Soft Flexible Silicone Wired Travel Keyboard User Manual

Model: FKB-12/4931

INTRODUCTION

This manual provides instructions for the SoundLogic XT USB Soft Flexible Silicone Wired Travel Keyboard, model FKB-12/4931. This keyboard is designed for portability and durability, featuring a soft, flexible, and washable silicone construction. It connects via USB and is compatible with Microsoft Windows operating systems.

PRODUCT FEATURES

- Durable waterproof silicone construction.
- Connects directly to your computer's USB port.
- Compatible with Microsoft Windows operating systems (Windows 98, 2000, XP, 7). Not compatible with Mac products.
- Washable design for easy cleaning.
- Ultra-slim and lightweight for travel and portability.

PACKAGE CONTENTS

The package for your SoundLogic XT Flexible Silicone Keyboard includes:

- 1x SoundLogic XT USB Soft Flexible Silicone Wired Travel Keyboard
- 1x Integrated USB Cable





Image: Packaging of the SoundLogic XT Flexible Silicone Keyboard, displaying the product name and key features like portability and spillproof design, with a black keyboard shown on the package.

SETUP

1. **Unroll the Keyboard:** Carefully unroll the silicone keyboard to its flat, usable position. Ensure it is placed on a stable, flat surface.

2. **Connect to USB Port:** Locate an available USB port on your computer. Insert the USB connector of the keyboard firmly into the USB port.
3. **Driver Installation (Automatic):** For most Windows operating systems, the keyboard will be recognized automatically, and necessary drivers will install without user intervention. A notification may appear indicating that the device is ready for use.
4. **Test Functionality:** Open a text editor or word processing program and type a few characters to confirm the keyboard is working correctly.



Image: The SoundLogic XT Flexible Silicone Keyboard (shown in blue, though available in black and other colors) rolled up, showcasing its compact form factor and the integrated USB cable.

OPERATING INSTRUCTIONS

The SoundLogic XT Flexible Silicone Keyboard functions like a standard QWERTY keyboard. Simply connect it to your computer's USB port, and it will be ready for use.

- **Typing:** Press the keys as you would on a conventional keyboard. Due to the flexible silicone material, a slightly firmer press may be required compared to rigid keyboards.

- **Portability:** When not in use, the keyboard can be rolled up or folded for easy storage and transport.
- **Compatibility:** This keyboard is designed for use with Microsoft Windows operating systems only. It is not compatible with Apple Mac products or other operating systems.

MAINTENANCE AND CARE

One of the key advantages of your silicone keyboard is its ease of cleaning.

- **Cleaning:** The keyboard can be cleaned with mild soap and water. Ensure the USB connector is not submerged or exposed to water during cleaning. Allow the keyboard to dry completely before reconnecting it to a computer.
- **Storage:** Store the keyboard rolled up or flat in a clean, dry environment away from direct sunlight and extreme temperatures.
- **Avoid Sharp Objects:** Do not use sharp objects on the keyboard surface, as this may damage the silicone material.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard not responding.	USB connection is loose or faulty.	Ensure the USB cable is securely plugged into the computer's USB port. Try a different USB port.
Keys are unresponsive or require hard pressing.	This is characteristic of flexible silicone keyboards.	Apply a firm, deliberate press to each key. Ensure the keyboard is on a flat, stable surface.
Keyboard not recognized by computer.	Driver issue or incompatibility.	Restart your computer. Verify your operating system is Microsoft Windows. This keyboard is not compatible with Mac OS.
Keyboard is dirty.	Accumulation of dust or spills.	Disconnect the keyboard from the computer. Clean with mild soap and water, avoiding the USB connector. Allow to dry completely before use.

SPECIFICATIONS

Brand	SoundLogic
Model Number	FKB-12/4931
Connectivity Technology	USB Wired
Material	Silicone
Color	Black (other colors may be available)
Operating System Compatibility	Microsoft Windows (Windows 98, 2000, XP, 7)
Product Dimensions (LxWxH)	5.25 x 0.63 x 13.75 inches
Item Weight	7.8 ounces

Special Feature

Water Resistant, Flexible, Washable

WARRANTY AND SUPPORT

For warranty information or technical support regarding your SoundLogic XT USB Soft Flexible Silicone Wired Travel Keyboard, please refer to the documentation included with your purchase or visit the official SoundLogic website. Keep your proof of purchase for warranty claims.

© 2024 SoundLogic. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0071368H8>

More documents and user manuals: <https://manuals.plus/>