

Bahco 2058-BR

Bahco 2058-BR 1/4-Inch Bit Ratchet Instruction Manual

Model: 2058-BR

INTRODUCTION

Thank you for choosing the Bahco 2058-BR 1/4-Inch Bit Ratchet. This manual provides essential information for the safe and efficient use, setup, operation, and maintenance of your new tool. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

Always observe basic safety precautions when using hand tools to reduce the risk of injury.

- Wear appropriate personal protective equipment, such as safety glasses, to protect against flying debris.
- Ensure the workpiece is securely fastened before applying force with the tool.
- Do not use the tool if it is damaged or appears to be malfunctioning.
- Keep hands and fingers clear of moving parts and the bit during operation.
- Use the correct size and type of bit for the fastener to prevent stripping or damage.
- Store the tool in a dry, secure place, out of reach of children.

PACKAGE CONTENTS

Verify that all items are present upon opening the package:

- 1 x Bahco 2058-BR 1/4-Inch Bit Ratchet

PRODUCT OVERVIEW

The Bahco 2058-BR is a compact and versatile bit ratchet designed for use in confined spaces. It features a 1/4-inch bit drive and an integrated 8mm ring spanner.



Front view of the Bahco 2058-BR 1/4-inch bit ratchet, showing the handle, the 1/4-inch bit drive, and the 8mm ring spanner end.



Top view of the Bahco 2058-BR 1/4-inch bit ratchet, highlighting the compact design and the Bahco branding.

SETUP

The Bahco 2058-BR is ready for use with standard 1/4-inch hex bits. No assembly is required.

1. **Selecting a Bit:** Choose the appropriate 1/4-inch hex bit for your fastener.
2. **Inserting the Bit:** Firmly push the hex bit into the 1/4-inch drive opening on the ratchet head until it clicks into place. Ensure the bit is fully seated.
3. **Removing the Bit:** Pull the bit straight out from the drive opening.

OPERATING INSTRUCTIONS

This tool offers two primary functions: a 1/4-inch bit ratchet and an 8mm ring spanner.

Using the 1/4-Inch Bit Ratchet

1. **Direction Selection:** Locate the small lever or switch on the ratchet head. Move it to select the desired direction for tightening (clockwise) or loosening (counter-clockwise) fasteners.

2. **Engaging the Fastener:** Place the inserted bit onto the head of the fastener.
3. **Applying Torque:** Rotate the handle to turn the fastener. The ratchet mechanism allows for continuous turning without repositioning the tool, especially useful in tight spaces.

Using the 8mm Ring Spanner

The opposite end of the tool features an integrated 8mm ring spanner.

1. **Engaging the Fastener:** Place the 8mm ring end over an 8mm nut or bolt head.
2. **Applying Torque:** Turn the tool to tighten or loosen the fastener.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your tool.

- **Cleaning:** After each use, wipe the tool clean with a dry cloth to remove dirt, grease, or debris. For stubborn grime, a mild solvent can be used, followed by thorough drying.
- **Lubrication:** Periodically apply a small amount of light machine oil to the ratchet mechanism to ensure smooth operation. Avoid over-lubricating.
- **Storage:** Store the ratchet in a dry environment to prevent rust. Keep it away from corrosive materials and extreme temperatures.
- **Inspection:** Regularly inspect the tool for any signs of wear, damage, or loose parts. Do not use a damaged tool.

TROUBLESHOOTING

If you encounter issues with your Bahco 2058-BR, consider the following common solutions:

- **Bit not holding securely:** Ensure the bit is fully inserted into the drive. Check the bit for wear or damage.
- **Ratchet mechanism feels stiff or slips:** The mechanism may require cleaning or light lubrication. Refer to the Maintenance section.
- **Difficulty turning fasteners:** Ensure you are using the correct size bit for the fastener. Do not apply excessive force that could damage the tool or fastener.

SPECIFICATIONS

Feature	Specification
Brand	Bahco
Model	2058-BR
Material	Alloy Steel
Drive Size	1/4-inch DIN 3126-C 6, ISO 1173
Integrated Spanner Size	8mm
Item Weight	1.41 ounces
Product Dimensions	11.02 x 11.02 x 3.94 inches
Included Components	1 x Bit ratchet

Feature	Specification
Compatible Fastener Range	0.25 inches

WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the documentation provided with your purchase or visit the official Bahco website. Contact the manufacturer directly for assistance with product-related inquiries or issues.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question