

PLAYMOBIL 5176

Playmobil 5176 Police Headquarter with Alarm Instruction Manual

Model: 5176 | Brand: PLAYMOBIL

INTRODUCTION

Welcome to the Playmobil 5176 Police Headquarter with Alarm. This playset provides an immersive experience for children aged 4 to 12 years, encouraging creative thinking, problem-solving skills, and role-play. The set features a multi-level police station with an integrated alarm system for exciting escape scenarios.

SAFETY INFORMATION

- **Choking Hazard:** Contains small parts. Not suitable for children under 3 years.
- Adult supervision is recommended during assembly and play.
- Ensure all components are securely assembled before play to prevent detachment.
- Dispose of packaging materials responsibly.

PACKAGE CONTENTS

The Playmobil 5176 Police Headquarter package includes various components necessary for assembly and play. Please verify that all parts are present before beginning assembly.

- Police Headquarter structure components
- Police figures and accessories (e.g., weapons, handcuffs, communication devices)
- Office furniture (desk, chairs, computer)
- Alarm unit and related parts
- Small vehicle (bicycle)
- Instruction booklet (this manual)

SETUP AND ASSEMBLY

While the main structure may come partially assembled, some components and accessories require attachment. Follow the visual instructions provided in the physical manual for detailed step-by-step assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Assemble Main Structure:** Connect the floor and wall sections as indicated in the diagrams. Ensure all connections are firm.
3. **Install Staircase:** Attach the spiral staircase to connect the levels of the headquarter.
4. **Place Furniture and Accessories:** Arrange the office desk, computer, and other small accessories in their designated areas.
5. **Battery Installation for Alarm:**
 - Locate the battery compartment for the alarm unit (typically on the roof or near the cell).
 - Using a small screwdriver, open the battery compartment.
 - Insert 2 AA batteries, ensuring correct polarity (+/-).
 - Close the battery compartment securely.
6. **Attach Alarm Unit:** Secure the alarm unit to the designated spot, usually above the escape cell.
7. **Position Figures:** Place the police figures and other characters in their roles.



Image: The fully assembled Playmobil 5176 Police Headquarter, showcasing its multi-level design, police figures, office area, and the cell with an escape mechanism. The alarm unit is visible on the roof of the cell block.

OPERATING INSTRUCTIONS

The Playmobil Police Headquarter offers interactive play features, most notably the alarm system.

Alarm Function

The playset includes a unique alarm feature designed to simulate a prisoner escape.

- Prisoner Placement:** Place a prisoner figure inside the cell.
- Escape Mechanism:** The cell features a hidden "hole" in the floor with a hook and rope. When a figure attempts to escape through this mechanism, it triggers the alarm.
- Alarm Activation:** The alarm unit, powered by 2 AA batteries, will emit a siren sound when the escape attempt is detected.
- Resetting the Alarm:** The alarm typically resets once the escape mechanism is returned to its original position or after a short duration.

General Play

Encourage imaginative play by utilizing the various areas of the police headquarter:

- Command Center:** Use the desk and computer accessories for police officers to monitor activity.
- Cell Block:** Secure prisoners in the cell.
- Patrol:** Utilize the figures and bicycle for patrol scenarios around the headquarter.

MAINTENANCE

- Cleaning:** Wipe the playset with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Storage:** Store the playset in a dry, cool place away from direct sunlight to prevent material degradation.
- Battery Replacement:** Replace AA batteries in the alarm unit when the sound becomes faint or stops working.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Alarm not sounding	<ul style="list-style-type: none">Batteries are dead or incorrectly installed.Alarm mechanism is not properly triggered.	<ul style="list-style-type: none">Check and replace the 2 AA batteries, ensuring correct polarity.Ensure the escape mechanism is fully engaged to trigger the sensor.
Parts do not fit together	<ul style="list-style-type: none">Incorrect orientation of parts.Excessive force being used.	<ul style="list-style-type: none">Refer to the assembly diagrams in the physical manual and re-orient parts.Ensure parts are aligned correctly before applying gentle pressure.

SPECIFICATIONS

- **Model Name:** 5176
- **Brand:** PLAYMOBIL
- **Material:** Plastic
- **Color:** Blue
- **Item Dimensions (L x W x H):** 55 x 36 x 53 cm (21.65 x 14.17 x 20.87 inches)
- **Item Weight:** 2.62 kg (5.78 lbs)
- **Recommended Age:** 4 - 12 years
- **Educational Objective:** Creative Thinking, Problem Solving Skills, Role Play
- **Power Source:** Manual (for general play)
- **Batteries Required:** 2 x AA batteries (for alarm function, included)
- **Assembly Required:** No (Note: Some minor accessory placement and battery installation may be needed)

WARRANTY AND SUPPORT

For information regarding warranty coverage or to obtain support for your Playmobil 5176 Police Headquarter, please refer to the official Playmobil website or contact their customer service department. Keep your proof of purchase for any warranty claims.

Official Playmobil Website: www.playmobil.com