Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Freaks And Geeks 150015

Freaks and Geeks PS5 Ventilated Charging Station User Manual

Model: 150015

1. Introduction

Thank you for purchasing the Freaks and Geeks PS5 Ventilated Charging Station. This product is designed to enhance your PlayStation 5 gaming experience by providing efficient cooling for your console and convenient charging for two DualSense wireless controllers. It also includes additional USB ports for your accessories. Please read this manual carefully before use to ensure proper setup and operation.

2. Safety Information

- Keep the device away from water, moisture, and high temperatures.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Ensure proper ventilation around the charging station and console.
- Use only the provided or recommended power sources and cables.
- Keep out of reach of children.
- Avoid dropping or subjecting the device to strong impacts.

3. Package Contents

The package should contain the following items:

- 1 x Freaks and Geeks PS5 Ventilated Charging Station
- 1 x USB Connection Cable
- 1 x Adapter for PS5 Digital Edition Console (if applicable)

4. Product Overview

Familiarize yourself with the components and features of your charging station.



Figure 4.1: Labeled diagram of the Freaks and Geeks PS5 Ventilated Charging Station. This image highlights key features including two controller charging ports, two cooling fans for the console, three USB ports, a fan on/off button, and load indicators for charging status. It also shows the USB connection cable and an adapter for the PS5 Digital Edition.

- **Controller Charging Ports:** Two dedicated slots for charging PlayStation 5 DualSense wireless controllers.
- **Cooling Fans:** Two integrated fans designed to dissipate heat from the PS5 console.
- **USB Ports:** Three additional USB ports for connecting other accessories or charging low-power devices.
- **Fan On/Off Button:** Allows manual control over the cooling fan operation.
- **Load Indicators:** LED indicators to show the charging status of the controllers.
- **Console Stand:** Provides a stable vertical stand for your PS5 console.

5. Setup Instructions

Follow these steps to set up your Freaks and Geeks PS5 Ventilated Charging Station:

1. **Place the Station:** Choose a stable, flat surface with adequate ventilation for the charging station.

2. **Connect to PS5:** Connect the included USB cable from the charging station to an available USB port on your PlayStation 5 console. This provides power to the station.
3. **Position PS5 Console:** Carefully place your PlayStation 5 console vertically onto the stand. If you have the PS5 Digital Edition, ensure the appropriate adapter is used for a secure fit.
4. **Initial Power On:** Once connected, the station should receive power from the PS5.




Figure 5.1: The PlayStation 5 console securely placed on the ventilated charging station. Blue swirling lines indicate the upward airflow generated by the cooling fans, designed to enhance heat dissipation from the console.



Figure 5.2: A complete setup showing the PS5 console mounted on the charging station, with two DualSense controllers docked in their respective charging ports. The image also depicts icons representing charging, lighting, and fan functions.

6. Operating Instructions

6.1. Charging Controllers

1. Ensure the charging station is powered on and connected to your PS5 console.
2. Align your DualSense wireless controller with one of the charging ports on the station.
3. Gently push the controller down until it clicks into place and makes contact with the charging pins.
4. The load indicator LED for that port will illuminate, typically indicating charging status (e.g., red for charging, blue/green for fully charged).
5. Charging time for a fully depleted controller is approximately 2-3 hours.



Figure 6.1: A close-up view of the controller charging ports on the station. Blue lightning bolt icons indicate active charging, showing the connection points for the DualSense controllers.



Figure 6.2: Two DualSense controllers docked for charging on the station. The background illustrates a circular timer, suggesting typical charging durations of 1 to 2 hours for a full charge.

6.2. Using Cooling Fans

The integrated cooling fans help maintain optimal operating temperatures for your PS5 console.

- Locate the fan on/off button on the charging station.
- Press the button once to turn the cooling fans on.
- Press the button again to turn the cooling fans off.
- It is recommended to use the cooling fans during extended gaming sessions or in warm environments.

6.3. Using USB Ports

The three additional USB ports can be used for various purposes:

- Connect other USB-powered accessories (e.g., external hard drives, headsets).
- Charge other low-power USB devices.
- Note that these ports are primarily for data transfer and low-power charging, not for high-power devices.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe down the charging station. Do not use abrasive cleaners or solvents.
- **Dust Removal:** Periodically check the fan vents for dust accumulation. Use compressed air to gently clear any dust to ensure optimal cooling performance.
- **Storage:** When not in use for an extended period, disconnect the station from power and store it in a cool, dry place.

8. Troubleshooting

Problem	Possible Cause	Solution
Station not powering on.	USB cable not properly connected. PS5 console not powered on.	Ensure the USB cable is securely connected to both the station and the PS5. Verify the PS5 console is powered on.
Controllers not charging.	Controller not seated correctly. Charging pins obstructed.	Reseat the controller firmly into the charging port. Check for any debris obstructing the charging pins on both the controller and the station.
Cooling fans not working.	Fans are turned off. Power issue.	Press the fan on/off button to activate the fans. Check if the station is receiving power from the PS5.
USB ports not functioning.	Device connected requires too much power. Station not powered.	Ensure the connected device is low-power. Verify the charging station is powered on.

9. Specifications

Feature	Detail
Model Number	150015
Product Dimensions	3.94 x 1.97 x 0.5 inches
Item Weight	1.19 pounds
Input Voltage	2 Volts (AC)
Output Current	1 Amps
Total USB Ports	3
Compatible Devices	PlayStation 5 Console, DualSense Controllers
Color	Black
Manufacturer	Freaks and Geeks

10. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Freaks and Geeks website. Specific warranty terms and contact details are not available in this

manual.

© 2023 Freaks and Geeks. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0079DKX0S

More documents and user manuals: **https://manuals.plus/**