

[Manuals.plus](#) /

› [NP99sp](#) /

› NP99sp NewPower99 Battery Replacement Kit for Garmin Nuvi 1410 Instruction Manual

NP99sp Nuvi 1410

NP99sp NewPower99 Battery Replacement Kit for Garmin Nuvi 1410 Instruction Manual


INTRODUCTION

This manual provides essential instructions for the safe and effective replacement of the battery in your Garmin Nuvi 1410 GPS device using the NP99sp NewPower99 Battery Replacement Kit. The kit includes a high-capacity lithium polymer battery, specialized tools, and access to video instructions to guide you through the process. Please read all instructions carefully before beginning the battery replacement.

WHAT'S INCLUDED IN YOUR KIT

Your NP99sp NewPower99 Battery Replacement Kit for Garmin Nuvi 1410 contains the following components:

- High-Capacity 1250 mAh 3.7V Lithium Polymer Battery
- Specialized Tools for device disassembly and reassembly
- Access to detailed Video Instructions



This image displays the front packaging of the NP99sp NewPower99 Battery Replacement Kit, highlighting key features such as a one-year warranty, included tools, and instructional video.



The back of the kit's packaging, detailing the advantages of battery replacement and listing the types of devices supported by NewPower99 kits, including GPS devices.

SETUP AND INSTALLATION

Important Safety Precautions:

- Ensure your Garmin Nuvi 1410 is powered off and disconnected from any charging source before beginning.

- Handle the battery and electronic components with care to avoid damage.
- Use only the tools provided or recommended for this procedure.
- Lithium Polymer batteries can be hazardous if punctured or damaged. Exercise caution.
- If you are unsure about any step, consult a professional.

General Installation Steps:

The battery replacement process involves carefully opening the device, disconnecting the old battery, installing the new battery, and reassembling the device. For detailed, step-by-step visual guidance, please refer to the official NewPower99 video instructions provided below. While the video may show various devices, the general principles and tool usage apply to your Garmin Nuvi 1410.

Your browser does not support the video tag.

This video provides a general overview of the NewPower99 battery replacement process for various electronic devices, including GPS units. It demonstrates the use of included tools and the steps involved in safely replacing a battery. Follow the specific instructions for your Garmin Nuvi 1410.

1. **Disassembly:** Carefully use the provided tools to open the casing of your Garmin Nuvi 1410. Pay attention to any clips or screws.
2. **Old Battery Removal:** Locate the existing battery. Gently disconnect its connector from the device's circuit board. Remove the old battery, noting its position.
3. **New Battery Installation:** Connect the new NP99sp battery to the circuit board. Position the new battery securely within the device.
4. **Reassembly:** Carefully close the device casing, ensuring all clips and screws are properly secured.
5. **Initial Charge:** After reassembly, connect your Garmin Nuvi 1410 to a power source and allow it to fully charge before first use.

OPERATING YOUR DEVICE AFTER BATTERY REPLACEMENT

Once the new battery is installed and fully charged, your Garmin Nuvi 1410 should function as expected. Power on the device and verify its operation. It may take a few charge cycles for the new battery to reach its optimal performance.

BATTERY MAINTENANCE

- **Regular Charging:** Charge your device regularly to maintain battery health.
- **Avoid Extreme Temperatures:** Do not expose your device to excessively high or low temperatures, as this can degrade battery performance and lifespan.
- **Storage:** If storing the device for an extended period, ensure the battery is charged to approximately 50% to prevent deep discharge.

TROUBLESHOOTING

- **Device Not Powering On:** Double-check all internal connections, especially the battery connector. Ensure the battery has an initial charge.
- **Battery Not Charging:** Verify that the charging cable and adapter are functioning correctly. Ensure the battery connector is firmly seated.
- **Short Battery Life:** Allow for a few full charge/discharge cycles for the battery to calibrate. If issues persist, re-verify installation steps.

- **Physical Damage:** If any components appear damaged during installation, cease operation and contact support.

SPECIFICATIONS

Feature	Detail
Brand	NP99sp
Model Number	Nuvi 1410
Battery Cell Composition	Lithium Polymer
Battery Capacity	1250 Milliampere Hour (mAh)
Voltage	3.7 Volts
Reusability	Rechargeable
Compatible Device	Garmin Nuvi 1410
Unit Count	1 Count
Item Dimensions	5 x 0.5 x 6 inches
UPC	816531012623

WARRANTY INFORMATION

The NP99sp NewPower99 Battery Replacement Kit for Garmin Nuvi 1410 is backed by a **Full One Year Warranty**. This warranty covers manufacturing defects and ensures the battery meets specified performance standards. For warranty claims or further details, please retain your proof of purchase.

SUPPORT

For additional assistance, troubleshooting, or inquiries regarding your NP99sp NewPower99 Battery Replacement Kit, please visit the [NP99sp Store on Amazon](#) or contact customer service through the platform where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0079GIKAA>

More documents and user manuals: <https://manuals.plus/>