

[Manuals.plus](#) /

› [Yamaha](#) /

› Yamaha Genuine Seat with Base for Vino SA26J/SA37J 4-Stroke Scooters Instruction Manual

Yamaha SA26J/SA37J

Yamaha Genuine Seat with Base for Vino SA26J/SA37J 4-Stroke Scooters

Instruction Manual

1. INTRODUCTION

This manual provides essential instructions for the installation and care of your new Yamaha Genuine Seat with Base. This product is a genuine Yamaha part, ensuring compatibility and quality for your scooter. This seat is specifically designed for Yamaha Vino 4-stroke scooter models **SA26J** and **SA37J**. It serves as a direct replacement part, ensuring proper fit and function without modifications.

Part Number: 5ST-F4730-11

Item Model Number: 990618



Image 1: Yamaha Genuine Seat with Base. This image displays the complete seat assembly, including the black seat cushion and its integrated base, ready for installation on compatible Yamaha Vino scooter models.

2. PARTS LIST

The product package includes the following:

- One (1) Yamaha Genuine Seat Assembly with Base (Black)

No additional components are typically required for installation, as this product is designed to replace the existing seat assembly directly.

3. SETUP AND INSTALLATION

Follow these steps for proper installation of your new seat:

Tools Required:

- Phillips head screwdriver or appropriate wrench (depending on existing seat mounting hardware)

Installation Procedure:

1. Ensure the scooter is parked on a stable, level surface with the engine off and the ignition key removed for safety.
2. Locate the mounting bolts for the existing seat. These are typically found at the rear of the seat, near the hinge mechanism, or underneath the seat itself.
3. Using the appropriate tool, carefully remove the existing seat mounting bolts. Keep these bolts for reuse if the new seat does not include new hardware.
4. Gently lift and remove the old seat assembly from the scooter.
5. Position the new Yamaha Genuine Seat with Base onto the scooter, aligning the mounting points on the seat base with the corresponding holes on the scooter's frame.
6. Insert the mounting bolts and hand-tighten them initially to ensure proper alignment.
7. Once all bolts are in place and aligned, tighten them securely. **Do not overtighten** to avoid damaging the seat base or the scooter frame.
8. Test the seat's stability by gently pushing down on it and checking for any movement.
9. Verify that the seat latch mechanism (if applicable to your scooter model) engages and disengages properly.

Note: For scooter-specific instructions or if you encounter difficulties, refer to your Yamaha Vino SA26J/SA37J service manual.

4. OPERATING

The seat functions as a standard scooter seat. Ensure it is securely latched and properly closed before operating the scooter.

If your scooter model includes a seat lock, always engage it when leaving the scooter unattended to secure any items stored beneath the seat.

5. MAINTENANCE

Proper care will extend the life and appearance of your seat:

- **Cleaning:** Wipe the seat surface with a damp cloth and a mild, non-abrasive soap solution. Avoid harsh chemicals, solvents, or abrasive cleaners, which can damage the seat material. Rinse thoroughly with clean water and dry with a soft cloth.
- **Protection:** To prolong the life of the seat, especially if the scooter is stored outdoors, consider using a scooter cover to protect it from prolonged exposure to direct sunlight, UV rays, and rain.
- **Inspection:** Periodically check the seat's mounting bolts for tightness. Inspect the seat material for any signs of wear, cracks, or damage. Address any issues promptly to prevent further deterioration.

6. TROUBLESHOOTING

If you encounter issues with your new seat, consider the following:

- **Seat does not fit correctly:** Double-check that your scooter model is indeed a Yamaha Vino SA26J or SA37J. Verify the part number 5ST-F4730-11. Ensure proper alignment of the seat base with the scooter's mounting points during installation.
- **Seat feels loose after installation:** Re-tighten all mounting bolts securely. If the issue persists, inspect the mounting points on both the seat base and the scooter frame for any damage, wear, or misalignment that might prevent a snug fit.
- **Seat latch not engaging or releasing:** Ensure the seat is fully pressed down and properly aligned with the latch mechanism on the scooter. Check the latch mechanism itself for any obstructions, debris, or damage that might impede its function.

7. SPECIFICATIONS

Brand	Yamaha
Part Number	5ST-F4730-11
Item Model Number	990618
Compatible Models	Yamaha Vino 4-stroke (SA26J/SA37J)
Color	Black
Package Dimensions	58 x 38 x 16.5 cm
Item Weight	1.6 kg

8. WARRANTY AND SUPPORT

This product is a genuine Yamaha part, manufactured to high standards. For specific warranty information, please refer to the documentation provided with your purchase or contact your authorized Yamaha dealer. For technical support or assistance with this product, please contact your authorized Yamaha dealer or the manufacturer directly. Keep your purchase receipt as proof of purchase for any warranty claims.