

[Manuals.plus](#) /

› [DELTA](#) /

› Delta Faucet Water Efficient Hand Shower Instruction Manual

DELTA 59434-15-BG

Delta Faucet Water Efficient Hand Shower Instruction Manual

Model: 59434-15-BG

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Delta Faucet Water Efficient Hand Shower, Model 59434-15-BG. Designed for water efficiency and user convenience, this hand shower offers a versatile showering experience while helping to conserve water.

The Delta WaterSense labeled products are engineered to use at least 20% less water than the industry standard, contributing to water conservation without compromising performance.

SAFETY INFORMATION

Please read all instructions carefully before installation and use. Keep this manual for future reference.

- Ensure water supply is turned off before beginning any installation or maintenance.
- Use appropriate tools and protective gear during installation.
- Do not overtighten connections, as this may damage the product.
- If you are unsure about any step, consult a qualified plumber.

COMPONENTS LIST

Verify that all components are present before beginning installation. The package typically includes:

- Delta Faucet Hand Shower (Model 59434-15-BG)
- Installation Instructions
- *Note: Shower hose and wall mount/holder are typically sold separately.*



Figure 1: Delta Faucet Hand Shower (Model 59434-15-BG) in Chrome finish.

SETUP AND INSTALLATION

Follow these steps to install your hand shower. Ensure you have a compatible shower hose and wall mount/holder (not included).

1. **Turn Off Water Supply:** Locate the main water shut-off valve for your bathroom or entire home and turn it off.
2. **Remove Old Shower Head (if applicable):** Unscrew your existing shower head from the shower arm or hose. Clean any old sealant or debris from the threads.
3. **Apply Plumber's Tape:** Wrap plumber's tape (Teflon tape) clockwise around the threads of your shower hose or

shower arm. This helps create a watertight seal.

4. **Attach Hand Shower:** Screw the Delta hand shower onto the threaded end of your shower hose. Hand-tighten first, then use a wrench to tighten an additional quarter to half turn. Do not overtighten.
5. **Install Wall Mount/Holder (if applicable):** If using a new wall mount, follow its specific installation instructions. Ensure it is securely fastened and can hold the hand shower firmly.
6. **Check for Leaks:** Turn the main water supply back on slowly. Check all connections for leaks. If leaks occur, tighten the connections slightly or reapply plumber's tape.



Figure 2: Detailed view of the hand shower's spray face.

OPERATING INSTRUCTIONS

Your Delta hand shower features multiple spray settings and a pause function for enhanced control and water conservation.

Changing Spray Settings

The hand shower offers 5 distinct spray settings. To change the spray pattern, rotate the spray face or the lever/dial on the shower head (depending on specific design) until you reach your desired setting. Common settings include:

- **Full Body Spray:** A consistent, strong spray for everyday showering.
- **Massage Spray:** A pulsating spray for muscle relaxation.
- **Pause Setting:** Reduces water to a trickle, allowing you to lather or shave without changing the water temperature.
- Other specialized sprays may be available depending on the model.

Using the Pause Feature

To activate the pause setting, typically press a button or rotate the spray face to the designated pause icon. This feature temporarily reduces water flow to a trickle, conserving water while maintaining your desired water temperature. To resume full flow, simply adjust the setting again.

MAINTENANCE

Regular cleaning will help maintain the performance and appearance of your hand shower.

Cleaning the Hand Shower

- Use a soft cloth and mild soap or a non-abrasive cleaner specifically designed for chrome finishes.
- Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the finish.
- For mineral deposits (limescale) on the spray nozzles, gently rub them with your finger or a soft brush. Some Delta hand showers feature Touch-Clean® spray holes that allow for easy removal of mineral buildup.
- Rinse thoroughly with clean water after cleaning and wipe dry to prevent water spots.

TROUBLESHOOTING

If you encounter issues with your hand shower, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Low Water Pressure	Mineral buildup in nozzles. Partially closed shut-off valve. Clogged hose or filter.	Clean spray nozzles (see Maintenance). Ensure all water valves are fully open. Inspect and clean the shower hose and any inline filters.
Leaking Connections	Loose connection. Insufficient plumber's tape. Damaged washer/gasket.	Tighten connection slightly. Reapply plumber's tape. Replace washer/gasket if damaged.
Difficulty Changing Spray Settings	Mineral buildup.	Clean the spray face and rotating mechanism.

SPECIFICATIONS

Feature	Detail
Brand	DELTA
Model Number	59434-15-BG
Color	Chrome
Material	Chrome
Finish Type	Chrome
Flow Rate	1.5 Gallons Per Minute (GPM) / 5.7 Liters Per Minute (L/min)
Number of Settings	5
Product Dimensions	8.5"L x 3.5"W
Item Weight	6.9 ounces
Special Feature	WaterSense label
Installation Type	Wall Mounted (requires separate hose/mount)

WARRANTY AND SUPPORT

Delta Faucet products are manufactured to the highest quality standards and are backed by a comprehensive warranty. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Delta Faucet website.

For technical assistance, replacement parts, or further inquiries, please contact Delta Faucet customer support:

- **Website:** www.deltafaucet.com
- **Customer Service:** Refer to the website for current contact numbers and hours of operation.

When contacting support, please have your product model number (59434-15-BG) and date of purchase available.

© 2024 Delta Faucet Company. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B007CM2MEG>

More documents and user manuals: <https://manuals.plus/>