

[manuals.plus](#) /› [Kenwood](#) /› [Kenwood HB680P 450W Triblade Hand Blender User Manual](#)

Kenwood HB680P

Kenwood HB680P 450W Triblade Hand Blender User Manual

Model: HB680P

IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using your Kenwood HB680P hand blender and retain them for future reference. Incorrect use may result in injury or damage to the appliance.

- Always ensure the voltage on the rating label corresponds to your mains supply.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Keep hands, hair, clothing, and utensils away from moving parts during operation to prevent injury.
- Never blend hot liquids without allowing them to cool slightly. Hot liquids can splash and cause burns.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- The blades are very sharp. Handle with extreme care during assembly, disassembly, and cleaning.

PRODUCT OVERVIEW

The Kenwood HB680P is a powerful 450W Triblade hand blender designed for efficient blending, pureeing, and chopping. Its unique Triblade system ensures faster and more effective results. The appliance includes a convenient 0.5-liter beaker for measuring and blending.



This image displays the Kenwood HB680P hand blender in white, alongside its transparent 0.5-liter measuring beaker. The blender features a comfortable grip handle with control buttons and a detachable blending shaft.

Components:

- **Motor Unit:** The main body containing the motor and control buttons.
- **Triblade Blending Shaft:** Detachable shaft with three sharp blades for efficient blending.
- **0.5L Beaker:** A transparent measuring beaker for preparing ingredients.

SETUP

Follow these steps to prepare your hand blender for first use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean Before First Use:** Wash the blending shaft and beaker in warm soapy water, then rinse and dry thoroughly. Wipe the motor unit with a damp cloth.
3. **Assemble Blending Shaft:** Align the blending shaft with the motor unit and twist until it locks securely into place. Ensure it is firmly attached before use.
4. **Position:** Place the ingredients you wish to blend into the 0.5L beaker or another suitable container.

OPERATING INSTRUCTIONS

General Use

1. **Connect Power:** Plug the hand blender into a suitable power outlet.
2. **Immerse Blender:** Submerge the blending shaft into the ingredients in the beaker or container. Ensure the blades are fully covered.
3. **Start Blending:** Press and hold the power button to start the blending process. Move the blender up and down gently to ensure all ingredients are processed evenly.
4. **Stop Blending:** Release the power button to stop the appliance.
5. **Unplug:** Always unplug the hand blender from the power outlet immediately after use.

Using the Turbo Boost

The Kenwood HB680P features a Turbo Boost function for extra power when needed, ideal for tougher ingredients or achieving a finer consistency.

- While blending, press and hold the **Turbo Boost** button. The blender will operate at maximum speed.
- Release the Turbo Boost button to return to the normal operating speed or to stop the appliance.

- Use the Turbo Boost in short bursts to avoid overheating the motor.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your hand blender.

1. **Unplug:** Always unplug the appliance before cleaning.
2. **Detach Blending Shaft:** Twist and pull the blending shaft away from the motor unit.
3. **Clean Blending Shaft and Beaker:** Wash these parts in warm soapy water immediately after use. Rinse thoroughly and dry. These parts are generally dishwasher safe, but refer to the product manual for specific instructions.
4. **Clean Motor Unit:** Wipe the motor unit with a damp cloth. Never immerse the motor unit in water or place it under running water.
5. **Storage:** Store the hand blender and its accessories in a dry place, away from direct sunlight and out of reach of children.

TROUBLESHOOTING

If you encounter any issues with your Kenwood HB680P hand blender, refer to the table below for common problems and their solutions.

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power outlet fault; motor unit not properly assembled with shaft.	Check power cord connection; test outlet with another appliance; ensure blending shaft is securely locked.
Poor blending results.	Too much food; insufficient liquid; ingredients too large.	Reduce quantity of ingredients; add more liquid; cut ingredients into smaller pieces.
Motor stops during operation or overheats.	Overloaded motor; continuous operation for too long.	Unplug and allow the appliance to cool down for at least 30 minutes; reduce load; use in shorter bursts.
Unusual noise or vibration.	Blending shaft not properly attached; foreign object in blades.	Ensure blending shaft is securely locked; unplug and check blades for obstructions.

SPECIFICATIONS

Feature	Specification
Brand	Kenwood
Model Number	HB680P
Wattage	450 Watts

Feature	Specification
Voltage	220 Volts
Beaker Capacity	500 Milliliters
Special Feature	Turbo Boost
Material	Stainless Steel, Plastic
Power Source	Corded Electric
Product Weight	1.1 kg

WARRANTY AND SUPPORT

Your Kenwood HB680P hand blender comes with a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions, including the warranty period and coverage details.

For technical support, spare parts, or service inquiries, please visit the official Kenwood website or contact their customer service department. You can also find more information and support resources on the [Kenwood Brand Store on Amazon](#).