Manuals+

Q & A | Deep Search | Upload

Universal P25-0057-7615901

McCulloch Universal Trimmer Head P25 Instruction Manual

Model: P25-0057-7615901 | Brand: Universal

INTRODUCTION

This manual provides essential information for the safe and effective use of your McCulloch Universal Trimmer Head P25. This trimmer head is part of the Universal range of parts and accessories, powered by McCulloch, designed to work with McCulloch machines and most other brands of lightweight petrol grass trimmers. It includes a pre-loaded spool and line (SPO001) with a 2.0 mm diameter and 4 meters in length.

SAFETY INFORMATION

Always read and understand the safety instructions provided with your specific grass trimmer or brush cutter before installing or operating this trimmer head. Failure to follow all instructions may result in serious injury.

- Wear appropriate personal protective equipment (PPE), including eye protection, hearing protection, and sturdy footwear
- Ensure the trimmer is turned off and the spark plug cap is removed (for petrol models) before performing any installation, maintenance, or inspection.
- Keep bystanders, especially children and pets, at a safe distance from the work area.
- Inspect the trimmer head for any damage before each use. Do not use if damaged.
- · Use only genuine replacement parts and accessories recommended by the manufacturer.

PACKAGE CONTENTS

The McCulloch Universal Trimmer Head P25 package includes:

- 1 x Universal Trimmer Head P25
- 1 x Pre-loaded 2.0 mm x 4m Trimmer Line (SPO001)
- 5 x Different Adaptors (to fit most lightweight petrol grass trimmers)



Figure 1: The McCulloch Universal Trimmer Head P25 as supplied in its protective packaging.

SETUP AND INSTALLATION

The P25 trimmer head is designed for easy installation on a wide range of petrol grass trimmers. It comes with five different adaptors to ensure compatibility.

- 1. **Identify the correct adaptor:** Consult your trimmer's instruction manual to determine the correct mounting thread size and type for your specific model. Select the adaptor from the provided set that matches your trimmer's shaft.
- 2. Prepare the trimmer: Ensure the trimmer is turned off and cooled down. Disconnect the spark plug wire for safety.
- 3. **Remove existing head (if applicable):** If an old trimmer head is present, remove it according to your trimmer's manual.
- 4. Install the adaptor: Screw the selected adaptor onto the trimmer's drive shaft. Ensure it is securely tightened.
- 5. Attach the P25 trimmer head: Align the P25 trimmer head with the installed adaptor and screw it on until it is firmly seated. Do not overtighten.
- 6. Verify installation: Gently tug on the trimmer head to ensure it is securely attached and does not wobble.

Trimmer head Fits all petrol trimmer brands HD0001 - 2.0mm 2-Line Trimmer Head Spool







The perfect fit, every time.

Figure 2: The P25 trimmer head is supplied with multiple adaptors to ensure broad compatibility with various trimmer brands. It is also compatible with replacement spool SPO001.

The McCulloch Universal Trimmer Head P25 is designed for efficient cutting of short to medium length grass and light bushes.

- Starting the Trimmer: Follow your trimmer's manufacturer instructions for starting the engine.
- **Trimming Technique:** Hold the trimmer firmly with both hands. Use a sweeping motion to cut grass. Avoid hitting hard objects like rocks, fences, or concrete, as this can damage the line and the trimmer head.
- Line Advancement: The P25 features an automatic line advancement system. When the line wears down, simply tap the trimmer head lightly on the ground while the engine is running at operating speed. This will release a small amount of new line. The cutting blade on your trimmer's guard will automatically trim the line to the correct length.
- **Optimal Performance:** For best results, maintain a consistent engine speed and avoid overloading the trimmer head by trying to cut too much material at once.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your trimmer head.

- Cleaning: After each use, clean the trimmer head to remove grass clippings, dirt, and debris. Use a brush or cloth. Do not use harsh chemicals.
- Line Replacement: When the pre-loaded line is depleted, replace it with a new spool of 2.0 mm trimmer line, such as the McCulloch SPO001 replacement spool.
- . Replacing the Spool:
 - a. Ensure the trimmer is off and the spark plug wire is disconnected.
 - b. Locate the tabs or buttons on the side of the trimmer head. Press them in and pull the cap off.
 - c. Remove the empty spool.
 - d. Insert the new pre-wound spool, ensuring the line ends are threaded through the eyelets on the trimmer head casing.
 - e. Replace the cap, ensuring it clicks securely into place.
- Storage: Store the trimmer head in a clean, dry place, away from direct sunlight and extreme temperatures.



Figure 3: Exploded view illustrating the internal components of the trimmer head, including the spool and line, for easy replacement.

TROUBLESHOOTING

If you encounter issues with your trimmer head, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Line not advancing	Line tangled or fused inside spool; spool empty; incorrect tapping technique.	Remove cap and untangle line, or replace spool. Ensure engine is at operating speed when tapping.
Poor cutting performance	Line too short or worn; incorrect line type; cutting too much material at once.	Advance line or replace spool. Ensure line is 2.0 mm diameter. Reduce cutting load.
Trimmer head wobbles	Trimmer head not securely attached; incorrect adaptor used.	Ensure trimmer head is tightened correctly. Verify the correct adaptor is installed and secured.

If problems persist, consult your trimmer's instruction manual or contact the manufacturer's customer support.

SPECIFICATIONS

Feature	Detail
Model Number	P25-0057-7615901
Brand	Universal (Powered by McCulloch)
Line Diameter	2.0 mm
Line Length (pre-loaded)	4 meters
Compatible Spool	SPO001
Included Components	Trimmer Head P25, 2.0 mm x 4m Trimmer Line, 5 Adaptors
Product Dimensions	25 x 14 x 6.5 cm
Item Weight	398 g
Recommended Use	For cutting grass and light bushes in gardens

 $\hfill \odot$ 2024 Universal. All rights reserved.

For further assistance, please refer to your trimmer's specific user manual or contact the manufacturer.