

## Annie 03000

# Annie 03000 Hair Dryer Nozzle

Instruction Manual

## INTRODUCTION

Thank you for choosing the Annie 03000 Hair Dryer Nozzle. This accessory is designed to enhance your hair drying and styling experience by providing precise airflow and aiding in detangling, straightening, and smoothing hair. Please read this manual thoroughly before use to ensure proper operation and maintenance.

## SAFETY INFORMATION

Always observe the following safety precautions when using the Annie 03000 Hair Dryer Nozzle:

- Ensure the nozzle is securely attached to your hair dryer before turning on the appliance.
- Do not use the nozzle if it is damaged or cracked.
- Keep the nozzle clean and free from hair buildup to maintain optimal performance and prevent overheating.
- Avoid direct contact of the hot nozzle with skin or scalp.
- Store in a cool, dry place when not in use.

## PRODUCT OVERVIEW

The Annie 03000 Hair Dryer Nozzle is a comb-style attachment designed to fit most standard hair dryers. It features durable teeth for detangling and straightening, and a secure attachment mechanism to ensure stability during use.



**Image 1:** Front view of the Annie 03000 Hair Dryer Nozzle. This black, comb-style attachment features multiple long, slender teeth extending from a wider base. The base is designed to connect to a hair dryer and includes a visible screw mechanism on the side for secure attachment. The "Annie" brand name is subtly embossed on the front of the base.

## SETUP

---

Follow these steps to properly attach the Annie 03000 Hair Dryer Nozzle to your hair dryer:

1. Ensure your hair dryer is unplugged and cool to the touch.
2. Align the opening of the Annie 03000 nozzle with the barrel of your hair dryer.
3. Gently push the nozzle onto the hair dryer barrel until it fits snugly.
4. Tighten the screw on the side of the nozzle to secure it firmly in place. This mechanism helps ensure the nozzle remains attached during use.
5. Verify that the nozzle is stable and does not wobble before plugging in and operating your hair dryer.

## OPERATING INSTRUCTIONS

The Annie 03000 Hair Dryer Nozzle is designed for efficient styling and drying. Use it as follows:

- **For Detangling and Straightening:** While drying, slowly comb through sections of hair with the nozzle. The comb teeth will help detangle knots and straighten hair as you dry.
- **For Smoothing and Styling:** Direct the airflow through the nozzle along the hair shaft from roots to ends. This helps to smooth the cuticle and create a sleek finish.
- **For Fast Drying:** The concentrated airflow from the nozzle can help to dry hair more quickly, especially when used in conjunction with the combing action.

Always start with a lower heat setting and increase as needed. Avoid holding the nozzle in one spot for too long to prevent heat damage to hair.

## MAINTENANCE AND CARE

Proper care will extend the life of your Annie 03000 Hair Dryer Nozzle:

- **Cleaning:** After each use, allow the nozzle to cool completely. Remove any trapped hair from the comb teeth. You can use a soft brush or a damp cloth to wipe down the surface. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Detach the nozzle from your hair dryer when not in use. Store it in a clean, dry place away from direct sunlight and extreme temperatures. Its compact design makes it easy to store and travel with.

## TROUBLESHOOTING

If you encounter issues with your Annie 03000 Hair Dryer Nozzle, refer to the following table:

Problem	Possible Cause	Solution
Nozzle does not fit hair dryer.	Hair dryer barrel size is incompatible.	Ensure your hair dryer's barrel diameter is compatible with the nozzle's opening. The nozzle is designed to fit most standard hair dryers, but some variations may exist.
Nozzle comes loose or falls off during use.	Not securely attached; screw not tightened sufficiently.	Ensure the nozzle is pushed firmly onto the hair dryer barrel and the side screw is tightened completely. If the screw mechanism feels loose, inspect for damage.
Hair gets caught in the nozzle.	Using too large a section of hair; comb teeth are dirty.	Work with smaller sections of hair. Clean the comb teeth regularly to remove any accumulated hair or product residue.

## SPECIFICATIONS

Feature	Detail
Product Model	03000
Manufacturer	Annie
Product Dimensions	4 x 2 x 8 inches
Product Weight	2.4 ounces

Feature	Detail
UPC	705372030005

## WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Annie 03000 Hair Dryer Nozzle, please contact the manufacturer, Annie, directly. Refer to the product packaging or the official Annie website for contact information and details regarding any applicable warranty.