

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [iSound](#) /

> [iSound Twist Portable Bluetooth Wireless Speaker \(White\) User Manual](#)

iSound ISOUND-1691

iSound Twist Portable Bluetooth Wireless Speaker (White) User Manual

Model: ISOUND-1691

PRODUCT OVERVIEW

The iSound Twist Portable Bluetooth Wireless Speaker offers a unique design combined with superior sound quality. Its compact form factor allows for portability, while its advanced features enable wireless music streaming and hands-free calling. The speaker features full stereo sound with 6 watts total output from two 40mm drivers and a passive radiator for enhanced bass.



Image: The iSound Twist Portable Bluetooth Wireless Speaker in white, showcasing its unique twisted design.

PACKAGE CONTENTS

- iSound Twist Portable Bluetooth Wireless Speaker
- USB Charging Cable
- 3.5mm AUX Input Cable
- User Manual (this document)

SETUP

1. Charging the Speaker

Before initial use, fully charge the iSound Twist speaker. Connect the provided USB charging cable to the speaker's USB charging port and the other end to a powered USB source (e.g., computer, USB wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged. A full charge provides up to 5 hours of continuous play.




Image: Rear panel of the speaker, highlighting the USB charging port, ON/OFF switch, and AUX IN port.

2. Powering On/Off

Locate the ON/OFF switch on the rear panel of the speaker. Slide the switch to the "ON" position to power on the device. Slide it to the "OFF" position to power off.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and within close proximity to your Bluetooth-enabled device (e.g., smartphone, tablet, laptop).
2. The speaker will automatically enter Bluetooth pairing mode. A blue indicator light will flash, indicating it is discoverable.
3. On your device, navigate to the Bluetooth settings and enable Bluetooth.
4. Search for available devices. The iSound Twist speaker should appear in the list, typically named "iSound Twist" or similar.
5. Select the speaker from the list to initiate pairing. If prompted for a password, enter "0000".
6. Once successfully paired, the blue indicator light on the speaker will stop flashing and remain solid. You will hear an audible confirmation.
7. Your device is now connected, and you can stream audio wirelessly.

4. AUX Input Connection

For devices without Bluetooth capability, or if you prefer a wired connection, use the provided 3.5mm AUX cable.

1. Connect one end of the 3.5mm AUX cable to the AUX IN port on the rear of the speaker.
2. Connect the other end of the cable to the headphone jack or audio output port of your audio device.
3. The speaker will automatically switch to AUX input mode.

OPERATING INSTRUCTIONS

Control Panel Functions

The speaker features onboard controls located on its top surface for convenient operation.

- **Power/Mode Button:** Press and hold to power on/off. Short press to switch between Bluetooth and AUX modes.
- **Play/Pause/Call Button:** Short press to play or pause music. During an incoming call, short press to answer or end the call. Press and hold to reject an incoming call.

- **Volume Up/Next Track Button:** Short press to increase volume. Press and hold to skip to the next track.
- **Volume Down/Previous Track Button:** Short press to decrease volume. Press and hold to go to the previous track.

Hands-Free Calling

When connected via Bluetooth, the iSound Twist speaker's built-in microphone allows for hands-free phone calls.

- **Answering a Call:** When a call comes in, the music will pause. Press the Play/Pause/Call button once to answer.
- **Ending a Call:** During a call, press the Play/Pause/Call button once to end the call.
- **Rejecting a Call:** Press and hold the Play/Pause/Call button to reject an incoming call.

MAINTENANCE

- Keep the speaker away from water, moisture, and extreme temperatures.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid dropping or subjecting the speaker to strong impacts.
- When not in use for extended periods, store the speaker in a cool, dry place and charge it periodically to maintain battery health.

TROUBLESHOOTING

Problem	Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the USB cable and try again.
Cannot pair via Bluetooth.	<ul style="list-style-type: none"> ◦ Ensure the speaker is in pairing mode (flashing blue light). ◦ Make sure Bluetooth is enabled on your device. ◦ Move the speaker closer to your device. ◦ Turn off and on both the speaker and your device, then try pairing again. ◦ Clear previous Bluetooth connections on your device.
No sound or low volume.	<ul style="list-style-type: none"> ◦ Increase the volume on both the speaker and your connected device. ◦ Ensure the speaker is correctly paired via Bluetooth or the AUX cable is fully inserted. ◦ Check if the correct input mode (Bluetooth or AUX) is selected.
Call quality is poor.	<ul style="list-style-type: none"> ◦ Ensure you are within Bluetooth range of your device. ◦ Reduce background noise. ◦ Speak clearly towards the speaker's microphone.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Name	ISOUND-1691
Brand	iSound
Speaker Type	Tower
Special Feature	Built In Microphone
Recommended Uses	For Smartphones or Tablets, Music Players
Compatible Devices	Desktop, Laptop, MP3 Player, Projector, Smartphone, Tablet, Television
Surround Sound Channel Configuration	2.0
Color	White
Item Weight	13.6 ounces
Is Waterproof	FALSE
Wireless Communication Technology	Bluetooth
Speaker Size	0.75 Inches
Power Source	Battery Powered
Number of Batteries	1 Lithium Ion batteries required. (included)
Audio Driver Type	Dynamic Driver
Audio Driver Size	40 Millimeters
Product Dimensions	5 x 4 x 11.75 inches
Speaker Maximum Output Power	6 Watts
Connectivity Technology	Wireless
Audio Output Mode	Stereo
Mounting Type	Tabletop Mount

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: Official product video for the iSound Twist Bluetooth Speaker, demonstrating its features and design. This video showcases the speaker's ability to stream audio from various devices and handle calls.

WARRANTY AND SUPPORT

The iSound Twist Portable Bluetooth Wireless Speaker comes with a **Limited Warranty**. For specific warranty terms, conditions, and support inquiries, please refer to the warranty card included in your product packaging or visit the official iSound website.

For further assistance, please contact iSound customer support.

