

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [LEGO](#) /

› [LEGO Hulk Helicarrier Breakout 6868 Instruction Manual](#)

LEGO 6868

LEGO Hulk Helicarrier Breakout 6868 Instruction Manual

Model Number: 6868

1. INTRODUCTION

Welcome to the instruction manual for your LEGO Hulk Helicarrier Breakout set. This manual provides detailed guidance for assembling and interacting with your new LEGO model. Please read all instructions carefully before beginning assembly.

This set is designed for builders aged 6 years and up, offering an engaging and creative building experience.

2. SAFETY INFORMATION

- **Choking Hazard:** This set contains small parts and is not suitable for children under 3 years of age.
- Always supervise young children during assembly and play.
- Keep all packaging materials away from children to prevent suffocation risks.

3. PACKAGE CONTENTS

Your LEGO Hulk Helicarrier Breakout set includes all the necessary bricks and minifigures to construct the Helicarrier section and the jet fighter. Please verify that all components are present before starting assembly.

- Hulk minifigure
- Thor minifigure
- Hawkeye minifigure
- Loki minifigure
- Helicarrier section components
- Jet fighter components

- Accessories: 2 canisters, Loki's staff, Hawkeye's bow and arrow, Thor's hammer



Image 3.1: The complete LEGO Hulk Helicarrier Breakout set, featuring the Helicarrier module, jet fighter, and minifigures including Hulk, Thor, Hawkeye, and Loki.

4. ASSEMBLY INSTRUCTIONS

Follow the step-by-step instructions provided in the included LEGO building guide. Ensure all pieces are securely connected to maintain the structural integrity of the model.

4.1. Helicarrier Section Assembly

Begin by assembling the base of the Helicarrier section. This module features a containment cell designed with an exploding function and a fuel canister holder with a firing mechanism. Pay close attention to the mechanisms for these interactive features during construction.

4.2. Jet Fighter Assembly

Next, construct the jet fighter. This vehicle is equipped with four flick missiles and an opening cockpit. The cockpit also includes a blast function for dynamic play. Ensure the flick missile launchers are correctly oriented for proper operation.



Image 4.2.1: A detailed view of the assembled jet fighter from the LEGO Hulk Helicarrier Breakout set, showcasing its sleek design and missile launchers.

4.3. Minifigure Assembly

Assemble the four included minifigures: Hulk, Thor, Hawkeye, and Loki. Attach their respective accessories as shown in the building guide. The Hulk figure is larger and assembled from several specialized pieces.

5. OPERATING INSTRUCTIONS

5.1. Helicarrier Functions

- Exploding Containment Cell:** To activate the exploding function, apply pressure to the designated trigger mechanism on the side of the cell. This will cause the cell walls to detach, simulating a breakout.
- Fuel Canister Holder:** Place the included canisters into the holder. The firing function is activated by pressing the lever or button located near the holder, launching the canisters.

5.2. Jet Fighter Functions

- Flick Missiles:** Load the four flick missiles into their launchers on the jet fighter's wings. To fire, use your finger to 'flick' the rear of the missile.
- Opening Cockpit:** The cockpit canopy can be opened to place a minifigure inside.
- Cockpit Blast Function:** A mechanism allows the cockpit to 'blast' open, simulating an ejection or rapid exit. Activate by pressing the designated button or lever.

6. MAINTENANCE

- Cleaning:** To clean your LEGO bricks, use a mild soap solution and lukewarm water. Rinse thoroughly and air dry. Avoid hot water or harsh chemicals, as these can damage the plastic.
- Storage:** Store your LEGO set in a clean, dry place away from direct sunlight and extreme temperatures to prevent discoloration and warping.
- Disassembly:** If disassembling the set, keep all small parts together to prevent loss.

7. TROUBLESHOOTING

- Missing Parts:** If you find any parts missing, please refer to the LEGO customer service section for assistance.
- Loose Connections:** Ensure all bricks are firmly pressed together. Sometimes, a loose connection can cause instability in the model.
- Functionality Issues:** If an interactive function (e.g., exploding cell, flick missiles) is not working, re-check the assembly steps for that specific mechanism in the building guide.

8. SPECIFICATIONS

Attribute	Detail
Product Name	LEGO Hulk Helicarrier Breakout

Model Number	6868
Item Model Number (Internal)	4654657
Product Dimensions	18.9 x 2.4 x 11.1 inches
Item Weight	1.85 pounds
Recommended Age	6 years and up
Release Date	May 1, 2012
Manufacturer	LEGO Superheroes

9. WARRANTY AND SUPPORT

LEGO products are manufactured to high-quality standards. If you encounter any issues with your set, such as missing or defective parts, please contact LEGO Customer Service.

For detailed warranty information and customer support, please visit the official LEGO website or contact their support team directly. You can typically find support contact information on the LEGO packaging or their official website: www.lego.com/service