

## Acctim 14287

# Acctim Bedside Alarm Clock User Manual

Model: 14287 | Brand: Acctim

## 1. INTRODUCTION

Thank you for choosing the Acctim Bedside Alarm Clock. This manual provides essential information for the proper setup, operation, and maintenance of your new clock. Please read it thoroughly before use and retain it for future reference.

This Acctim clock combines functionality with style, featuring Smartlite technology for automatic dial illumination, a silent sweep seconds hand, and a crescendo alarm with snooze. It is designed to complement your home and office environment.

## 2. IMPORTANT SAFETY INFORMATION

- Do not expose the clock to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping the clock or subjecting it to strong impacts.
- Do not attempt to disassemble or repair the clock yourself. Refer all servicing to qualified personnel.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.
- Dispose of used batteries responsibly according to local regulations.
- Use only the specified battery type (3 x AA batteries, not included).

## 3. PACKAGE CONTENTS

- 1 x Acctim Bedside Alarm Clock (Model 14287)

## 4. PRODUCT OVERVIEW

Familiarize yourself with the components of your Acctim Bedside Alarm Clock.



Figure 4.1: Front view of the Acctim Bedside Alarm Clock, showing the silver casing, white analog dial with black numbers, and hands.



Figure 4.2: Rear view of the Acctim Bedside Alarm Clock, displaying the battery compartment, time setting knob, alarm setting knob, and Smartlite/Everglow controls.

## Key Features:

- **Smartlite Technology:** Automatically illuminates the dial for easy night time viewing.
- **Silent Non-Ticking Sweep Seconds Hand:** Ensures quiet operation.
- **Everglow Adjustable Brightness:** Allows customization of the dial illumination intensity.
- **Crescendo Alarm with Snooze and Backlight:** Gradually increasing alarm sound with a temporary silence option.
- **Compact Dimensions:** 120 x 113 x 75mm, ideal for bedside tables.

## 5. SETUP

## 5.1 Battery Installation

The clock requires 3 x AA batteries (not included).

1. Locate the battery compartment cover on the back of the clock (refer to Figure 4.2).
2. Slide the cover downwards to open.
3. Insert 3 new AA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover, sliding it upwards until it clicks securely into place.

## 5.2 Setting the Time

1. Locate the 'TIME SET' knob on the back of the clock (usually the right-hand knob when facing the back, refer to Figure 4.2).
2. Rotate the 'TIME SET' knob clockwise or counter-clockwise until the hour and minute hands display the correct current time.

# 6. OPERATING INSTRUCTIONS

---

## 6.1 Setting the Alarm

1. Locate the 'ALARM SET' knob on the back of the clock (usually the left-hand knob when facing the back, refer to Figure 4.2).
2. Rotate the 'ALARM SET' knob to move the alarm hand to your desired alarm time.
3. To activate the alarm, slide the 'ALARM ON/OFF' switch (located on the side or back) to the 'ON' position.
4. The alarm will sound at the set time with a crescendo (gradually increasing) volume.

## 6.2 Snooze Function and Backlight



Figure 6.1: Close-up view of the top of the clock, showing the large 'SNOOZE-LIGHT' button and the 'BRITE-DIM' Everglow switch.

When the alarm sounds, press the large 'SNOOZE-LIGHT' button located on the top of the clock (refer to Figure 6.1). This will temporarily silence the alarm for approximately 5 minutes. The alarm will sound again after the snooze period. Pressing this button also activates the backlight for a few seconds for easy viewing in the dark.

### 6.3 Smartlite Technology



Figure 6.2: The Acctim clock alongside its packaging, with an overlay illustrating the Smartlite feature illuminating the dial in low light conditions.

The Acctim Bedside Alarm Clock features Smartlite technology. This innovative function automatically illuminates the clock's dial in low-light conditions, making it easy to read the time at night without needing to press any buttons. The illumination level adjusts based on ambient light.

#### 6.4 Everglow Adjustable Brightness

The Everglow feature allows you to adjust the brightness of the Smartlite illumination. Locate the 'BRITE-DIM' switch or slider on the back or top of the clock (refer to Figure 6.1). Move the switch to your preferred brightness level to customize the night-time visibility of the dial.

### 7. MAINTENANCE

- Clean the clock with a soft, dry cloth. Do not use abrasive cleaners or chemical solvents.
- If the clock will not be used for an extended period, remove the batteries to prevent leakage.
- Ensure the clock is placed on a stable, flat surface to prevent accidental falls.

### 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not working / Display blank	Batteries are dead or incorrectly inserted.	Replace with new AA batteries, ensuring correct polarity.
Alarm does not sound	Alarm is not activated or set incorrectly.	Ensure 'ALARM ON/OFF' switch is in 'ON' position. Verify alarm time is set correctly.

Problem	Possible Cause	Solution
Smartlite not illuminating	Ambient light is too bright or Everglow setting is too dim.	Move the clock to a darker environment. Adjust the 'BRITE-DIM' Everglow switch to a brighter setting.
Snooze/Backlight button not working	Batteries are low.	Replace batteries.

## 9. SPECIFICATIONS




Figure 9.1: Diagram illustrating the dimensions of the Acctim Bedside Alarm Clock: 12 cm width, 11.3 cm height, and 7.5 cm depth.

Feature	Detail
Brand	Acctim
Model Number	14287
Color	Silver
Display Type	Analog
Dimensions (W x H x D)	12 x 11.3 x 7.5 cm (4.72"W x 4.33"H)
Power Source	Battery Powered (3 x AA batteries required, not included)
Special Features	Adjustable Brightness, Alarm, Illuminated, Silent Clock, Snooze
Material	Plastic, Metal Frame
Item Weight	0.21 Kilograms (7.4 ounces)

## 10. WARRANTY AND SUPPORT

This Acctim Bedside Alarm Clock is backed by a 1-year guarantee from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For warranty claims, technical support, or any inquiries regarding your product, please refer to the retailer where the product was purchased or visit the official Acctim website for contact information. Please have your model number (14287) and proof of purchase ready when contacting support.

© 2023 Acctim. All rights reserved.