

Casio DBC-611-1DF

Casio DBC-611-1DF Men's Silver Tone 25 Memory Calculator Databank Watch Instruction Manual

Model: DBC-611-1DF

INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your Casio DBC-611-1DF Men's Silver Tone 25 Memory Calculator Databank Watch. Please read this manual thoroughly to ensure proper use and to fully utilize all features of your watch.



Front view of the Casio DBC-611-1DF Databank Watch, displaying the digital time and calculator keypad.

SETUP

Setting the Time and Date

1. In Timekeeping Mode, press the **ADJUST** button (top left) until the seconds start to flash. This indicates the setting mode.
2. Press the **MODE** button (bottom left) to cycle through the settings: seconds, hour, minutes, year, month, day.
3. Use the numeric keypad (calculator buttons) to input the correct values for each setting. For example,

to set the hour, press the corresponding number on the keypad.

4. To switch between 12-hour and 24-hour format, press the **PM** button (bottom left of keypad) while the hour setting is flashing.
5. Once all settings are adjusted, press the **ADJUST** button again to exit the setting mode.

Adjusting the Band

The watch features an adjustable metal band. To adjust the length, locate the clasp and use a small flathead tool to lift the locking tab. Slide the clasp along the band to the desired position, then press the tab down firmly to secure it. Ensure the clasp is securely fastened before wearing.



Rear view of the watch, showing the adjustable metal clasp for band sizing.

OPERATING INSTRUCTIONS

Mode Navigation

Press the **MODE** button (bottom left) to cycle through the different modes:

- **Timekeeping Mode:** Displays current time, date, and day of the week.
- **Telememo Mode:** Stores up to 25 sets of name and telephone number data.

- **Calculator Mode:** Performs basic arithmetic calculations.
- **Stopwatch Mode:** Measures elapsed time, split times, and 1st-2nd place times.
- **Dual Time Mode:** Displays the current time in a different time zone.
- **Alarm Mode:** Sets up to 5 daily alarms and an hourly time signal.

Using the Calculator

In Calculator Mode, use the numeric keypad to input numbers and perform operations. The display supports 8 digits. Press the **AC** button (top right of keypad) to clear the current entry.

Telememo Function

To enter or recall data in Telememo Mode:

1. Navigate to Telememo Mode.
2. Press the **ADJUST** button to enter data input mode.
3. Use the numeric keypad to enter numbers. Use the **SPACE** button for spaces.
4. Press **ADJUST** to save the entry.
5. Use the **TEL/FWD** and **REV/TIME** buttons to scroll through stored entries.

Stopwatch Function

In Stopwatch Mode:

- Press **START/STOP** (bottom right of keypad) to start and stop the stopwatch.
- Press **LAP/RESET** (bottom left of keypad) to record lap times or reset the stopwatch when stopped.

Alarms and Hourly Time Signal

In Alarm Mode:

- Use the **MODE** button to select one of the 5 alarms or the hourly time signal.
- Press **ADJUST** to set the alarm time. Use the numeric keypad to input the hour and minutes.
- Press **ALM ON/OFF** (top left of keypad) to toggle the selected alarm on or off.
- Press **SIG ON/OFF** (middle right of keypad) to toggle the hourly time signal on or off.

Auto LED Light

The watch features an Auto LED light. This function automatically illuminates the display when the watch is tilted towards your face in a dark environment. To activate or deactivate this feature, refer to the detailed instructions in the full module manual (Module No. 437, 438, 3208).



Angled view of the Casio Databank Watch, highlighting the display and keypad.

MAINTENANCE

General Care

- Clean the watch regularly with a soft, dry cloth.
- Avoid exposing the watch to extreme temperatures, direct sunlight for prolonged periods, or strong magnetic fields.
- While the watch is water-resistant, avoid direct contact with water to prolong its lifespan, especially for the calculator buttons.

Battery Replacement

The watch uses 1 CR123A battery. Battery life is approximately 5 years. When the display becomes dim or functions become erratic, it is time to replace the battery. Battery replacement should ideally be performed by a qualified technician to ensure water resistance is maintained.

TROUBLESHOOTING

- **Display is blank or dim:** Check the battery. If recently replaced, ensure it is installed correctly.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, refer to full manual). If the issue persists, a reset may be required (consult a technician).
- **Time is inaccurate:** Re-set the time and date as per the "Setting the Time and Date" section.

SPECIFICATIONS

Brand	Casio
-------	-------

Model Number	DBC-611-1DF
Product Dimensions	2.44 x 4.09 x 3.62 inches
Item Weight	1.69 ounces
Battery Type	1 CR123A (included)
Special Features	25 pages of Telememo, 1/100-second stopwatch, Dual time, 5 alarms, Auto LED light
Water Resistance	Water Resistant (general daily use, not for swimming or diving)
Date First Available	March 22, 2012

OFFICIAL PRODUCT VIDEO






Official product video showcasing the features and design of the Casio Databank Watch.




WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Casio website. The module number for this watch is 437, 438, or 3208, which can be used to find specific support documents online.

For additional assistance, you may contact Casio customer service directly.

Related Documents - DBC-611-1DF

	<p>Casio DBC-30/30G/300A/300GA Watch User Manual (Module 1253)</p> <p>User manual for Casio DBC-30, DBC-30G, DBC-300A, and DBC-300GA watches (Module 1253). Details features like timekeeping, phonebook, calculator, alarms, stopwatch, water resistance, and watch care.</p>
	<p>Casio 3228 Operation Guide - Digital Watch Manual</p> <p>Comprehensive operation guide for the Casio 3228 digital watch, covering timekeeping, data bank, calculator, alarms, stopwatch, dual time, and illumination features. Includes instructions, specifications, and reference information.</p>
	<p>Casio DBC-32 Module 2888 Watch User Manual</p> <p>User manual for the Casio DBC-32 watch (Module 2888), providing detailed instructions on time setting, alarms, stopwatch, calculator, phonebook, water resistance, and technical specifications.</p>

	<p>Руководство пользователя часов CASIO Модуль 676</p> <p>Подробное руководство пользователя для часов CASIO Модуль 676, охватывающее функции Мирового времени, Таймера, Секундомера, Телефонной книги, Расписания и Калькулятора. Включает инструкции по установке времени, будильников и использованию различных функций.</p>
	<p>CASIO CMD-40/CMD-40G Watch User Manual (Module 1174) - Remote Control & Functions</p> <p>Comprehensive user manual for CASIO CMD-40 and CMD-40G digital watches (Module 1174), detailing remote control functions for TVs and VCRs, calculator, alarm, and stopwatch modes. Includes instructions for setting time, date, and learning remote signals.</p>
	<p>Casio LAW-21 Модуль 2789: Руководство пользователя и характеристики</p> <p>Полное руководство пользователя для часов Casio LAW-21 (Модуль 2789). Содержит инструкции по эксплуатации, уходу, описания режимов работы (текущее время, мировое время, таймер, секундомер, будильник) и технические характеристики.</p>