

BRIO 33052

BRIO World Deluxe Railway Set

Model: 33052

Brand: BRIO

INTRODUCTION

The BRIO World Deluxe Railway Set offers an expansive and imaginative play experience for children aged 3 and up. This 87-piece wooden train set includes passenger and freight trains, captivating harbor and metro scenes, and various stations, designed to inspire creativity and foster learning through exploration. It provides a secure and inviting environment for children to develop essential skills such as spatial awareness and fine motor development, while carrying on a cherished childhood tradition.



Classic Tracks, Creative Minds

Bring the nostalgia of traditional wooden railway toys to life while boosting motor skills, creativity, & imagination.

Image: Children engaging with the BRIO World Deluxe Railway Set, demonstrating interactive play.

SAFETY INFORMATION

WARNING: Small parts. Not for children under 3 years.

All BRIO products undergo rigorous safety testing to ensure they meet and exceed safety standards, providing peace of mind during playtime.

WHAT'S IN THE BOX

The BRIO World Deluxe Railway Set is an 87-piece collection designed for comprehensive railway play. The set includes:

- Wooden Railway Pieces (87 total)
- Passenger Trains
- Freight Trains
- Stations (including a 2-story station with mechanical lift)
- Harbor and Metro Scene elements
- Tunnels (including a bright red tunnel)
- Bridges (three special train trestle bridges)

- Mechanical, magnetic crane
- Cargo trucks and a container ship
- Various accessories and figurines
- Special storage box that converts into a playmat

Play, Create, & Explore!



With 87 pieces, this set has it all — bridges, tunnels, stations, and a fleet of trains. All aboard for this deluxe railway adventure!

87 pieces

3+ years old

Image: A comprehensive layout of all components included in the 87-piece set.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all 87 pieces from the packaging. The storage box can be unfolded to serve as a playmat, providing a designated play area.
2. **Assemble Tracks:** Connect the wooden track pieces to form your desired railway layout. The pieces are designed for easy connection, allowing for various configurations. Refer to the included diagrams for suggested layouts or create your own unique railway world.
3. **Position Structures:** Place the stations, tunnels, bridges, and other scene elements onto the track layout. Ensure bridges and elevated sections are stable.
4. **Prepare Trains:** For the battery-powered light and sound engine, ensure 2 LR44 batteries are installed (included). This engine activates lights and sounds when pushed.
5. **Arrange Accessories:** Place figurines, cargo, trucks, and the container ship around the railway to enhance the play experience.



Image: The assembled railway set, demonstrating a possible layout.


OPERATING THE RAILWAY SET

- **Driving Trains:** Manually push the trains along the wooden tracks. The battery-powered engine will activate lights and sounds when pushed, with intensity increasing with speed.
- **Passenger Operations:** Use the 2-story station with its mechanical lift to transport passengers between levels. The Metro city train features sliding doors for passengers to embark and disembark.
- **Cargo Handling:** Utilize the mechanical, magnetic crane at the shipping port to load and unload cargo from the container ship onto the cargo train or trucks. The set includes various cargo pieces for interactive play.
- **Navigating the Course:** Drive trains through the red tunnel and over the three special train trestle bridges. Cargo trucks can be driven on and off special road sections, including a track crossing with working safety gates.
- **Expanding the World:** This set is fully compatible with other BRIO railway toys, allowing for expansion of tracks, stations, and accessories as your child's imagination grows.

Bright Tracks, Bold Adventures!



Battery-powered lights & sound
Press the engine to activate the train's lights & sounds.



Switching station
Help passengers switch trains at the switching station.



Life & load cargo
Use the crane to move cargo between transports.



Sliding train doors
Transport passengers from one destination to the next.

Image: Detailed features of the set, including interactive elements.



Expand The Fun As They Grow

This set is fully compatible with other BRIO railway toys, so you can expand the tracks, stations, and more!

Image: An expansive railway setup showcasing various components and compatibility.

MAINTENANCE

- **Cleaning:** The wooden components are made from solid Beech wood with a water-based lacquer finish. Wipe surfaces with a damp cloth to clean. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, the set can be stored in its special storage box, which also functions as a playmat. This helps keep all pieces organized and protected.
- **Durability:** BRIO toys are crafted for lasting value. The meticulous painting with 6 coats of water-based lacquer ensures a chip-resistant, vibrant finish.
- **Battery Replacement:** For the battery-powered engine, replace 2 LR44 batteries as needed. Ensure correct polarity when inserting new batteries.



Crafted to Last a Lifetime

Made from FSC® certified beech wood, this train set is built to last for generations of play & makes a timeless gift.

Image: Illustrating the quality and finish of the wooden components.

TROUBLESHOOTING

- **Trains Derailing:** Ensure all track pieces are securely connected and laid on a flat, stable surface. Check for any debris on the tracks or wheels that might impede smooth movement. If using elevated sections, ensure supports are properly placed to prevent track separation.
- **Battery-Powered Train Not Working:** Verify that the 2 LR44 batteries are correctly installed and not depleted. Replace batteries if necessary. Ensure the train is pushed with sufficient force to activate the light and sound features.
- **Magnetic Connections Not Holding:** Check for any obstructions between the magnetic connectors of the train cars. Ensure the magnets are clean and free from dust or small particles.
- **Mechanical Crane Malfunction:** Inspect the crane for any obstructions or misalignments. Ensure all moving parts are free to rotate and lift.

SPECIFICATIONS

Product Dimensions	44.49 x 28.74 x 0.01 inches

Item Weight	14.52 pounds
Model Number	33052
Manufacturer Recommended Age	36 months - 10 years
Batteries Required	2 LR44 batteries (included)
Material	FSC-Certified Beech Wood
Release Date	September 3, 2012
Manufacturer	Brio





WARRANTY AND SUPPORT



For information regarding product warranty, replacement parts, or additional support, please visit the official BRIO website or contact their customer service department. BRIO is committed to providing high-quality toys and excellent customer satisfaction.

You can find more information and contact details on the [BRIO Store on Amazon](#).

© 2024 BRIO. All rights reserved.

Related Documents - 33052

	<p>BRIO World Remote Control Travel Train Troubleshooting Guide</p> <p>Provides essential troubleshooting steps for the BRIO World Remote Control Travel Train, helping users resolve issues related to infrared control, channel synchronization, remote operation, and battery performance.</p>
	<p>BRIO Lift & Load Warehouse Set 33887 Assembly Instructions</p> <p>Detailed assembly instructions and layout suggestions for the BRIO Lift & Load Warehouse Set 33887, a wooden toy train accessory from BRIO.</p>
	<p>BRIO Battery-Operated Steaming Train - User Manual and Instructions</p> <p>Comprehensive guide for the BRIO Battery-Operated Steaming Train (model 33884). Learn how to install batteries, operate the train, generate steam, and understand safety precautions. Includes tips for optimal play and maintenance.</p>
	<p>BRIO Builder Motor Set 34591: Inspiration and Assembly Guide</p> <p>Explore the BRIO Builder Motor Set 34591 with this inspiration booklet. Learn how to assemble various models using the included parts and motor unit, with instructions and safety information.</p>

 <p>BRIO Rote Lola 33592</p> <p>BRIO Rote Lola 33592 ist ein Spielzeuglokomotiv aus Kunststoff, das in der BRIO-Serie hergestellt wird. Es ist eine rote Lokomotive mit einem schwarzen Rauchrohr und einem schwarzen Kamin. Die Lokomotive ist mit einem schwarzen Schieber und einem schwarzen Schieberhebel ausgestattet. Die Lokomotive ist mit einem schwarzen Schieber und einem schwarzen Schieberhebel ausgestattet. Die Lokomotive ist mit einem schwarzen Schieber und einem schwarzen Schieberhebel ausgestattet.</p>	<p>BRIO Rote Lola 33592: Questions and Answers</p> <p>Find answers to common questions about the BRIO Rote Lola 33592 toy train, including operation, troubleshooting, and battery replacement. This guide provides information on how to use, maintain, and resolve issues with the toy.</p>
 <p>BRIO Battery Metro Engine</p> <p>BRIO Battery Metro Engine ist ein Spielzeuglokomotiv aus Kunststoff, das in der BRIO-Serie hergestellt wird. Es ist eine rote Lokomotive mit einem schwarzen Rauchrohr und einem schwarzen Kamin. Die Lokomotive ist mit einem schwarzen Schieber und einem schwarzen Schieberhebel ausgestattet. Die Lokomotive ist mit einem schwarzen Schieber und einem schwarzen Schieberhebel ausgestattet.</p>	<p>BRIO Battery Metro Engine: Features, Operation & Safety Guide</p> <p>Comprehensive guide to the BRIO Battery Metro Engine, covering its features, how to operate it, battery replacement, and essential safety warnings.</p>