

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Severin](#) /

› [Severin Descaling Tablets User Manual](#)

### Severin 8697

## Severin Descaling Tablets User Manual

Model: 8697

### INTRODUCTION

This manual provides essential information for the proper use and maintenance of Severin Descaling Tablets. These tablets are specifically formulated to remove limescale buildup in coffee machines, ensuring optimal performance and extending the lifespan of your appliance.

### PRODUCT OVERVIEW



The image displays the packaging for Severin 9-piece descaling tablets. The black box features the "SEVERIN" logo prominently at the top. Below the logo, a stylized illustration of a coffee machine component is visible. The number "9" is clearly displayed on the left side, indicating the quantity of tablets. Below the number, a list of languages translates "Descaling tablets," including English, German, French, Dutch, Swedish, Spanish, Italian, and Polish.

Key features of Severin Descaling Tablets include:

- Designed for use with Severin S2 and S3 fully automatic coffee machines.
- Supplied in a convenient 9-piece blister pack.

- Effectively protects your coffee machine against calcification.
- Contributes to increasing the longevity of your appliance.
- Formulated for use in accordance with your machine's descaling program.

## SETUP

---

Before initiating the descaling process, ensure your coffee machine is turned off and cooled down. Refer to your specific coffee machine's user manual for any preliminary steps required before descaling, such as emptying water tanks or removing filters.

## OPERATING INSTRUCTIONS

---

Always follow the descaling program instructions provided in your coffee machine's specific user manual. The following steps are general guidelines for using Severin Descaling Tablets:

1. **Preparation:** Empty the water tank of your coffee machine.
2. **Dissolve Tablets:** Dissolve the recommended number of Severin descaling tablets (typically one or more, as per your machine's manual) in a sufficient amount of lukewarm water in a separate container. Stir until fully dissolved.
3. **Fill Tank:** Pour the dissolved descaling solution into the water tank of your coffee machine.
4. **Start Descaling Program:** Activate the descaling program on your coffee machine. The machine will guide you through the process, which usually involves running the solution through the system.
5. **Rinsing:** After the descaling program is complete, thoroughly rinse the water tank and run several cycles of clean water through the machine to remove any residual descaling solution. This is crucial to ensure no taste residue remains.
6. **Final Check:** Refill the water tank with fresh water and your machine is ready for use.

*Note: The frequency of descaling depends on the hardness of your water and the frequency of machine use. Regular descaling is vital for optimal machine performance.*

## MAINTENANCE

---

Store Severin Descaling Tablets in their original packaging in a cool, dry place, away from direct sunlight and out of reach of children and pets. Do not expose tablets to moisture before use. Ensure the coffee machine is regularly descaled as per the manufacturer's recommendations to prevent severe limescale buildup, which can be harder to remove and potentially damage the appliance.

## TROUBLESHOOTING

---

If your coffee machine continues to show signs of limescale buildup or performance issues after descaling, consider the following:

- **Incomplete Descaling:** Ensure the entire descaling program of your machine was completed without interruption.
- **Water Hardness:** In areas with very hard water, more frequent descaling or a higher concentration of descaling solution (if permitted by your machine's manual) might be necessary.
- **Machine Malfunction:** If descaling does not resolve the issue, the problem might be mechanical and require professional servicing.
- **Incorrect Usage:** Verify that the correct number of tablets and proper dilution were used as per your

machine's instructions.

## SPECIFICATIONS

<b>Brand</b>	Severin
<b>Model Number</b>	8697
<b>Product Dimensions</b>	0.99 x 0.99 x 0.99 cm
<b>Product Weight</b>	220 g
<b>Material</b>	Plastic (packaging), Descaling Agent (tablets)
<b>Special Feature</b>	Descaler
<b>Product Form</b>	Tablet
<b>Fragrance</b>	Unscented
<b>Specific Uses</b>	Coffee Machine
<b>Number of Units</b>	9.0 units
<b>Surface Recommendation</b>	Metal (internal components of coffee machine)
<b>Contains Liquids</b>	Yes (when dissolved)
<b>Global Trade Item Number (GTIN)</b>	04008146869709

## SAFETY INFORMATION

**Warning:** Keep out of reach of children. Avoid contact with eyes and skin. In case of contact, rinse immediately with plenty of water and seek medical advice. Do not ingest. If swallowed, seek medical advice immediately and show this container or label. Use in a well-ventilated area. Always follow the instructions of your coffee machine manufacturer regarding descaling procedures.

## WARRANTY AND SUPPORT

For product support or warranty inquiries regarding Severin Descaling Tablets, please refer to the contact information provided on the product packaging or visit the official Severin website. This product is designed to support the proper functioning of your Severin coffee machine when used as directed.