

[Manuals.plus /](#)

[Braun /](#)

[Braun BNC010 Digital Alarm Clock Radio User Manual](#)

Braun BNC010

Braun BNC010 Digital Alarm Clock Radio User Manual

Model: BNC010

INTRODUCTION

Thank you for purchasing the Braun BNC010 Digital Alarm Clock Radio. This manual provides detailed instructions for setting up, operating, and maintaining your new device. Please read this manual thoroughly before use to ensure proper function and longevity of your product.



Image: The Braun BNC010 Digital Alarm Clock Radio, showcasing its sleek white design, large digital display, and integrated speaker grille.

SAFETY INFORMATION

- Do not expose the device to water or excessive moisture.
- Avoid placing the device near heat sources or in direct sunlight.
- Use only the specified power adapter (if applicable) and batteries.
- Do not attempt to disassemble or repair the device yourself. Refer to qualified service personnel.
- Keep out of reach of children.

PACKAGE CONTENTS

Please check that all items are present in the package:

- Braun BNC010 Digital Alarm Clock Radio
- Batteries (pre-installed or separate)
- User Manual
- Optional AC Power Adapter (may be sold separately or included depending on region/bundle)

PRODUCT OVERVIEW

Familiarize yourself with the various parts of your Braun BNC010.




Image: Front view of the Braun BNC010, highlighting the digital display, speaker grille, and side-mounted control buttons for time and alarm settings.

Key Features:

- FM/AM Radio with 6 station presets
- Digital Tuner for precise station selection
- Easy-to-read display with backlight
- Snooze function
- Volume control
- Battery operated with optional AC adapter support
- Compact dimensions: 180 mm x 90 mm x 49 mm

SETUP

1. Powering the Device

The Braun BNC010 can be powered by batteries or an optional AC adapter.

Battery Installation:

1. Locate the battery compartment on the underside of the unit.
2. Open the battery compartment cover.
3. Insert the required batteries (usually AA or AAA, check compartment for type) ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

AC Adapter Connection (Optional):

1. If using an AC adapter, plug the adapter into the DC input jack on the back of the unit.
2. Plug the other end of the adapter into a standard wall outlet.

2. Initial Time Setting

The BNC010 features worldwide radio-controlled time for automatic synchronization.

1. Upon first power-on, the clock will attempt to synchronize with the atomic clock signal. This may take a few minutes.
2. Ensure the device is placed in an area with good signal reception, away from large metal objects or other electronic devices that may cause interference.
3. If manual setting is required (e.g., in areas with no signal), refer to the "Operating" section for time adjustment instructions.

OPERATING

Setting the Time Manually:

1. Press and hold the **TIME** button (usually located on the side or back) until the time display flashes.
2. Use the **+** and **-** buttons to adjust the hours.
3. Press the **TIME** button again to move to minutes, then use **+** and **-** to adjust.
4. Press **TIME** once more to confirm and exit time setting mode.

Setting the Alarm:

1. Press and hold the **ALARM** button until the alarm time display flashes.
2. Use the **+** and **-** buttons to adjust the alarm hours.
3. Press the **ALARM** button again to move to alarm minutes, then use **+** and **-** to adjust.
4. Press **ALARM** once more to confirm.
5. To activate/deactivate the alarm, briefly press the **ALARM** button. An alarm icon will appear/disappear on the display.

Using the Snooze Function:

When the alarm sounds, press the large **SNOOZE** button (usually on top of the unit) to temporarily silence the alarm. The alarm will sound again after a few minutes (default snooze time is typically 5-9 minutes).

Radio Operation:

Tuning the Radio:

1. Press the **RADIO ON/OFF** button to turn on the radio.
2. Use the **TUNING +** and **TUNING -** buttons to manually tune to your desired FM or AM frequency.
3. For automatic scanning, press and hold the **TUNING +** or **TUNING -** button.

Setting Station Presets:

The BNC010 features 6 station preset buttons.

1. Tune to the desired radio station.
2. Press and hold one of the preset buttons (M1-M6) until you hear a beep or see a confirmation on the display. The station is now saved to that preset.
3. To recall a preset station, simply press the corresponding preset button briefly.

Adjusting Volume:

Use the **VOLUME +** and **VOLUME -** buttons to adjust the radio volume.

MAINTENANCE

Cleaning:

To clean the device, use a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.

Battery Replacement:

When the display dims or the device functions erratically, it may be time to replace the batteries. Follow the "Battery Installation" steps in the "Setup" section. Dispose of old batteries responsibly according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	No power, dead batteries, or AC adapter not connected properly.	Check battery polarity, replace batteries, or ensure AC adapter is securely plugged in.
Time is incorrect.	Poor radio-controlled signal reception or manual setting error.	Relocate the device to an area with better signal. Manually set the time if automatic synchronization fails.
Radio static or poor reception.	Weak signal, interference, or antenna not extended.	Extend the telescopic antenna fully. Try repositioning the unit. Tune to a stronger station.
Alarm does not sound.	Alarm not activated or volume too low.	Ensure the alarm icon is displayed. Increase the alarm volume.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Product Dimensions	5.6 x 18 x 9 cm; 439.98 g
Batteries Required	Yes
Item Model Number	BNC010
Brand	Braun
Color	White
Display Type	Digital
Special Features	Alarm
Power Source	Battery
Material	Plastic
Batteries Included	Yes
Alarm Clock	Yes

Note: Specifications are subject to change without notice for product improvement.

© 2024 Braun. All rights reserved.

For further assistance, please visit the official Braun website or contact customer support.

[Visit the Braun Store on Amazon](#)