

[Manuals.plus](#) /

> [KONCEPT](#) /

> KONCEPT AR3000-CD-MBK-DSK Z-Bar LED Desk Lamp User Manual

KONCEPT AR3000-CD-MBK-DSK

KONCEPT AR3000-CD-MBK-DSK Z-Bar LED Desk Lamp User Manual

Model: AR3000-CD-MBK-DSK | Brand: KONCEPT

INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your KONCEPT AR3000-CD-MBK-DSK Z-Bar LED Desk Lamp. Please read this manual thoroughly before installation and operation, and retain it for future reference.

The Z-Bar LED Desk Lamp features an award-winning three-bar design, offering extensive reach and flexibility. Its adjustable LED head can rotate, sweep side to side, and pivot to direct light precisely where needed. The integrated touchstrip allows for continuous dimming and on/off control.

SAFETY INFORMATION

- Ensure the power supply voltage matches the lamp's requirements (120 Volts).
- Do not attempt to disassemble or modify the lamp. Refer all servicing to qualified personnel.
- Avoid exposing the lamp to excessive moisture or extreme temperatures.
- Always unplug the lamp from the power outlet before cleaning or performing any maintenance.
- Keep the lamp away from flammable materials.

PACKAGE CONTENTS

Verify that all components are present before proceeding with assembly.

- KONCEPT Z-Bar LED Desk Lamp (Main Unit)
- Desk Base
- Power Cord
- User Manual (This document)

SETUP AND ASSEMBLY

The KONCEPT Z-Bar LED Desk Lamp requires assembly. Follow these steps carefully.

1. **Unpack Components:** Carefully remove all parts from the packaging and place them on a clean, flat surface.
2. **Attach Lamp to Base:** Securely attach the main lamp unit to the desk base. Ensure all connections are firm.
3. **Connect Power:** Plug the power cord into the lamp's power input, then plug the other end into a standard 120V AC electrical outlet.



Image 1: The KONCEPT Z-Bar LED Desk Lamp fully assembled, showcasing its metallic black finish and flexible arm design.



Image 2: The KONCEPT Z-Bar LED Desk Lamp in a typical desk setup, demonstrating its compact footprint and modern aesthetic.

OPERATING INSTRUCTIONS

Power On/Off and Dimming

The Z-Bar lamp features a touchstrip control located near the LED head for easy access.

- **To Turn On/Off:** Briefly touch any point on the touchstrip.
- **To Dim Gradually:** Slide your finger along the touchstrip. Sliding towards one end will increase brightness, and towards the other will decrease it.

- **To Jump to Specific Brightness:** Touch the touchstrip at the desired brightness level.

Adjusting the Lamp Head and Arms

The lamp's three-bar design allows for extensive adjustability.

- **LED Head Rotation:** The LED head can spin in its socket, allowing for 360-degree rotation.
- **Side-to-Side Sweep:** The LED head can sweep from side to side.
- **Arm Adjustment:** The articulated arms can be positioned to achieve the desired height and reach.



Image 3: A detailed view of the KONCEPT Z-Bar LED Desk Lamp, highlighting its flexible joints and the integrated LED light source.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your lamp.

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the lamp's surfaces. Do not use abrasive cleaners, solvents, or polishes, as these can damage the finish.

- **LED Lifespan:** The integrated LEDs have a lifespan of approximately 50,000 hours and are not user-replaceable.
- **Storage:** If storing the lamp for an extended period, ensure it is clean, dry, and stored in a safe place to prevent damage.

TROUBLESHOOTING

Refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply.	Check if the power cord is securely plugged into both the lamp and the electrical outlet. Verify the outlet is functional.
Light flickers or dims unexpectedly.	Unstable power connection or faulty outlet.	Ensure the power cord is firmly connected. Try plugging the lamp into a different outlet.
Touchstrip not responding.	Temporary electronic glitch.	Unplug the lamp for 30 seconds, then plug it back in to reset. Ensure your finger is clean and dry when using the touchstrip.

If the problem persists after attempting these solutions, please contact KONCEPT customer support.

SPECIFICATIONS

Feature	Detail
Model	AR3000-CD-MBK-DSK
Brand	KONCEPT
Lamp Type	LED Desk Lamp
Finish	Metallic Black
Material	Aluminum
Wattage	9.5 Watts
Voltage	120 Volts
Light Source Type	LED
LED Lifespan	50,000 hours
Color Temperature Options	3500K (Warm) or 4500K (Cool)
CRI	85
Switch Type	Touchstrip (Continuous Dimming & On/Off)
Product Dimensions	9"D x 33.88"W x 33.88"H
Item Weight	5.53 Pounds
Cord Length	120 inches

Feature	Detail
Assembly Required	Yes

WARRANTY INFORMATION

The KONCEPT AR3000-CD-MBK-DSK Z-Bar LED Desk Lamp comes with a **5-year warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or improper installation. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For technical assistance, warranty claims, or further inquiries, please contact KONCEPT customer support.

- **Website:** Visit the official KONCEPT website for support resources and contact information.
- **Email:** Refer to your product packaging or the KONCEPT website for the appropriate support email address.
- **Phone:** Refer to your product packaging or the KONCEPT website for customer service phone numbers.

When contacting support, please have your model number (AR3000-CD-MBK-DSK) and proof of purchase readily available.

