

[Manuals.plus](#) /

› [RYGHT](#) /

› RYGHT Y-Storm R480477 Wired Portable Speaker User Manual

RYGHT Y-Storm

RYGHT Y-Storm R480477 Wired Portable Speaker User Manual

Model: Y-Storm | Brand: RYGHT

INTRODUCTION

The RYGHT Y-Storm R480477 is a compact and lightweight wired portable speaker designed for use with various audio devices. Its durable metal construction provides robustness and contributes to its acoustic performance. This speaker features a 3.5mm jack connection for audio input and a USB port for charging. It delivers 3 Watts of power and offers up to 8 hours of battery life on a 2-hour charge.



Figure 1: RYGHT Y-Storm R480477 Wired Portable Speaker. This image shows the speaker's front with the RYGHT logo and the control panel at the base.

SETUP

Package Contents

Before setup, ensure all items are present:

- RYGHT Y-Storm Wired Portable Speaker
- 3.5mm Jack Audio Cable
- Micro USB Charging Cable
- User Manual (this document)

ACCESSOIRES



Notice



Y-Storm Filaire



Câble jack 3,5mm



Câble micro USB

Figure 2: Included accessories for the RYGH T Y-Storm speaker, showing the speaker unit, 3.5mm audio cable, micro USB charging cable, and the user manual.

Charging the Speaker

1. Connect the micro USB end of the charging cable to the USB port on the speaker.
2. Connect the standard USB end of the charging cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate.
4. A full charge takes approximately 2 hours. The indicator light will change or turn off once charging is complete.



Figure 3: Rear view of the RYGHT Y-Storm speaker, highlighting the micro USB charging port at the base.

OPERATING INSTRUCTIONS

Powering On/Off

- To power on the speaker, locate the power switch at the base of the unit and slide it to the 'ON' position.
- To power off, slide the switch to the 'OFF' position.

Connecting to an Audio Device

The RYGHT Y-Storm R480477 is a wired speaker and connects via a 3.5mm audio jack.

1. Ensure the speaker is powered on.
2. Connect one end of the provided 3.5mm audio cable to the audio input jack on the speaker.
3. Connect the other end of the 3.5mm audio cable to the headphone jack or audio output port of your smartphone, tablet, laptop, or game console.
4. Play audio from your connected device. The sound will be output through the RYGHT Y-Storm speaker.

Volume Control

Adjust the playback volume directly from your connected audio device. The speaker itself does not feature independent volume controls.

MAINTENANCE

Cleaning

- Wipe the speaker's exterior with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or strong chemicals, as these may damage the finish.
- Ensure no liquid enters the ports or speaker grille.

Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery periodically to maintain its health.

Durability

The RYGHT Y-Storm speaker features a robust metal casing, making it highly resistant to minor impacts. It is also designed to be waterproof, offering protection against splashes and light moisture exposure. However, it is not intended for submersion in water.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from speaker	Speaker is off; Low battery; Audio cable not connected properly; Device volume too low; Incorrect audio output selected on device.	Ensure speaker is ON; Charge the speaker; Reconnect the 3.5mm audio cable firmly; Increase volume on your audio device; Check audio settings on your device.
Speaker not charging	Charging cable faulty; USB power source not working; USB port on speaker damaged.	Try a different micro USB cable; Use a different USB power adapter or computer port; Contact support if ports appear damaged.
Distorted sound	Volume too high on device; Audio source quality is poor; Speaker placed on vibrating surface.	Reduce volume on your audio device; Try a different audio source; Place the speaker on a stable, non-vibrating surface.
Short battery life	Speaker not fully charged; Battery degradation over time.	Ensure speaker is charged for the full 2 hours; Battery life naturally decreases over time.

SPECIFICATIONS

Feature	Detail
Model Number	Y-Storm
Brand	RYGHT
Power Output	3 Watts
Connectivity Technology	Wired (3.5mm Jack), USB for charging

Feature	Detail
Power Source	Electric Cable (USB rechargeable battery)
Battery Life	Up to 8 hours
Charging Time	Approximately 2 hours
Dimensions (L x W x H)	20 x 25 x 15 cm
Weight	249.48 grams
Color	Violet
Waterproof	Yes (splash-resistant)
Recommended Uses	Game console, Smartphone, Tablet



Figure 4: Dimensions of the RYGHT Y-Storm speaker, indicating a height of 5cm and a width of 6cm.

WARRANTY INFORMATION

The RYGHT Y-Storm R480477 Wired Portable Speaker comes with a manufacturer's warranty of **1 year** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage

caused by misuse, accidents, unauthorized modifications, or normal wear and tear.
Please retain your proof of purchase for warranty claims.

SUPPORT

For further assistance, technical support, or warranty inquiries regarding your RYGHT Y-Storm R480477 speaker, please refer to the official RYGHT website or contact their customer service department. Contact details can typically be found on the product packaging or the brand's official online presence.
You may also visit the [RYGHT Brand Store](#) for more information.

© 2023 RYGHT. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question