

[Manuals.plus](#) /

› [Montblanc](#) /

› Montblanc Classique UNICEF Mechanical Pencil (0.7 mm) User Manual

Montblanc 105608

Montblanc Classique UNICEF Mechanical Pencil (0.7 mm) User Manual

Model: 105608

1. PRODUCT OVERVIEW

This manual provides comprehensive instructions for the proper use, maintenance, and care of your Montblanc Classique UNICEF Mechanical Pencil (0.7 mm), Model 105608. Designed for precision and durability, this mechanical pencil is a sophisticated writing instrument. Please read this manual thoroughly before first use to ensure optimal performance and longevity of your product.



Image 1.1: The Montblanc Classique UNICEF Mechanical Pencil. This image displays the sleek black barrel, gold-plated accents, the iconic Montblanc star emblem on the cap, and the 0.7 mm lead tip.

2. SETUP

2.1. Unpacking

Carefully remove the mechanical pencil from its packaging. Inspect the pencil for any visible damage. Retain the original packaging for future storage or transport.

2.2. Loading Lead

1. Ensure the pencil is in a vertical position with the tip facing downwards.
2. Press the push-button mechanism at the top of the pencil until the lead sleeve is fully extended.
3. Insert a 0.7 mm lead refill into the opening at the tip of the lead sleeve.
4. Gently release the push-button. The lead should now be securely held.
5. To advance the lead, press the push-button repeatedly until the desired lead length is exposed.

Important: Use only 0.7 mm lead refills to prevent damage to the internal mechanism.

3. OPERATING INSTRUCTIONS

3.1. Writing

Hold the mechanical pencil comfortably as you would any writing instrument. Press the push-button at the top to extend the lead. Adjust the lead length as needed for optimal writing experience.

3.2. Retracting Lead

To retract the lead, gently press the push-button while simultaneously pushing the lead tip against a hard surface until the lead is fully retracted into the sleeve. This prevents lead breakage when not in use.

3.3. Using the Eraser

The eraser is located under the push-button cap. Gently pull the push-button straight off to reveal the eraser. After use, replace the push-button cap firmly.

4. MAINTENANCE

4.1. Cleaning

- Wipe the exterior of the pencil with a soft, dry, lint-free cloth.
- Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth.

4.2. Storage

Store the mechanical pencil in its original case or a protective pouch when not in use to prevent scratches and damage. Avoid exposing the pencil to extreme temperatures or direct sunlight for prolonged periods.

4.3. Lead Refills and Eraser Replacement

Always use genuine Montblanc 0.7 mm lead refills and Montblanc erasers to ensure proper function and to maintain the integrity of your writing instrument. These can be purchased from authorized Montblanc retailers.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lead does not advance.	No lead loaded or incorrect lead size.	Load new 0.7 mm lead. Ensure no broken lead pieces are jammed inside.
Lead breaks frequently.	Too much lead exposed or excessive writing pressure.	Advance less lead. Reduce writing pressure. Ensure lead is genuine 0.7 mm.

Problem	Possible Cause	Solution
Eraser is worn out or missing.	Normal wear and tear.	Replace with a genuine Montblanc eraser.

6. SPECIFICATIONS

- **Brand:** Montblanc
- **Model Number:** 105608
- **Lead Size:** 0.7 mm
- **Material Type:** Plastic (internal components/specific parts)
- **Package Dimensions:** 15.24 x 15.24 x 5.08 cm
- **ASIN:** B007OLD2SU
- **First Available:** January 15, 2020

7. WARRANTY AND SUPPORT

Montblanc products are crafted with the highest standards of quality. For specific warranty information regarding your Montblanc Classique UNICEF Mechanical Pencil, please refer to the warranty card included with your purchase or visit the official Montblanc website.

For technical support, service, or inquiries about genuine Montblanc accessories and refills, please contact Montblanc customer service or visit an authorized Montblanc boutique.

Official Montblanc Website: www.montblanc.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question