

[Manuals.plus](#) /

› [REVLON](#) /

› Revlon RVST2082 Tourmaline Ceramic Digital Straightener User Manual

REVLON RVST2082

Revlon RVST2082 Tourmaline Ceramic Digital Straightener

Model: RVST2082

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your Revlon RVST2082 Tourmaline Ceramic Digital Straightener. Please read all instructions carefully before use and retain this manual for future reference.



Figure 1: Revlon RVST2082 Tourmaline Ceramic Digital Straightener. This image shows the sleek black design of the straightener with its digital display and control buttons visible.

IMPORTANT SAFETY INFORMATION

To reduce the risk of burns, electrocution, fire, or injury to persons, please observe the following safety precautions:

- **DO NOT** wrap the cord around the appliance when not in use or while in storage. This can damage the cord and create a shock hazard.
- Always unplug the appliance immediately after using it.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- This appliance is for household use only.

- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- Do not touch hot surfaces. Use handles or knobs.
- Before plugging in, read information about dual voltage contained in the operating instructions section.

PRODUCT FEATURES

The Revlon RVST2082 straightener is designed with advanced features for efficient and safe hair styling.



©2021 Helen of Troy. All rights reserved.

Figure 2: Key components of the Revlon RVST2082 straightener. This diagram highlights the 1" Ceramic Plates, Precise Digital Temperature Display, Multiple Heat Settings, Lock/Unlock Tab, and Tangle-Free Swivel Cord.

1" Ceramic Plates: Ideal for ultra-straight styles, providing even heat distribution.

Precise Digital Temperature Display: Provides an accurate reading of the perfect styling temperature.

Multiple Heat Settings: Offers precise control for all hair types, ensuring optimal results.

Lock/Unlock Tab: For storage flexibility, allowing the plates to be securely closed.

Tangle-Free Swivel Cord: Designed for easy styling and maneuverability.



©2021 Helen of Troy. All rights reserved.

Figure 3: Illustration of 3X Ceramic Coating. This image emphasizes the ceramic plates and the benefit of reduced damage from over-styling due to even heat distribution.

Triple Baked Ceramic, Tourmaline: This technology provides high, even heat that penetrates hair from the inside out, helping hair retain natural moisture for frizz-free styles. The 3X Ceramic Coating helps reduce damage from over-styling with even heat distribution, making styling fast and easy.



**Multiple
Heat Settings**
Precise control
for all hair types.

©2021 Helen of Troy. All rights reserved.

Figure 4: Digital display showing multiple heat settings. This image highlights the precise control available for different hair types.

The easy-to-read DIGITAL TEMPERATURE DISPLAY and SENSORS help you find and keep the perfect styling temperature for your hair, ensuring consistent temperatures every time.

SETUP AND INITIAL USE

1. **Unpacking:** Carefully remove the straightener from its packaging. Ensure all components are present and undamaged.
2. **Power Connection:** Plug the Revlon Perfect Heat Ceramic Digital Flat Iron into a suitable electrical outlet. Ensure the voltage matches your local power supply.
3. **Cord Management:** Uncoil the tangle-free swivel cord completely before use.

OPERATING INSTRUCTIONS

Follow these steps for effective hair straightening:

1. **Power On:** Press the ON/OFF button to turn on the straightener.
2. **Select Temperature:** Use the '+' and '-' buttons to select your desired heat setting. The digital display will show the current temperature.
3. **Heat Up:** Wait for the flat iron to reach the selected temperature. The digital display will indicate when it's ready.
4. **Prepare Hair:** Section your hair into manageable portions using clips. Ensure hair is clean, dry, and tangle-free.
5. **Straighten Hair:** Place a section of hair between the ceramic plates, close to the roots.
6. **Glide:** Gently close the plates and glide the flat iron down the hair shaft from root to tip in a smooth, continuous motion. Do not hold the straightener in one place for too long to avoid heat damage.
7. **Repeat:** Repeat steps 5 and 6 for the remaining hair sections until desired style is achieved.
8. **Power Off:** When finished, press the ON/OFF button to turn off the straightener and unplug it from the electrical outlet.

The straightener features an **Auto Shut-off** for peace of mind, automatically turning off after a period of inactivity.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and performance of your straightener.

- **Cleaning:** Ensure the appliance is unplugged and completely cool before cleaning. Wipe the ceramic plates and exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the appliance in a cool, dry place. **DO NOT** wrap the cord around the appliance when not in use or while in storage, as this can damage the cord. Use the Lock/Unlock tab to keep the plates closed for compact storage.
- **Cord Care:** Regularly inspect the power cord for any signs of damage. If the cord is damaged, discontinue use and contact customer support.

TROUBLESHOOTING

If you encounter issues with your Revlon RVST2082 straightener, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Straightener does not turn on.	Not plugged in, power outlet issue, or damaged cord.	Ensure the straightener is securely plugged into a working outlet. Check the power cord for visible damage. Try a different outlet.
Straightener not heating up.	Incorrect temperature setting, internal malfunction.	Verify the temperature setting on the digital display. Allow sufficient time for heating. If the issue persists, contact customer support.
Hair is not straightening effectively.	Hair is not dry, sections are too large, or temperature is too low.	Ensure hair is completely dry before styling. Use smaller sections of hair. Increase the temperature setting if appropriate for your hair type.
Straightener automatically shuts off.	Auto shut-off feature activated due to inactivity.	This is a safety feature. Simply turn the straightener back on if you wish to continue styling.

For issues not listed here, please contact Revlon customer support.

SPECIFICATIONS

Model Number: RVST2082

Brand: REVLON

Color: Black

Plate Material: Tourmaline Ceramic

Plate Size: 1 inch

Max. Temperature Setting: 221.1 Degrees Celsius (430 Degrees Fahrenheit)

Power Source: Corded Electric

Item Weight: 0.9 Pounds (approx. 408.23 g)

Product Dimensions: 7.62 x 14.61 x 36.83 cm

Product Benefits: Moisturizing, Frizz-free styles

Features: Digital Temperature Display, Multiple Heat Settings, Auto Shut-off, Tangle-Free Swivel Cord

Manufacturer: Revlon

Date First Available: August 6, 2012

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Revlon website. Keep your purchase receipt as proof of purchase for any warranty claims.

Revlon Official Website: www.revlon.com

© 2024 Revlon. All rights reserved. Information subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B007RX2W3G>

More documents and user manuals: <https://manuals.plus/>