



Manuals.plus /

› Emjoi /

› Emjoi Micro-Pedi 3D POWER Corded Callus Remover User Manual

Emjoi AP-3DA

Emjoi Micro-Pedi 3D POWER Corded Callus Remover User Manual

Model: AP-3DA

1. INTRODUCTION

The Emjoi Micro-Pedi 3D POWER Callus Remover is an advanced device designed to effectively smooth dry, rough, and calloused skin on the feet and heels. Featuring multi-movement technology, its unique flex roller spins at 360 degrees, 30 times per second, and oscillates laterally at 20 times per second, providing efficient and gentle exfoliation. This corded model ensures consistent power for optimal performance.



Figure 1: Emjoi Micro-Pedi 3D POWER Callus Remover.

2. SAFETY INFORMATION

- **Caution:** For safe and proper use, keep out of reach of children.
- Do not use near water or in a damp environment.
- Do not use with metal scrapers, which can cause injury.
- This is an electrically-operated device; handle with care to avoid electrical shock.
- If ingested, seek medical help immediately.
- Do not use on areas that are red, irritated, inflamed, or infected.
- Discontinue use if irritation occurs.
- Please refer to the user manual for detailed safety instructions.

3. PACKAGE CONTENTS

Your Emjoi Micro-Pedi 3D POWER package includes:

- Emjoi Micro-Pedi 3D POWER Device
- Micro-Pedi Flex Xtreme Coarse (Purple) Roller (installed in unit)
- Power Adapter (Corded)
- Cleaning Brush
- Instruction Manual



Figure 2: Product packaging showing included items.

4. SETUP

4.1. Inserting the Roller

1. Ensure the device is turned off and unplugged.
2. Press the release button on the side of the device to remove the existing roller or protective cover.
3. Align the new Micro-Pedi Flex roller with the unit, ensuring the thinner side goes into the unit first.
4. Push the roller firmly until it clicks into place. Verify it is securely installed without any signs of looseness.

4.2. Connecting Power

1. Insert the adapter plug into the adapter inlet located at the bottom of the device.
2. Plug the power adapter into a standard electrical outlet (100-240V). Ensure the adapter is appropriate for the local voltage.

5. OPERATING INSTRUCTIONS

5.1. Before Use

- Use the device only on dry, rough skin. Do not use on wet or moist skin.
- Wash and clean the skin thoroughly and dry fully before use.

5.2. Turning On/Off

To turn on the device, press and push up the safety switch lock. To turn off, push the switch down.

5.3. Using the Micro-Pedi 3D POWER

1. Gently glide the spinning roller over the calloused area. Apply light to moderate pressure.
2. Allow the device to do the work; do not press down too hard, as this may cause the roller to stop or damage the skin.
3. Move the device in a back-and-forth and side-to-side motion to effectively buff away dead skin.
4. Continue until the skin is smooth. Avoid using on one area for too long to prevent irritation.
5. After use, turn off the device and unplug it.

ACCEPTED



Emjoi®

MICRO  **Pedi™**

Figure 3: Illustrates the effectiveness of the callus remover.

5.4. Roller Types

The Micro-Pedi Flex roller is available in four versions to suit various foot care needs:

- Gentle/Sensitive
- Normal/Classic
- Extra Coarse
- Xtreme Coarse (included with this model for severe calluses)

Our Flex rollers fit all Emjoi Micro-Pedi Callus Removers



Figure 4: Different Emjoi Micro-Pedi devices and compatible Flex rollers.

6. MAINTENANCE

6.1. Cleaning the Device

1. Ensure the device is turned off and unplugged.
2. Remove the roller by pressing the release button.
3. Use the provided cleaning brush to remove any dead skin particles from the roller and the device head.
4. The device body can be wiped clean with a dry cloth. Do not rinse the device under water.

6.2. Replacing Rollers

Rollers should be replaced when they show signs of wear or become less effective. Replacement rollers are available separately. Follow the instructions in Section 4.1 for inserting a new roller.

7. TROUBLESHOOTING

- **Device not turning on:** Ensure the power adapter is securely plugged into both the device and a working electrical outlet. This model is corded and requires continuous power.
- **Roller not spinning properly:** Check that the roller is correctly inserted and clicked into place. Ensure no debris is obstructing its movement.
- **Reduced effectiveness:** The roller may be worn out. Replace it with a new Emjoi Micro-Pedi Flex roller.

8. SPECIFICATIONS

Feature	Specification
Model Number	AP-3DA (Emjoi Micro-Pedi Power)
Power Source	Electrically-operated (Corded)
Roller Type	Micro-Pedi Flex Xtreme Coarse (Purple)
Roller Rotation	360 degrees at 30 times per second
Roller Oscillation	Laterally at 20 times per second
Material	Metal
Color	Blue (device color)
Item Weight	6.4 ounces
Package Dimensions	7.6 x 5.16 x 2.48 inches

9. OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video 1: Unboxing and demonstration of the Emjoi Micro-Pedi 3D POWER Callus Remover, showing its components, assembly, and operation. This video highlights the corded power and the unique multi-directional roller movement for effective callus removal.

10. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement rollers, please visit the official Emjoi website or contact Emjoi customer service. Refer to the original product packaging for specific contact details.