

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Oxelo](#) /

› [Oxelo Town 5 Adult Scooter Instruction Manual](#)

Oxelo Town 5

Oxelo Town 5 Adult Scooter Instruction Manual

Model: Town 5

Brand: Oxelo

1. INTRODUCTION

Welcome to your new Oxelo Town 5 Adult Scooter. This manual provides essential information for safe assembly, operation, maintenance, and troubleshooting. Please read it thoroughly before first use to ensure a safe and enjoyable experience.

The Oxelo Town 5 scooter is designed for mid and long urban trips, suitable for users between 1.45m and 1.85m tall, with a maximum weight limit of 100kg.

2. SAFETY INFORMATION

Important Safety Guidelines

- Always wear appropriate safety gear, including a helmet, knee pads, and elbow pads, to minimize injury risk.
- Ensure all locking mechanisms are securely fastened before each ride. A loose mechanism can lead to loss of control.
- Do not exceed the maximum weight limit of 100 kg. Exceeding this limit can compromise the scooter's structural integrity and safety.
- Ride on smooth, dry surfaces away from traffic. Avoid uneven terrain, potholes, and slippery conditions.
- Avoid riding in wet conditions, at night, or in low visibility. Reduced visibility and traction increase accident risk.
- Regularly inspect the scooter for wear and tear, especially wheels, brakes, and folding mechanisms. Address any issues promptly.
- This scooter is designed for adult use. It is not intended for children.

3. PRODUCT OVERVIEW

Components

The Oxelo Town 5 Adult Scooter features a robust design optimized for urban commuting, offering comfort

and portability.



Image: The Oxelo Town 5 Adult Scooter in a folded state, showcasing its compact design for easy transport.

Handlebar: Fixed type for stability and control during rides.

Frame: Constructed from lightweight and sturdy 6061 Aluminium, ensuring durability without excessive weight.

Deck: Also made from 6061 Aluminium, providing a stable platform for the rider.

Wheels: Large diameter Polyurethane (PU) cast wheels designed for comfort over longer distances and improved acceleration with less effort.

Bearings: ABEC 5 quality bearings enhance wheel movement smoothness and efficiency.

Brake: Features a reliable rear braking system for effective stopping power.

Grips: Rubber grips on the handlebar provide comfort and a secure hold.

Folding System: A compact folding mechanism allows for convenient storage and transport.

Carry Strap: An integrated carry strap is included for easy portability when the scooter is folded.

4. SETUP

Initial Assembly and Adjustment

1. Unfolding the Scooter:

Locate the folding mechanism near the base of the handlebar stem. Release the locking lever and carefully unfold the scooter until it clicks into place. Ensure the mechanism is fully engaged and locked before use. Verify there is no play in the folding joint.

2. Adjusting Handlebar Height:

The Oxelo Town 5 features a fixed handlebar for enhanced stability. Ensure the handlebar is securely attached to the stem and all bolts are tightened according to manufacturer specifications.

3. Checking Components:

Before your first ride, and periodically thereafter, verify that all screws, bolts, and quick-release levers are tight and secure. Check the wheels for proper rotation and ensure the rear brake functions effectively. Any loose parts should be tightened immediately.

5. OPERATING

Riding Your Oxelo Town 5 Scooter

1. Starting:

Place one foot firmly on the deck, preferably towards the front. Use your other foot to push off the ground, gaining initial momentum. Continue pushing until you reach a comfortable speed.

2. Riding Stance:

Once moving, place both feet on the deck. You can position them one behind the other, or side-by-side if you find it more comfortable and stable. Maintain a balanced posture with slightly bent knees.

3. Steering:

Steer the scooter by leaning gently in the desired direction and making subtle turns with the handlebars. Avoid sudden or sharp turns at high speeds.

4. Braking:

To slow down or stop, apply pressure to the rear brake with your foot. Apply the brake gradually to avoid sudden stops, which can cause loss of balance. Practice braking in a safe, open area.

5. Folding for Transport:

To fold the scooter, ensure you are stationary. Release the locking lever of the folding mechanism and carefully collapse the scooter. Secure it with the integrated carry strap for easy and convenient transport.

6. MAINTENANCE

Care and Upkeep

- Cleaning:** Wipe down the scooter with a damp cloth after use to remove dirt and debris. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- Lubrication:** Periodically check and lubricate moving parts, such as the folding mechanism, if necessary. Use a light, non-corrosive lubricant.
- Wheel Inspection:** Regularly inspect the PU cast wheels for signs of wear, cracks, or damage. Replace worn wheels to maintain optimal performance and safety.
- Bearing Care:** ABEC 5 bearings are designed for durability. Keep them clean and free from dirt and moisture. If bearings become noisy or stiff, they may need cleaning or replacement.
- Brake Check:** Ensure the rear brake is responsive and not excessively worn. Inspect the brake pad for wear and replace it if needed. Ensure the brake mechanism is clear of obstructions.
- Storage:** Store the scooter in a dry place, away from direct sunlight and extreme temperatures, to prevent material degradation.

7. TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
Scooter does not fold/unfold smoothly	Mechanism dirty or stiff	Clean and lubricate the folding mechanism with a suitable lubricant.
Wheels not spinning freely	Dirt in bearings, worn bearings, or overtightened axle nuts	Clean bearings thoroughly. Replace bearings if worn. Check and adjust axle nut tightness.
Brake not effective	Worn brake pad or mechanism, debris in brake area	Inspect and replace the brake pad if worn. Ensure the brake mechanism is clear of any obstructions.
Rattling noise during ride	Loose components (screws, bolts, quick-release levers)	Carefully check and tighten all screws, bolts, and quick-release levers on the scooter.

8. SPECIFICATIONS

Technical Details

Model Name: Town 5

Brand: Oxelo

Colour: Grey

Age Range: Adult

Special Feature: Lightweight

Weight Limit: 100 Kilograms

Item Weight: 4.7 Kilograms (4 kg 700 g)

Wheel Material: Polyurethane (PU Cast)

Frame Material: 6061 Aluminium

Handlebar Type: Fixed

Wheel Type: Solid

Grip Type: Rubber

Brake Style: Rear Braking

Recommended Use: Urban commuting

Included Components: Scooter

9. WARRANTY AND SUPPORT

Product Support

For warranty information, spare parts, or technical support, please refer to the official Oxelo website or contact your local retailer. Keep your purchase receipt as proof of purchase for any warranty claims.

Note: Specific warranty terms and conditions may vary by region and retailer. Please consult your point of purchase for detailed information.

For further assistance and to find local support, visit the official Oxelo support page: [Oxelo India Support](#).

