

LEGO 11625

LEGO Marvel Super Heroes Deadpool Minifigure Instruction Manual

Model: 11625

[Introduction](#)

[Safety Information](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

This instruction manual provides essential information for the assembly, use, and care of your **LEGO Marvel Super Heroes Deadpool Minifigure**, Model 11625. This authentic LEGO product is designed for imaginative play and display.

Please read this manual thoroughly before handling the product to ensure proper usage and safety.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD.

- This toy contains small parts and a small ball.
- Not suitable for children under 3 years due to potential choking hazards.
- Adult supervision is recommended during play, especially with younger children.
- Keep all packaging materials away from children.

The manufacturer's recommended minimum age for this product is 12 years (144 months).

3. SETUP AND ASSEMBLY

Your LEGO Marvel Super Heroes Deadpool Minifigure may arrive partially disassembled. Follow these steps to complete the assembly:

1. Carefully remove all components from the packaging. Ensure all parts are present: one Deadpool minifigure body (head, torso, legs), two arms, two hands, and two katana accessories.
2. Attach the arms to the minifigure torso if they are separate. Ensure they click securely into place.
3. Insert the hands into the arm sockets.
4. Attach the head to the neck stud on the torso.
5. Position the two katana accessories into the back holster of the minifigure. The katanas should slide into the designated slots on the back accessory piece.



Figure 1: Front view of the assembled LEGO Deadpool Minifigure. The minifigure is red and black, holding two black katanas, with a brown harness on its back.



Figure 2: Back view of the assembled LEGO Deadpool Minifigure. The brown harness on the back holds two black katanas, crossed over each other.

4. OPERATING (PLAY AND DISPLAY)

The LEGO Deadpool Minifigure is designed for imaginative play and as a collectible display item.

- **Play:** Use the minifigure in conjunction with other LEGO sets or as a standalone character for creative storytelling. The arms, hands, and head can be posed for various actions.
- **Display:** The minifigure can be displayed on a flat surface or a LEGO baseplate (not included) to showcase its design.
- **Accessories:** The included katanas can be held by the minifigure's hands or stored in the back holster.

Avoid excessive force when posing or playing with the minifigure to prevent damage to the plastic components.

5. MAINTENANCE AND CARE

Proper care will ensure the longevity of your LEGO Minifigure.

- **Cleaning:** To clean the minifigure, wipe it gently with a soft, damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly with clean water. Avoid harsh chemicals or abrasive materials.
- **Drying:** Allow the minifigure to air dry completely before storing or reassembling.
- **Storage:** Store the minifigure in a cool, dry place away from direct sunlight and extreme temperatures to prevent discoloration or warping of the plastic.
- **Avoid Heat:** Do not expose the minifigure to high heat sources, as this can deform the plastic.

6. TROUBLESHOOTING

If you encounter any issues with your LEGO Deadpool Minifigure, please refer to the following:

- **Missing Parts:** If any parts are missing upon opening the package, please contact LEGO Customer Service directly. Refer to the "Warranty & Support" section for contact information.
- **Damaged Parts:** If a part is damaged, avoid forcing it. Contact LEGO Customer Service for assistance.
- **Loose Connections:** Ensure all parts are firmly pressed together during assembly. If connections remain loose, inspect the studs and holes for any debris or manufacturing defects.

7. SPECIFICATIONS

Brand	LEGO
Model Name	Deadpool
Model Number	11625
Material Type	Plastic
Item Dimensions (L x W x H)	0.39 x 0.39 x 0.79 inches (1"L x 1"W x 2"H)
Item Weight	15 Grams
Number of Pieces	1 (Minifigure)
UPC	885212138457
Recommended Age	12 years and up (Manufacturer's recommendation)

8. WARRANTY & SUPPORT

Specific warranty details for individual LEGO minifigures are typically covered under the general LEGO product warranty policy. For detailed warranty information, please visit the official LEGO website or contact their customer service.

For product support, missing parts, or any other inquiries, please contact LEGO Customer Service:

- **Website:** www.lego.com/service
- **Contact Information:** Refer to the LEGO website for regional contact numbers and email support.

