

[manuals.plus](#) /› [Genius](#) /› [Genius GX-Gaming SW-G2.1 3000 Speaker System User Manual](#)**Genius SW-G2.1 3000**

Genius GX-Gaming SW-G2.1 3000 Speaker System User Manual

Model: SW-G2.1 3000 | Brand: Genius

1. INTRODUCTION

The Genius GX-Gaming SW-G2.1 3000 is a 2.1 channel speaker system designed to enhance audio experiences for gaming, music, and movies. It features a powerful subwoofer for deep bass and two satellite speakers for clear mid and high-range sounds. The system includes a dedicated control box for convenient adjustments and multiple input options for various devices.



An image showing the Genius GX-Gaming SW-G2.1 3000 speaker system, featuring the subwoofer, two satellite speakers, and the control unit.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- One (1) Wooden Cabinet Subwoofer
- Two (2) Satellite Speakers
- One (1) Control Box
- One (1) Stereo RCA to 3.5mm Audio Cable
- One (1) 3.5mm Plug Audio Cable
- One (1) Microphone Jack Cable
- One (1) Headphone Jack Cable
- One (1) Multi-language User Manual

3. PRODUCT FEATURES

- **Total Output Power:** 70 Watts (RMS)

- **Subwoofer:** Wooden cabinet with a 6.5-inch driver for deep bass
- **Satellite Speakers:** Two curvaceous speakers with 3-inch metal drivers for clear mid and high tones
- **Control Box:** Independent controls for volume and bass adjustment
- **Connectivity:** Two input jacks (3.5mm standard and two RCA) for PC, TV, DVD, and game devices
- **Audio Jacks:** Dedicated microphone jack for online communication and headphone jack for private listening
- **Frequency Response:** 35 Hz ~ 20K Hz
- **Signal-to-Noise Ratio:** 85 dB
- **Power Saving Mode:** Automatically enters sleep mode after 1 minute of inactivity. To resume, ensure audio input device volume is at least 50%.

4. SETUP INSTRUCTIONS

1. **Positioning Speakers:** Place the subwoofer on a stable surface, preferably on the floor, for optimal bass. Position the satellite speakers on either side of your listening area, facing you.
2. **Connect Satellite Speakers:** Connect the cables from the two satellite speakers to the corresponding output ports on the subwoofer.
3. **Connect Control Box:** Plug the control box cable into the designated port on the subwoofer.
4. **Connect Audio Source:**
 - For PC, MP3/CD players: Use the 3.5mm audio cable to connect your device's audio output to the 3.5mm input on the control box.
 - For Game Consoles, DVD Players, TV: Use the stereo RCA to 3.5mm cable. Connect the RCA ends to your device's audio output and the 3.5mm end to the corresponding input on the control box.
5. **Connect Power:** Plug the subwoofer's power cord into a standard electrical outlet (110V or 220V AC, depending on your region).
6. **Power On:** Turn on the power switch, usually located on the subwoofer. The system is now ready for use.

5. OPERATING INSTRUCTIONS

- **Volume Control:** Use the large knob on the control box to adjust the overall volume of the speaker system.
- **Bass Control:** Use the dedicated bass knob on the control box to increase or decrease the subwoofer's bass output.
- **Microphone Usage:** Connect a microphone to the MIC jack on the control box for online communication.
- **Headphone Usage:** Plug your headphones into the headphone jack on the control box for private listening. This will mute the speakers.
- **Power Saving Mode:** If the system enters sleep mode due to inactivity, ensure your audio input device's volume is set to 50% or higher, then adjust the system's volume using the control box to resume audio.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the speakers and control box. Avoid using liquid cleaners or abrasive materials.
- **Placement:** Keep the speakers away from direct sunlight, heat sources, and excessive moisture. Ensure adequate ventilation around the subwoofer.
- **Cable Management:** Ensure all cables are securely connected and not tangled or pinched to prevent damage.
- **Storage:** If storing the system for an extended period, disconnect it from power and store it in a cool, dry place.

7. TROUBLESHOOTING

- **No Sound:**
 - Ensure the power cable is securely plugged in and the power switch is on.
 - Check all audio cables are correctly connected between the source device, control box, and subwoofer.
 - Verify the volume knob on the control box is turned up.
 - Ensure the audio source device (PC, TV, etc.) is playing audio and its volume is not muted or too low.
 - If in Power Saving Mode, increase the audio source device's volume to at least 50%.
- **Distorted Sound:**
 - Reduce the volume on both the speaker system and the audio source device.
 - Adjust the bass level on the control box.
 - Ensure speaker cables are not damaged or loosely connected.
- **One Speaker Not Working:**
 - Check the connection of the non-working satellite speaker to the subwoofer.
 - Test with another audio source or swap the satellite speaker connections (if possible) to isolate the issue.

8. TECHNICAL SPECIFICATIONS

Total Output Power	70 Watts (RMS)
Satellite Power	2 x 15 Watts
Subwoofer Power	40 Watts
Driver Units	Satellites: 2 x 3 inches, Subwoofer: 1 x 6.5 inches
Frequency Response	35 Hz ~ 20K Hz
Signal-to-Noise Ratio	85 dB
Subwoofer Dimensions (WxHxD)	230 x 314 x 215 mm (approx. 9 x 12.4 x 8.5 inches)
Satellite Dimensions (WxHxD)	99 x 115 x 143 mm

Controller Dimensions (WxHxD)	60 x 154 x 170 mm
System Weight	4.66 kg (approx. 10.27 lbs)
Power Source	110V or 220V AC
Compatible Devices	Personal Computer, Television, DVD Players, Game Consoles, MP3/CD players
Input Jacks	3.5mm standard input, two RCA jacks
Control Method	Knobs/Buttons (listed as 'Touch' in some specifications)

9. WARRANTY AND SUPPORT

This Genius GX-Gaming SW-G2.1 3000 speaker system comes with a **Limited Warranty**. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included in your product packaging or visit the official Genius website.

For technical support, troubleshooting assistance, or service inquiries, please contact Genius customer support through their official website or the contact information provided in your product documentation. When contacting support, please have your product model number (SW-G2.1 3000) and purchase information readily available.