

TIMEX T2N614

Timex Intelligent Quartz T2N614 Watch User Manual

Model: T2N614

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Timex Intelligent Quartz T2N614 Analog Watch. Please read this manual carefully to ensure proper use and to maximize the lifespan of your timepiece.

WATCH COMPONENTS

Familiarize yourself with the key components of your watch:

- **Crown:** Used for setting time and date.
- **Pushers:** Used for operating specific functions like chronograph or world time (depending on model features).
- **Dial:** Displays time, date, and other functions.
- **Hands:** Hour, minute, and second hands.
- **World Time Ring:** Outer ring displaying city names for world time function.
- **INDIGLO® Night-Light:** Illuminates the dial for low-light visibility.



Image Description: A close-up front view of the Timex Intelligent Quartz T2N614 watch. The black dial features white hour markers, a date window, and sub-dials. The outer ring displays various city names for the world time function. The

watch has a black stainless steel band.

SETUP

1. Setting the Time

1. Pull the crown out to the furthest position (position 3). The second hand will stop.
2. Rotate the crown to move the hour and minute hands clockwise until the desired time is set. Ensure the AM/PM is correctly set if your watch has a 24-hour indicator or date changes at midnight.
3. Push the crown back in to position 1 to start the watch.

2. Setting the Date

1. Pull the crown out to the middle position (position 2).
2. Rotate the crown either clockwise or counter-clockwise (depending on the model) to adjust the date.
3. Once the correct date is displayed, push the crown back in to position 1.

3. Adjusting the World Time (if applicable)

The Timex Intelligent Quartz T2N614 features a world time function. Refer to the specific instructions below:

1. Identify the pusher (usually at 2 or 4 o'clock) designated for world time adjustment.
2. Press and hold the world time pusher until the second hand moves to indicate the current city/time zone.
3. Rotate the crown or press the pusher repeatedly to cycle through the city names on the outer ring until your desired home city (or corresponding time zone) is aligned with the 12 o'clock position.
4. The watch will automatically adjust the main hands to reflect the time in the selected city.

4. Band Adjustment

The stainless steel band can be adjusted for a comfortable fit. It is recommended to have a professional jeweler or watch repair service adjust the band to prevent damage to the watch or band.



Image Description: A side view of the Timex Intelligent Quartz T2N614 watch, highlighting the crown and two pushers on the right side of the watch case. The black stainless steel finish is visible.

OPERATING YOUR WATCH

1. Reading the Time and Date

The watch displays time using traditional hour, minute, and second hands. The date is shown in a dedicated window on the dial.

2. Using the INDIGLO® Night-Light

To activate the INDIGLO® night-light, press the crown firmly inwards. The entire dial will illuminate for a few seconds, providing visibility in low-light conditions.

3. Water Resistance

Your Timex T2N614 watch is water-resistant up to 100 meters (WR 100M). This means it is suitable for showering, swimming, and snorkeling. It is not suitable for scuba diving. Always ensure the crown is fully pushed in before exposing the watch to water.



Image Description: A back view of the Timex Intelligent Quartz T2N614 watch, showing the stainless steel case back engraved with "TIMEX", "INTELLIGENT QUARTZ", "WR 100 METERS", and the model number "T2N614-YY". The black stainless steel bracelet is also visible.

MAINTENANCE

1. Cleaning Your Watch

Wipe the watch case and band regularly with a soft, dry cloth. For stainless steel bands, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.

2. Battery Replacement

The watch is powered by a quartz movement and requires a battery. When the battery runs low, the second hand may jump in 2-second intervals (End-of-Life indicator). It is highly recommended to have the battery replaced by an authorized Timex service center or a professional watchmaker to ensure proper sealing and maintain water resistance.

3. Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. A watch box or pouch is ideal for protection.

TROUBLESHOOTING

- **Watch Not Running:**

Check if the crown is fully pushed in. If the watch still does not run, the battery may need replacement. Refer to the "Battery Replacement" section.

- Incorrect Time/Date:**

Follow the "Setting the Time" and "Setting the Date" instructions carefully. Ensure the crown is fully pushed in after setting.
- Water Inside the Watch:**

If moisture or condensation appears inside the watch, take it to an authorized service center immediately. This indicates a breach in water resistance, and prompt action is needed to prevent further damage.

SPECIFICATIONS

Feature	Detail
Model Number	T2N614
Movement Type	Quartz
Display Type	Analog
Dial Color	Black
Case Diameter	44.15 mm
Case Thickness	12.81 mm
Band Material	Stainless Steel
Band Color	Black
Water Resistance	100 Meters (WR 100M)
Dial Glass Material	Mineral
Item Weight	261 g



Image Description: The Timex Intelligent Quartz T2N614 watch displayed on a wrist, showing its size and fit. The black dial and stainless steel band are clearly visible against the skin.

WARRANTY AND SUPPORT

Warranty Information

Your Timex Intelligent Quartz T2N614 watch comes with a **1 Year Manufacturer Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear.






Customer Support

For warranty claims, service, or technical assistance, please contact Timex customer support or visit an authorized Timex service center. Keep your proof of purchase for warranty validation.

For more information, you may visit the official Timex website or refer to the contact details provided with your purchase documentation.

© 2023 Timex. All rights reserved.

Related Documents - T2N614

	<p>Timex Analog Watch User Manual - Features, Settings, and Care</p> <p>Comprehensive user guide for Timex Analog watches, covering setup, features like INDIGLO® Night-Light, water resistance, alarms, perpetual calendar, and maintenance. Available in multiple languages.</p>
	<p>Timex Watch User Manual - Instructions and Guides</p> <p>Comprehensive user manual for Timex watches, providing detailed instructions, setup guides, and troubleshooting tips in multiple languages. Learn how to operate your Timex timepiece effectively.</p>
	<p>Timex Combination Watch User Manual and Instructions</p> <p>Comprehensive user manual for the Timex Combination Analog/Digital Watch, detailing features like INDIGLO night-light, various time modes, chronograph, countdown timer, second time zone, water resistance, and warranty information.</p>
	<p>Timex W217 Analog Watch User Manual and Operating Instructions</p> <p>Comprehensive user manual for the Timex W217 Analog watch, covering setup, water resistance, Indiglo night-light, and detailed instructions for setting time, date, day, moon phase, and alarms.</p>
	<p>Timex W217 Analog Watch User Manual: Features, Setup, and Care</p> <p>Comprehensive user manual for the Timex W217 Analog watch. Learn how to set the time, date, alarms, and understand features like INDIGLO® Night-Light, water resistance, and more. Includes setup guides and maintenance tips.</p>

TIMEX



[Timex Higher-Function Analog Watch User Guide](#)

Explore the features and operation of Timex Higher-Function Analog watches with this comprehensive user guide. Learn about time setting, alarms, chronograph functions, Indiglo Night-Light, water resistance, and more. Available in multiple languages.