

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [iBall](#) /
- > [iBall Dhwani 5.1 Multimedia Speaker User Manual](#)

iBall Dhwani 5.1

iBall Dhwani 5.1 Multimedia Speaker User Manual

Model: Dhwani 5.1

[Introduction](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#)
[Warranty & Support](#)

1. INTRODUCTION

The iBall Dhwani 5.1 Multimedia Speaker system is designed to provide a rich and immersive audio experience. Featuring a 5.1 channel configuration with a powerful subwoofer and four satellite speakers, this system delivers surround sound quality for various multimedia applications. Its wooden cabinet construction enhances sound depth and clarity. The system offers versatile connectivity options including USB, SD/MMC card slots, AUX (2.1CH Stereo), and 5.1 channel input, along with a built-in FM radio.



Figure 1: iBall Dhwani 5.1 Multimedia Speaker System

2. SETUP INSTRUCTIONS

Follow these steps to set up your iBall Dhwani 5.1 Multimedia Speaker system:

1. **Unpacking:** Carefully remove all components from the packaging. Ensure you have one subwoofer and four satellite speakers.
2. **Speaker Placement:**
 - Place the subwoofer on the floor, preferably near a wall or corner for optimal bass response.
 - Position the four satellite speakers around your listening area. For a true surround sound experience, place two satellites at the front (left and right of your display) and two at the rear (left and right behind your listening position). Ensure wires are not stretched or obstructed.
3. **Connecting Satellite Speakers:** Connect each satellite speaker to the corresponding output ports on the rear of the subwoofer unit. Ensure a secure connection for each speaker.
4. **Connecting Audio Source:**
 - **For 5.1 Channel Input:** Use the provided 5.1 audio cables to connect the subwoofer to your 5.1 channel sound card or DVD player. Match the color-coded plugs to the corresponding jacks (e.g., Front L/R, Rear L/R, Center/Sub).
 - **For AUX (2.1CH Stereo) Input:** Use a 3.5mm stereo audio cable to connect the subwoofer's AUX input to the audio output of your PC, laptop, smartphone, or other audio device.
5. **Power Connection:** Plug the power cord from the subwoofer into a standard AC power outlet.
6. **Initial Power On:** Turn on the power switch located on the subwoofer unit. The system should power on, indicated by an LED light.

3. OPERATING INSTRUCTIONS

This section details how to operate your iBall Dhvani 5.1 speaker system.

3.1 Power On/Off

Locate the power switch on the subwoofer unit. Flip the switch to the 'ON' position to power on the speakers. Flip it to 'OFF' to power down.

3.2 Input Source Selection

Use the 'MODE' button on the front panel of the subwoofer or the remote control to cycle through available input sources:

- **5.1 CH:** For true 5.1 surround sound from compatible devices.
- **AUX (2.1 CH Stereo):** For stereo audio input from PCs, laptops, mobile phones, etc.
- **USB:** For playing audio files from a USB pen drive.
- **SD/MMC:** For playing audio files from an SD or MMC memory card.
- **FM:** For listening to the built-in FM radio.

3.3 Volume Control

Adjust the master volume using the main volume knob on the subwoofer's front panel or the volume buttons on the remote control. Individual channel volume adjustments (e.g., bass, center, surround) may also be available via the remote control.

3.4 USB/SD/MMC Playback

Insert a USB pen drive or an SD/MMC card into the respective slot on the subwoofer. The system will automatically switch to USB/SD mode and begin playing compatible audio files. Use the playback controls (Play/Pause, Next, Previous) on the subwoofer or remote control.

3.5 FM Radio Operation

1. Switch the input mode to 'FM'.
2. Press the 'SCAN' button (if available) to automatically scan and save available FM stations.

3. Use the 'NEXT' and 'PREVIOUS' buttons to navigate through the saved stations.
4. Extend the FM antenna (if applicable) for better reception.

4. MAINTENANCE

Proper care and maintenance will ensure the longevity and optimal performance of your speaker system.

- **Cleaning:** Use a soft, dry cloth to wipe the surfaces of the speakers and subwoofer. Do not use liquid cleaners, aerosols, or abrasive materials, as these can damage the wooden finish and electronic components.
- **Dust Removal:** Regularly dust the speaker grilles and vents to prevent accumulation, which can affect sound quality and internal cooling.
- **Placement:** Avoid placing the speakers in direct sunlight, near heat sources, or in areas with high humidity. Ensure adequate ventilation around the subwoofer.
- **Cable Management:** Ensure all cables are securely connected and not pinched or tangled. Avoid placing heavy objects on cables.
- **Power Off When Not in Use:** For extended periods of inactivity, it is recommended to power off the speaker system and unplug it from the power outlet.

5. TROUBLESHOOTING

If you encounter issues with your iBall Dhvani 5.1 speaker system, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from speakers.	<ul style="list-style-type: none"> • Power is off. • Incorrect input source selected. • Volume is too low or muted. • Audio cables are loose or incorrectly connected. • Audio source device is not playing or has low volume. 	<ul style="list-style-type: none"> • Ensure the power switch is ON. • Press the 'MODE' button to select the correct input (e.g., AUX, 5.1 CH, USB, SD, FM). • Increase the master volume. Check if the audio source device is muted or has low volume. • Check all audio cable connections between the speakers and the audio source. • Verify the audio source device is functioning correctly.
Distorted or unclear sound.	<ul style="list-style-type: none"> • Volume set too high. • Poor audio source quality. • Loose cable connections. • Interference. 	<ul style="list-style-type: none"> • Reduce the volume. • Try a different audio source or file. • Ensure all cables are securely connected. • Move speakers away from other electronic devices that may cause interference.
USB/SD card not playing.	<ul style="list-style-type: none"> • Incorrect input mode. • Unsupported file format. • Corrupted USB/SD card. • Card/drive not inserted correctly. 	<ul style="list-style-type: none"> • Select 'USB' or 'SD' mode. • Ensure audio files are in a supported format (e.g., MP3). • Try a different USB drive or SD card. • Re-insert the USB drive or SD card firmly.
FM radio reception is poor.	<ul style="list-style-type: none"> • Weak signal. • Antenna not extended. 	<ul style="list-style-type: none"> • Extend the FM antenna fully. • Reposition the antenna for better reception. • Perform an auto-scan for stations again.

6. SPECIFICATIONS

Model Name	Dhwani 5.1
Type	Multimedia Speaker System
Channel Configuration	5.1
Total Power Output (RMS)	23 W
Frequency Response (Satellite)	40 to 20000 Hz
Signal-to-Noise Ratio	75 dB
Satellite Driver	3-inch full-range
Connectivity	5.1 Channel Input, AUX (2.1CH Stereo), USB, SD/MMC
Additional Features	Built-in FM Radio, Full Volume Controls, Magnetically Shielded Satellites
Package Dimensions	40.6 x 39.4 x 21 cm
Item Weight	4.46 kg

7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official iBall website. Keep your purchase receipt as proof of purchase for warranty claims.

For technical assistance or service inquiries, please contact iBall customer support through their official channels.

