

[Manuals.plus](#) /

› [Samsonite](#) /

› [Samsonite S'cure Spinner 75/28 10U002 49308 Luggage Instruction Manual](#)

Samsonite 49308-1041

Samsonite S'cure Spinner 75/28 10U002 49308 Luggage Instruction Manual

Model: 49308-1041 | Brand: Samsonite

PRODUCT OVERVIEW

The Samsonite S'cure Spinner 75/28 is a large, durable suitcase designed for extended travel, offering a capacity of 102 liters. Constructed from the revolutionary Flowlite material, this luggage is engineered to be lightweight yet exceptionally resistant. Its design focuses on security, ease of movement, and functional interior organization.

- **Dimensions:** 52 x 31 x 75 cm (29.53 x 20.47 x 12.2 inches)
- **Capacity:** 102 Liters
- **Weight:** 4.6 kg (8.8 pounds)
- **Material:** Flowlite Polypropylene
- **Security:** Integrated 3-point locking system with TSA functionality
- **Mobility:** Double spinner wheels and double tube pull handle
- **Interior:** Functional interior with low cross straps and a zipped divider tray with a large storage pocket

SETUP AND FIRST USE

Setting the Combination Lock

Your Samsonite S'cure Spinner luggage is equipped with an integrated 3-point locking system, including a TSA-compatible combination lock. The lock is preset to 0-0-0 at the factory. To set your personal combination, follow these steps:

1. Ensure the lock is set to the factory preset combination (0-0-0).
2. Locate the reset button (usually a small, recessed button) next to the dials.
3. Using a pen or a pointed object, press and hold the reset button until you hear a click or feel it engage.
4. While holding the reset button, set your desired 3-digit combination by turning the dials.
5. Release the reset button. Your new combination is now set.
6. Test your new combination by scrambling the dials and then entering your set combination to open the lock.

Note: Remember your combination. Samsonite cannot open your lock if you forget the combination.

Your browser does not support the video tag.

Video: How to Reset Your Samsonite Combination Lock. This video demonstrates the process of setting or resetting the combination lock on Samsonite luggage, ensuring your belongings are secure during travel.

OPERATING INSTRUCTIONS

Using the Spinner Wheels

The S'cure Spinner features four double spinner wheels, allowing for effortless 360-degree maneuverability. This design reduces strain on your arm and shoulder, making it easy to navigate through airports and crowded spaces.

- To move the suitcase, simply push it alongside you. The wheels will glide smoothly in any direction.
- For rougher surfaces, you can tilt the suitcase and pull it on two wheels.

Extending and Retracting the Pull Handle

The double tube pull handle is designed for comfort and durability. It can be adjusted to multiple heights to suit your preference.

- To extend the handle, press the button located on the top of the handle and pull upwards.
- To retract the handle, press the button and push downwards until it is fully recessed.

Packing the Interior

The functional interior is designed to maximize packing space and keep your belongings organized.

- Utilize the low cross straps in the main compartment to secure your clothes and prevent shifting during transit.
- The zipped divider tray with a large storage pocket is ideal for separating items, such as shoes, toiletries, or dirty laundry.



Image: Interior view of the Samsonite S'cure Spinner luggage. The image displays the spacious interior with adjustable cross straps on one side and a zipped divider with a pocket on the other, designed for efficient organization.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your Samsonite S'cure Spinner luggage, follow these maintenance guidelines:

- **Cleaning the Exterior:** Wipe the polycarbonate shell with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners or solvents.
- **Cleaning the Interior:** The interior lining can be spot cleaned with a damp cloth and mild detergent. Allow to air dry completely before closing.
- **Wheel Maintenance:** Periodically check the spinner wheels for any debris or hair that might impede their smooth operation. Clean as necessary.
- **Storage:** Store your luggage in a cool, dry place away from direct sunlight when not in use.

TROUBLESHOOTING

If you encounter any issues with your Samsonite S'cure Spinner luggage, consider the following common solutions:

- **Stuck Pull Handle:** Ensure no items are obstructing the handle mechanism inside the lining. Gently pull and push the handle while pressing the release button.
- **Wheels Not Spinning Smoothly:** Check for trapped debris (hair, lint) around the wheel axles. Clean thoroughly. If the issue persists, the wheels may require professional servicing.
- **Combination Lock Issues:** Double-check that you are entering the correct combination. If you have forgotten your combination, unfortunately, Samsonite cannot assist in opening it without potentially damaging the lock. It is crucial to remember your set combination.

SPECIFICATIONS

Product Dimensions	29.53 x 20.47 x 12.2 inches (75 x 52 x 31 cm)
Item Weight	8.8 pounds (4.0 kg)
Capacity	102 Liters
Material	Flowlite Polypropylene
Color	Black
Model Number	49308-1041
Manufacturer	Samsonite

WARRANTY AND SUPPORT

Samsonite products are known for their quality and durability. For specific warranty information and support, it is recommended to contact Samsonite directly.

- For warranty claims or replacement parts, especially if purchased outside the US, it is advised to contact Samsonite UK or the relevant regional Samsonite customer service.
- Protection plans may be available for purchase separately to cover accidental damage or extended coverage.

Visit the official [Samsonite Store on Amazon](#) for additional product information and support resources.