

Naxa NPD-703

Naxa NPD-703 7-Inch Portable DVD Player User Manual

Model: NPD-703



1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Naxa NPD-703 7-Inch Portable DVD Player. Please read this manual thoroughly before using the device and retain it for future reference.



Figure 1.1: Naxa NPD-703 Portable DVD Player

The Naxa NPD-703 is a versatile portable entertainment device featuring a 7-inch TFT LCD swivel screen, capable of playing DVDs, CDs, and digital media from USB flash drives and SD/MMC cards. Its compact design and rechargeable battery make it ideal for on-the-go use.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package. If any items are missing or damaged, please contact your retailer.

- Naxa NPD-703 Portable DVD Player
- Remote Control
- AC Power Adapter
- Car Power Adapter (DC 12V)
- Audio/Video (AV) Cable
- Earphones



Figure 2.1: Player with Remote Control

3. PRODUCT OVERVIEW

3.1 Top Panel Controls



7" TFT LCD Swivel Screen Portable DVD Player

with USB/Card /MMC Inputs



Figure 3.1: Top Panel Controls

1. **POWER Button:** Press to turn the unit on or off.
2. **MENU Button:** Access the DVD menu during playback.
3. **SETUP Button:** Enter the system setup menu.
4. **MODE Button:** Switch between DVD, USB, and SD/MMC modes.
5. **PLAY/PAUSE Button:** Start or pause playback.
6. **STOP Button:** Stop playback.
7. **PREV/NEXT Buttons:** Skip to the previous or next track/chapter.
8. **VOL-/VOL+ Buttons:** Adjust the volume level.
9. **Directional Buttons (Up/Down/Left/Right) & ENTER:** Navigate menus and confirm selections.

3.2 Side Panel Ports



Figure 3.2: Side Panel Ports

1. **DC IN 9-12V:** Power input for AC adapter or car adapter.
2. **AV OUT:** Audio/Video output to connect to an external display or TV.
3. **AV IN:** Audio/Video input to connect external devices.
4. **EARPHONE Jack:** 3.5mm jack for headphones.
5. **USB Port:** Connect USB flash drives for media playback.
6. **SD/MMC Card Slot:** Insert SD or MMC memory cards for media playback.

4. SETUP

4.1 Charging the Battery

Before first use, fully charge the internal rechargeable battery. Connect the AC power adapter to the DC IN port on the player and plug the other end into a standard wall outlet. The charging indicator light will illuminate. Charging typically takes several hours. The indicator light will change or turn off once fully charged.

4.2 Powering On/Off

Press the **POWER** button on the unit or the remote control to turn the player on. Press and hold the **POWER** button for a few seconds to turn it off.

4.3 Swivel Screen Adjustment

The screen can swivel up to 180 degrees and fold flat against the base, allowing for various viewing angles. Gently

rotate the screen to your desired position. Avoid excessive force.

5. OPERATING INSTRUCTIONS

5.1 Playing a DVD/CD

1. Open the disc cover by gently lifting it.
2. Place a DVD or CD onto the disc spindle with the label side facing up. Gently press the disc down until it clicks into place.
3. Close the disc cover.
4. Ensure the player is in DVD mode (press **MODE** if necessary).
5. The disc should begin playing automatically. If not, press the **PLAY/PAUSE** button.

5.2 Playing Media from USB/SD/MMC

1. Insert a USB flash drive into the USB port or an SD/MMC card into the card slot.
2. Press the **MODE** button repeatedly until USB or CARD mode is selected.
3. Use the directional buttons and **ENTER** to navigate through your files (MP3, MPEG-4, JPEG).
4. Select the desired file and press **ENTER** or **PLAY/PAUSE** to begin playback.

5.3 Basic Playback Controls

- **PLAY/PAUSE:** Press once to pause, press again to resume.
- **STOP:** Stops playback. Press **PLAY** to resume from the beginning of the disc/file.
- **PREV/NEXT:** Skips to the previous or next chapter/track.
- **VOL-/VOL+:** Adjusts the audio output level.

5.4 Using the Remote Control

Point the remote control directly at the infrared sensor on the front of the DVD player. Ensure there are no obstructions between the remote and the player. The remote provides full control over all player functions, including menu navigation, playback, and setup options.

6. BATTERY INFORMATION

The Naxa NPD-703 features a built-in rechargeable battery that provides up to 2 hours of continuous playback on a full charge. Battery life may vary depending on usage, volume level, and screen brightness. To maximize battery life, reduce screen brightness and volume when possible.

7. MAINTENANCE

7.1 Cleaning the Unit

Wipe the player's exterior with a soft, dry cloth. For stubborn marks, slightly dampen the cloth with water. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.

7.2 Cleaning Discs

Wipe discs from the center outwards with a soft, lint-free cloth. Do not use solvents or abrasive cleaners. Avoid touching the playback surface of the disc.

7.3 Storage

When not in use for extended periods, store the player in a cool, dry place away from direct sunlight and extreme temperatures. Remove any discs, USB drives, or SD cards before storage.

8. TROUBLESHOOTING

If you encounter issues with your Naxa NPD-703, refer to the following common problems and solutions:











Problem	Possible Solution
No power	Ensure the AC adapter is securely connected and plugged into a working outlet. Check if the battery is charged.
"No Disc" message	Verify the disc is inserted correctly with the label side up. Clean the disc if it is dirty or scratched. Try a different disc.
No sound	Increase the volume. Check if headphones are connected. Ensure the AV cable is properly connected if using external speakers.
Picture distorted or no picture	Adjust the screen angle. If connected to an external display, check AV cable connections.
Remote control not working	Ensure there are no obstructions. Replace the remote control batteries. Point the remote directly at the IR sensor.
Cannot read USB/SD card	Ensure the device is in the correct mode (USB/CARD). Check that the file formats are supported (MP3, MPEG-4, JPEG). Reformat the USB/SD card if necessary (FAT32).


9. SPECIFICATIONS

Feature	Description
Model	NPD-703
Screen Size	7 Inches
Display Type	TFT LCD
Swivel Screen	Yes, 180-degree rotation
Supported Media	DVD, CD, CD-R, DVD-R
Digital Media Support	USB Flash Drives, SD/MMC Cards (max 32GB)
Supported Formats	MP3 (audio), MPEG-4 (video), JPEG (photos)
Battery Life	Up to 2 hours (rechargeable)
Connectivity	USB Port, SD/MMC Card Slot, AV In, AV Out, Earphone Jack, DC In
Product Dimensions	8.9 x 6.5 x 1.5 inches
Item Weight	1.6 pounds

Feature	Description
Color	Shiny Black
<div> <div></div> <div></div> </div>	
<div>© 2023 Naxa Electronics. All rights reserved.</div>	

Related Documents - NPD-703

<div> <div>  <div>7" Bluetooth® DVD Boombox with TV</div> </div> <div>  <div>Instruction Manual</div> </div> </div>	<div> Naxa NDL-287 7" Bluetooth DVD Boombox with TV Instruction Manual </div> <div>User manual for the Naxa NDL-287 7" Bluetooth DVD Boombox with TV, detailing its features, setup, operation, and troubleshooting for a comprehensive portable entertainment experience.</div>
<div> <div>  <div>NF-1000</div> </div> <div> <div>USER'S MANUAL</div> <div>10" Digital Photo Frame</div> </div> </div>	<div> Naxa NF-1000 10-Inch Digital Photo Frame User Manual </div> <div>Comprehensive user manual for the Naxa NF-1000 10-inch Digital Photo Frame, covering setup, operation, features, technical specifications, and troubleshooting.</div>
<div> <div>  <div>NF-503</div> </div> <div> <div>USER'S MANUAL</div> <div>7" Digital Photo Frame</div> </div> </div>	<div> Naxa NF-503 7-Inch Digital Photo Frame User Manual </div> <div>User manual for the Naxa NF-503 7-inch Digital Photo Frame, covering its features, setup, operating instructions, and troubleshooting guide.</div>
<div> <div>  <div>DIGITAL ALARM CLOCK RADIO WITH CD PLAYER</div> </div> <div>  <div>Instruction Manual</div> </div> </div>	<div> Naxa NRC-176 Digital Alarm Clock Radio with CD Player - Instruction Manual </div> <div>Comprehensive instruction manual for the Naxa NRC-176 Digital Alarm Clock Radio with CD Player, covering setup, operation, safety precautions, and specifications. Learn how to set the clock, alarms, use the CD player, radio, and sleep timer.</div>
<div> <div>  <div>10.1" Core Tablet with Android® 11, Bluetooth®, Keyboard & Webcam</div> </div> <div>  <div>Instruction Manual</div> </div> </div>	<div> Naxa NID-1070 Core Tablet User Manual </div> <div>Comprehensive user manual for the Naxa NID-1070 10.1-inch Core Tablet with Android 11 and Bluetooth Keyboard. Get detailed instructions on setup, features, connecting to Wi-Fi and Bluetooth, using applications, and technical specifications. Includes troubleshooting and support information.</div>
<div> <div>  <div>Portable CD Player with AM/FM Stereo Radio</div> </div> <div>  <div>Instruction Manual</div> </div> </div>	<div> Naxa NPB-254 Portable CD Player with AM/FM Stereo Radio - Instruction Manual </div> <div>Comprehensive instruction manual for the Naxa NPB-254 portable CD player. Learn how to use its CD player, AM/FM radio, connect external devices via AUX, and important safety information.</div>



[\[pdf\]](#) User Manual

Provided by ManualsAndMore Download User Manual Naxa NPD 703 Instruction NPD703 manualsandmore |||

...

lang: **score:43** filesize: 6.44 M page_count: 14 document date: 2019-07-23



[\[pdf\]](#) User Manual

Untitled NPD 703 Spanish Manual naxa manuals |||

...

lang: **score:33** filesize: 15.14 M page_count: 14 document date: 2013-04-10



[\[pdf\]](#) Specifications Dimension Guide Accessories

NPD 703 Sales sheet low res Naxa FEATURES * Features specifications measurements and weights may be subject to change without prior notice For more detailed information about this product including naxa 2021 03 |||

7 TFT LCD Swivel Screen Portable DVD Player Model:**NPD-703** 180° SWIVEL Rechargeable Battery USB Media Card LARGE 7.0 LCD SCREEN FEATURES: A 7 portable DVD player and digital entertainment solution Enjoy all of your DVD movies, anywhere Play digital media from USB ash drives and SD cards m...

lang:en **score:31** filesize: 259.44 K page_count: 1 document date: 2021-04-28



[\[pdf\]](#) Specifications Dimension Guide Accessories

NPD 703 Sales sheet 7 TFT LCD Swivel Screen Portable DVD Player Model 180° SWIVEL Rechargeable Battery USB Media Card LARGE 0 SCREEN FEATURES A naxa 2021 03

7 TFT LCD Swivel Screen Portable DVD Player Model:**NPD-703** 180° SWIVEL Rechargeable Battery USB Media Card LARGE 7.0 LCD SCREEN FEATURES: A 7 portable DVD player and digital entertainment solution Enjoy all of your DVD movies, anywhere Play digital media from USB ash drives and SD cards m...

lang:en **score:30** filesize: 1.41 M page_count: 1 document date: 2021-03-02



[pdf] Specifications Dimension Guide Accessories

NPD 703 Sales sheet low res 7 TFT LCD Swivel Screen Portable DVD Player Model LARGE 0 SCREEN

Rechargeable Battery USB FEATURES A portable player and View 1 naxa 2021 03 |||

USB 180 SWIVEL Media Card 7 TFT LCD Swivel Screen Portable DVD Player

Model: **NPD-703** LARGE 7.0 LCD SCREEN Rechargeable Battery FEATURES: A 7 portable DVD player and digital entertainment solution Enjoy all of your DVD movies, anywhere Play digital media from USB ash drives and SD cards ma...

lang:en score:29 filesize: 1.39 M page_count: 1 document date: 2021-10-14



[pdf] Specifications Dimension Guide Catalog

NPD 703 naxa 80 catalog index sale ID 424

7 TFT LCD Swivel Screen Portable DVD Player with USB/SD/MMC Inputs **NPD-703**

Features and Specification Product Details 7 Widescreen LCD Display Top Loading DVD Player Up to 180 Degrees Swivel Screen Built-in SD/MMC Card Slot Built-in USB Input Built-in Speakers Swivel Design LCD Display For Mult...

lang:en score:28 filesize: 128.33 K page_count: 1 document date: 2013-02-23




[pdf] User Manual


User Manual Untitled If you cannot wipe off the dust with a soft cloth disc lightly slightly moistened and finish dry Do not use any type of solvent CLASS 1 LASER PRODUCT THIS IS A USE OF SETUP setup button press once to enter into DVD system function once NPD 703 English naxa manuals

...

lang:en score:20 filesize: 15.1 M page_count: 14 document date: 2013-04-10



PROGRESSIVE SCAN



[\[pdf\]](#) Catalog

Naxa 2016 catalog web naxa

Corporate Mission Naxa Electronics designs and distributes personal electronics that entertain and ... ox Gift box Gift box Gift box 31 / 2016 Portable DVD Players LARGE 7.0 LCD SCREEN 180 SWIVEL **NPD-703** 7 TFT LCD Swivel Screen Portable DVD Player with USB/SD/MMC Inputs A 7 portable DVD play...

lang:en score:20 filesize: 18.17 M page_count: 118 document date: 2016-01-12



[\[pdf\]](#) Catalog

FINAL NAXA CATALOG 2015 Ind Pages w Cover naxa

Corporate Mission Naxa Electronics designs and distributes personal electronics that entertain and ... 27 / 2015 Portable DVD Players LARGE 7.0 LCD SCREEN 180 SWIVEL LARGE 9.0 LCD SCREEN 180 SWIVEL **NPD-703** 7 TFT LCD Swivel Screen Portable DVD Player with USB/SD/MMC Inputs A 7 portable DVD play...

lang:en score:20 filesize: 25.78 M page_count: 101 document date: 2015-02-03




[\[pdf\]](#) User Manual Accessories Catalog

2021 General Catalog Naxa Electronics Core™ Tablets Untitled Accessories included UL approved power adapter User manual 13 3 HD IPS Screen Core™ Core™ tablets from Naxa® are purposely and Sound Bars Audio 62 Portable Bluetooth® Speakers High Quad Processor turns your tablet into a multimedia powerhouse Cortex A9 1 2GHz Mali 400 GB DDR3 Rechargeable battery 5000 mAh AC 4 Hours* USB cable 2 naxa 02 Page not found Along with product innovation is dedicated to providing unequalled service Our management team staff do everything within their satisfy |||

CORPORATE HEADQUARTERS NAXAELECTRONICS,INC. 2320E.49thStreet Vernon,California90058 Tel: 323 583 ... control, A/V cable, User manual 2021/49 Portable DVD Players LARGE 7.0 LCD SCREEN 180 SWIVEL **NPD-703** 7 TFT LCD Swivel Screen Portable DVD Player A 7 portable DVD player and digital entertain...

lang:en score:20 filesize: 34.86 M page_count: 73 document date: 0000-00-00



[\[pdf\]](#) Catalog

40201A 68P Copy kamran 2012 Naxa Catalog Gen naxa 80


2012 CONSUMER ELECTRONICS About Us Mission Statement CORPORATE MISSION Our corporate mission is ... nction n Clock Calendar 1 NAXA 2012 / 20 Portable DVD Players with LCD Screen 180 SWIVEL 1 **NPD-703** 7 TFT LCD Swivel Screen Portable DVD Player with USB/SD/MMC Inputs n 7 Widescreen LCD Di... lang:en **score:19** filesize: 8.11 M page_count: 68 document date: 2012-01-26



[\[pdf\]](#) Catalog

2023 Naxa Catalog General Support Electronics naxa 01 |||

Corporate Mission Naxa Electronics designs and distributes consumer electronics that entertain and ... WUOR SRZHUDGDSWHU FDUFRUG 9FDEOH Media Card 50 / 2023 3RUWDEOH 9 3OD HUV LARGE 7.0 LCD SCREEN **NPD-703** 7 7/ 6ZLYHO6FUHHQ3RUWDEOH 9 3OD HU SRUWDEOH 9 SOD HUDQGGLJLWDOHQWHUWDLQPHQWVROXWLRQ QMR... lang:en **score:19** filesize: 84.61 M page_count: 67 document date: 2023-01-04



[\[pdf\]](#) Catalog

2020 General Catalog Page not found Naxa Electronics Final naxa catalog |||

Corporate Mission Naxa Electronics designs and distributes consumer electronics that entertain and ... Yes Yes Yes Yes Yes Yes 40 / 2020 Portable DVD Players LARGE 7.0 LCD SCREEN 180 SWIVEL **NPD-703** 7 TFT LCD Swivel Screen Portable DVD Player with USB/SD/MMC Inputs A 7 portable DVD play... lang:en **score:18** filesize: 85.99 M page_count: 73 document date: 2019-12-20



[\[pdf\]](#) Catalog

2021 Naxa Catalog 1 18 21 FINAL LATEST naxa catalog

CORPORATE HEADQUARTERS NAXAELECTRONICS,INC. 2320E.49thStreet Vernon,California90058 Tel: 323 583 ... control, A/V cable, User manual 2020/ 49 Portable DVD Players LARGE 7.0 LCD SCREEN 180 SWIVEL **NPD-703** 7 TFT LCD Swivel Screen Portable DVD Player with USB/SD/MMC Inputs A 7 portable DVD play... lang:en **score:18** filesize: 285.31 M page_count: 73 document date: 2021-01-18



[\[pdf\]](#) Catalog

Naxa Car Stereos Catalog car stereos single din double head units audio systems cd players dvd bluetooth navigation am fm CARiD naxa 2017 catalog images carid info |||

Corporate Mission Naxa Electronics designs and distributes consumer electronics that entertain and ... ox Gift box Gift box Gift box 36 / 2017 Portable DVD Players LARGE 7.0 LCD SCREEN 180 SWIVEL **NPD-703** 7 TFT LCD Swivel Screen Portable DVD Player with USB/SD/MMC Inputs A 7 portable DVD play... lang:en **score:18** filesize: 59.35 M page_count: 137 document date: 2017-10-03

