

[manuals.plus](#) /› [B. toys](#) /› [B. toys Hellophone Red - Instruction Manual](#)

B. toys BX1177Z

B. toys Hellophone Red - Instruction Manual

Model: BX1177Z

INTRODUCTION

The B. toys Hellophone Red is a realistic-looking toy cellphone designed for toddlers aged 18 months and over. It features engaging audio, bright lights, song playback, and a voice recorder, promoting early learning and imaginative play.

This manual provides detailed instructions on how to set up, operate, and maintain your Hellophone to ensure a safe and enjoyable experience.

WHAT'S IN THE BOX

- 1 x Hellophone Red Toy Cellphone
- 1 x Wrist Strap
- 3 x AAA Batteries (pre-installed)



Hellophone - Red

Toy Cellphone



Image: The Hellophone Red toy cellphone, showing its vibrant red color and flip design, with a wrist strap attached. The image also indicates an 18+ months age recommendation.

SETUP

Battery Installation (Pre-installed)

The Hellophone comes with 3 AAA batteries pre-installed. If replacement is needed:

1. Locate the battery compartment on the back of the phone.
2. Using a small Phillips head screwdriver (not included), unscrew the battery compartment cover.
3. Remove the old batteries and insert 3 new AAA batteries, ensuring correct polarity (+/-).
4. Replace the cover and secure it with the screw.

Safety Note: Always ensure the battery compartment is securely closed to prevent small parts from becoming a choking hazard. Adult supervision is recommended during battery replacement.

OPERATING INSTRUCTIONS

Turning On/Off

Simply open the flip phone to activate it. Close the flip phone to turn it off and conserve battery life.

Using the Keypad

The Hellophone features a numeric keypad (0-9, *, #) and additional function buttons.

- **Number Buttons (0-9):** Press these buttons to hear corresponding sounds and practice numbers.
- **Star Button (*):** Press the star button to hear pleasant tunes.
- **Pound Button (#):** Press the pound button to hear additional pleasant tunes.



Image: A detailed view of the Hellophone's red keypad, showing the numbered buttons and the illuminated "HELLO" display. This illustrates the interactive elements of the phone.

Voice Recording and Playback

The Hellophone allows you to record and play back short messages.

1. **To Record:** Locate the "record" button on the side of the phone. Press and hold the "record" button while speaking clearly into the microphone. Release the button when finished.
2. **To Playback:** Press the "play" button located on the keypad. The recorded message will play.
3. **Lock Feature:** Use the "lock" switch on the side of the phone to protect your recorded messages from being accidentally overwritten. Slide the switch to the 'lock' position to secure the current recording.



Image: A visual representation highlighting the key interactive features of the Hellophone, including its flip design, light and sound capabilities, and the record playback function.

Pre-recorded Messages

The phone includes 3 pre-recorded messages. Press the button with stars (usually the top-left button on the keypad) to cycle through these messages.

MAINTENANCE

- **Cleaning:** Wipe the Hellophone with a soft, damp cloth. Do not immerse in water.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight when not in use.

- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound or lights	Batteries are dead or incorrectly installed.	Replace batteries with new AAA batteries, ensuring correct polarity.
Recorded message is too quiet or unclear	Microphone too far away or speaking too softly during recording.	Speak loudly and clearly directly into the microphone when recording. Ensure the lock switch is not engaged if trying to re-record.
Phone does not respond to button presses	Phone is off (closed) or batteries are low.	Open the flip phone. Check and replace batteries if necessary.

SPECIFICATIONS

Model Number	BX1177Z
Product Dimensions	2 x 2 x 7.25 inches
Item Weight	5.3 ounces
Recommended Age	18 months - 5 years
Batteries	3 AAA batteries (included)
Manufacturer	Branford Limited
Release Date	August 2, 2023


WARRANTY & SUPPORT


B. toys products are designed for durability and enjoyment. For any questions, concerns, or support needs regarding your Hellophone, please contact B. toys customer service. While specific warranty details are not provided in this manual, please refer to the product packaging or the official B. toys website for the most up-to-date warranty information.

You can visit the official B. toys store for more information and contact options: [B. toys Store on Amazon](#).

© 2024 B. toys. All rights reserved.

Related Documents - BX1177Z

	B. toys Rainbow Doodler LCD Drawing Tablet - Fun Educational Toy Discover the B. toys Rainbow Doodler LCD Drawing Tablet, a fun and educational toy for children. Learn about its features, how to use it, and safety information. Includes tablet, double-tip pen, and stamps.
---	--

	<p><u>Rally Ripster Remote Control Car - B. toys - Model BX2425Z/BX2485Z - User Manual & Instructions</u></p> <p>Official user manual and product information for the B. toys Rally Ripster Remote Control Car (Model BX2425Z/BX2485Z). Learn about features, operation, battery installation, safety, and compliance.</p>
	<p><u>Fisher-Price Linkimals Peacock (HMF12) - User Guide and Instructions</u></p> <p>Comprehensive guide for the Fisher-Price Linkimals Peacock (HMF12) toy, covering features, battery replacement, safety instructions, cleaning, and syncing with other Linkimals toys. Includes contact information and compliance details.</p>
	<p><u>VTech Splash & Play Octopus Instruction Manual - Bath Toy Guide</u></p> <p>Comprehensive instruction manual for the VTech Splash & Play Octopus bath toy, covering setup, features, activities, care, troubleshooting, and safety information.</p>
	<p>מדריך למשתמש: Philips VoiceTracer DVT1160</p> <p>למד כיצד להקליט. מדריך מוקף למשתמש עבור מקליט הקול הדיגיטלי. להנל קבצים ולהשתמש בכל תכונות המכשיר.</p>
	<p><u>LYY10 Baby Phone Toy: User Guide and Features</u></p> <p>User manual for the LYY10 Baby Phone Toy, detailing its interactive features, button functions, battery installation, and important safety precautions for infant use.</p>