

[Manuals.plus](#) /

› [PRECISE](#) /

› Precise SP-009 Stainless Belly Putter User Manual

PRECISE Os-B-009

Precise SP-009 Stainless Belly Putter User Manual

MODEL: OS-B-009

Introduction

Thank you for choosing the Precise SP-009 Stainless Belly Putter. This manual provides essential information for the proper setup, operation, maintenance, and care of your new golf club. Adhering to these guidelines will help ensure optimal performance and longevity of your putter.





This image displays the Precision SP-009 Stainless Belly Putter. It features a black and red Winn grip, a silver stainless steel shaft, and a putter head designed for belly putting. A bonus headcover is included with the putter for protection.

Setup

Upon receiving your Precision SP-009 Belly Putter, please follow these steps for initial setup:

1. **Unboxing:** Carefully remove the putter and its bonus headcover from the packaging. Inspect the club for any visible damage during transit.
2. **Headcover Application:** Place the provided headcover over the putter head when not in use or during transport. This protects the club face and finish from scratches and dings.
3. **Grip Inspection:** The putter comes equipped with a 21-inch Deluxe Belly Putter Grip. Ensure the grip is securely attached and free from any tears or slippage. A proper grip is crucial for consistent putting.

Operating

The Precision SP-009 Belly Putter is designed to help reduce putting strokes by providing a stable putting stroke. Here are general guidelines for its operation:

- **Belly Putter Technique:** A belly putter is typically anchored against the stomach or sternum, creating a pendulum-like stroke. This anchoring point helps stabilize the putter and minimize wrist movement.
- **Grip:** Hold the 21-inch Deluxe Belly Putter Grip with both hands, ensuring a comfortable and firm hold. The extended length allows for the upper part of the grip to be positioned against your body.
- **Stance and Alignment:** Position yourself over the ball with your eyes directly above or slightly inside the ball. Utilize the easy-to-use ball alignment feature on the putter head to aim accurately towards your target.
- **Putting Stroke:** Execute a smooth, controlled pendulum stroke, allowing the putter head to swing back and through along your intended line. Focus on maintaining a consistent tempo and follow-through.

Maintenance

Proper maintenance will extend the life and performance of your putter:

- **Cleaning the Putter Head:** After each round, wipe the stainless steel putter head with a soft, damp cloth to remove dirt, grass, and debris. For stubborn marks, a mild soap solution can be used, followed by thorough drying.
- **Grip Care:** The synthetic rubber grip can accumulate oils and dirt, leading to slippage. Clean the grip periodically with a damp cloth and mild soap, then rinse and allow it to air dry completely. Avoid harsh chemicals.
- **Storage:** Always store your putter with the bonus headcover on to protect the club head. Store in a dry environment, away from extreme temperatures and humidity, to prevent material degradation.

Troubleshooting

If you encounter issues with your putting performance, consider the following general troubleshooting tips:

- **Inconsistent Putting:** Review your grip, stance, and alignment. Ensure the putter is anchored correctly against your body. Practice drills focusing on consistent stroke length and tempo.
- **Distance Control Issues:** Practice putting from various distances to develop a feel for the required stroke length. Focus on a smooth, accelerating stroke rather than a jerky one.
- **Putter Feel:** If the putter feels too light or heavy, consider if it matches your preferred putting style. The SP-009 is designed with a specific weight for stability.
- **Seek Professional Advice:** For persistent technique issues, consulting a certified golf instructor can provide personalized guidance and drills to improve your putting.

Specifications

Key specifications for the Precise SP-009 Stainless Belly Putter:

Feature	Detail
Model Name	Os-B-009
Size	42" LONG BELLY PUTTER
Color	Black/Red
Hand Orientation	Right
Golf Club Flex	Regular

Golf Club Loft	3 Degrees
Material (Head)	Stainless Steel
Material (Grip)	Synthetic Rubber
Material (Shaft)	Steel
Item Weight	1.16 Kilograms
Product Dimensions (LxWxH)	6"L x 4"W x 44"H
UPC	092115100096
Included Components	Headcover

Warranty

The Precise SP-009 Stainless Belly Putter is covered by a **1-year manufacturer defect warranty**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, abuse, accidents, or unauthorized modifications. Please retain your proof of purchase for warranty claims.

Support

For further assistance, technical support, or inquiries regarding your Precise SP-009 Stainless Belly Putter, please refer to the official PRECISE brand website or contact an authorized dealer. Always ensure you are using genuine parts and accessories for optimal performance and to maintain warranty validity.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0081CQO22>

More documents and user manuals: <https://manuals.plus/>