

Wahl 79524-5201

Wahl Clipper USA Deluxe Corded Chrome Pro Hair and Trimming Kit

Model: 79524-5201

INTRODUCTION

This manual provides instructions for the safe and effective use of your Wahl Clipper USA Deluxe Corded Chrome Pro Hair and Trimming Kit. Please read all instructions carefully before initial use and retain for future reference.

Important Safety Information

Hair trimming kits can pose safety risks if not used correctly. These risks include electric shocks, fires, and skin irritation. It is crucial to follow safety guidelines to minimize these dangers. Always follow basic precautions when using an electrical appliance. Refer to the insert included with your kit for detailed safety guidelines.

KIT CONTENTS

Your Wahl Deluxe Corded Chrome Pro kit includes the following items:

- Corded Hair Clipper
- Cordless Battery Mini Trimmer (AA battery required, not included)
- 14 Attachment Combs (ranging from 1/16" to 1" cutting lengths)
- Blade Oil
- Soft Storage Case
- Trimmer Blade Guard
- Cleaning Brush
- Barber Comb
- Styling Comb
- Styling Shears



Image: A detailed layout of all 25 pieces included in the kit, featuring the main clipper, mini trimmer, multiple guide combs, scissors, combs, cleaning tools, and storage case.

KEY FEATURES

- **Heavy Duty Motor:** The powerful motor provides efficient cutting for thick hair. A strong audible hum is normal during operation.
- **Self-Sharpening Blades:** Precision blades maintain sharpness over time, ensuring consistent cutting performance.
- **Adjustable Taper Lever:** Easily adjust the closeness of your cut between guide comb lengths for blending and fading.
- **Matching Trimmer:** A cordless mini trimmer is included for precise detailing around the neckline, sideburns, and ears.




**Self-Sharpening
Precision T-Blade**

Self-sharpening precision ground blades cut through all hair types & stays sharper longer. The T-blade is for precision cutting.

Soft Touch Grip

Taper Lever
Adjusts for blending and customized cutting lengths

Image: A close-up view of the corded clipper highlighting the self-sharpening precision T-blade, soft-touch grip, and the adjustable taper lever for customized cutting lengths.



**ULTRA POWER
HEAVY DUTY MOTOR**
Long-lasting motor
delivers exceptional
power for no-snag
cutting

Matching Trimmer
Cleans up neckline,
sideburns, and trimming
around the ears



Image: An X-ray view illustrating the ultra-power heavy-duty motor inside the main clipper, alongside the matching chrome trimmer for detailing.

SETUP

1. **Initial Inspection:** Unpack all components and ensure no items are missing or damaged.
2. **Oiling Blades:** Before first use, and periodically thereafter, apply a few drops of the included blade oil to the clipper and trimmer blades. This ensures smooth operation and extends blade life.
3. **Attaching Guide Combs:** Select the desired attachment comb based on the hair length required. Snap the comb securely onto the clipper or trimmer blade.
4. **Blade Alignment:** Proper blade alignment is crucial for safe and effective cutting. Refer to the video below for detailed instructions on how to align your clipper blades.

Your browser does not support the video tag.

Video: This instructional video from Wahl Clipper Corp demonstrates the correct procedure for aligning the blades on your clipper, ensuring optimal cutting performance and safety.

OPERATING INSTRUCTIONS

1. **Preparation:** Ensure hair is clean, dry, and combed to remove tangles. Place the cape around the user's neck to catch cut hair.
2. **Selecting Length:** Choose the appropriate attachment comb for the desired hair length. For first-time users, start with a longer comb to avoid cutting too short.
3. **Using the Clipper:** Hold the clipper with the blades pointing upwards. Begin cutting from the bottom of the head, moving upwards against the direction of hair growth. Use smooth, overlapping strokes.
4. **Adjustable Taper Lever:** Use the taper lever to fine-tune the cutting length between comb sizes, allowing for seamless blending and fading. Move the lever up for a closer cut and down for a longer cut.
5. **Using the Trimmer:** The cordless mini trimmer is ideal for precise edging around the neckline, sideburns, and ears. Use without an attachment comb for the closest trim.
6. **Styling Shears:** Use the styling shears for trimming longer hair on top of the head or for blending sections that require more control than the clipper.



Image: A man demonstrating the use of the corded clipper for a self-haircut, illustrating proper grip and movement.

MAINTENANCE

1. **Cleaning Blades:** After each use, remove any hair clippings from the blades using the provided cleaning brush.
2. **Oiling Blades:** To maintain optimal performance and longevity, oil the clipper and trimmer blades every few haircuts with the included blade oil.
3. **Storage:** Store the clipper and all accessories in the soft storage case provided to protect them from damage and keep them organized.

TROUBLESHOOTING

- **Loud Motor Hum:** The heavy-duty motor of the corded clipper is designed for powerful cutting and may produce a strong audible hum. This is normal for its operation.
- **Blades Snagging Hair:** Ensure blades are clean and properly oiled. Check blade alignment and adjust if necessary (refer to the blade alignment video in the Setup section).
- **Cordless Trimmer Not Working:** Verify that fresh AA batteries are correctly installed in the cordless mini trimmer.

SPECIFICATIONS

Feature	Detail
Brand	Wahl
Model Name	Chrome Pro
Item Model Number	79524-5201
Product Dimensions	11.5 x 4.5 x 9.5 inches
Item Weight	1 Pound
Power Source (Clipper)	Corded (for US outlets only)
Power Source (Trimmer)	Battery (1 AA battery required, not included)
Blades	Self-sharpening precision blades

WARRANTY & SUPPORT

The Wahl Clipper USA Deluxe Corded Chrome Pro kit typically comes with a 5-year limited warranty. For specific warranty details, claims, or product support, please refer to the warranty information provided in the instruction booklet included with your kit or visit the official Wahl website.

For additional tutorials and support, please visit wahlusa.com.