GROHE 31255000

GROHE Eurocube Kitchen Faucet Model 31255000 Instruction Manual

Your guide to installation, operation, and maintenance.

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your GROHE Eurocube Kitchen Faucet, Model 31255000. Designed with a clean aesthetic of straight lines and square shapes, this faucet features a durable GROHE StarLight chrome finish and GROHE SilkMove technology for smooth control. Please read these instructions carefully before proceeding with installation or use to ensure proper function and longevity of the product.

Figure 1: The GROHE Eurocube Kitchen Faucet, Model 31255000, showcasing its distinctive cuboid design and chrome finish in a kitchen environment.

SETUP AND INSTALLATION

The GROHE Eurocube Kitchen Faucet is designed for single-hole installation and includes a rapid installation system for ease of setup. Ensure all necessary components are present before beginning.

Included Components:

- 1 x GROHE Eurocube Kitchen Faucet
- Flexible connection hoses
- Mounting hardware

Installation Steps:

1. **Prepare the Mounting Surface:** Ensure the sink or countertop has a single mounting hole with a diameter of approximately 34mm. The maximum thickness of the mounting surface should not exceed 60mm.
2. **Connect Hoses:** Attach the flexible connection hoses to the faucet base. Ensure a secure, watertight connection.
3. **Mount the Faucet:** Insert the faucet into the mounting hole. From underneath the sink, secure the faucet using the provided mounting hardware. Tighten firmly but do not overtighten.
4. **Connect to Water Supply:** Connect the flexible hoses to your hot and cold water supply lines. Ensure the connections are tight to prevent leaks.
5. **Check for Leaks:** Slowly turn on the main water supply and check all connections for any signs of leakage.

A minimum recommended water pressure of 1.0 bar is required for optimal performance.

Figure 2: Technical drawing illustrating key dimensions and connection points for the GROHE Eurocube Kitchen Faucet. Note the spout height, handle movement, and connection specifications.

OPERATING INSTRUCTIONS

Your GROHE Eurocube Kitchen Faucet is designed for intuitive and comfortable use.

Water Flow and Temperature Control:

- The single lever handle controls both water flow and temperature.
- **Flow Control:** Lift the lever upwards to increase water flow. Push downwards to decrease or stop the flow.
- **Temperature Control:** Move the lever to the left for hot water and to the right for cold water. The integrated GROHE SilkMove 28 mm ceramic cartridge ensures smooth and precise adjustment.

Spout Functionality:

- The high spout design allows for easy filling and cleaning of large pots and containers.
- The spout features a 360° swivel range, providing full flexibility and convenience for various kitchen tasks, including switching between multiple sink basins if applicable.

Figure 3: The faucet in operation, showing water flowing from the high spout, ideal for various kitchen tasks.

MAINTENANCE AND CARE

To maintain the lustrous appearance and optimal performance of your GROHE Eurocube Kitchen Faucet, follow these simple care instructions:

- **Cleaning the Finish:** The GROHE StarLight chrome finish is highly durable and scratch-resistant. To clean, simply wipe the faucet down with a soft, dry cloth. For more stubborn marks, use a mild soap solution and rinse thoroughly with clean water, then dry immediately with a soft cloth.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, scouring pads, or cleaning agents containing alcohol, ammonia, or phosphoric acid, as these can damage the chrome finish.
- **Aerator Maintenance:** Periodically unscrew and clean the aerator (the mesh screen at the end of the spout) to remove any mineral deposits or debris that may affect water flow.

TROUBLESHOOTING

If you encounter any issues with your GROHE Eurocube Kitchen Faucet, refer to the following common solutions:

- **Low Water Flow:**

    - Check if the main water supply valves are fully open.
    - Clean the aerator for any blockages (refer to Maintenance section).
    - Verify that the minimum recommended pressure of 1.0 bar is met.

- **Leaking from Faucet Base:**

    - Ensure all connections to the water supply lines are securely tightened.
    - Check the mounting hardware for tightness.

- **Difficulty Adjusting Temperature/Flow:**

    - The GROHE SilkMove cartridge is designed for smooth operation. If stiffness occurs, ensure no external obstructions are present. If the issue persists, professional assistance may be required.

For issues not resolved by these steps, please contact customer support.

PRODUCT SPECIFICATIONS

Brand:	GROHE
Model Number:	31255000
Series ID:	Eurocube
Mounting Type:	Single Hole
Finish Type:	Chrome (GROHE StarLight)
Material:	Metal (Handle Material: Ceramic)
Spout Design:	High-arc
Swivel Area:	360°
Cartridge:	GROHE SilkMove 28 mm ceramic cartridge
Number of Handles:	1 (Lever)
Item Weight:	2.85 Kilograms
Included Components:	1 Faucet
Minimum Recommended Pressure:	1.0 bar

WARRANTY INFORMATION

The GROHE Eurocube Kitchen Faucet Model 31255000 comes with a **10-year warranty** from the date of invoice. This warranty covers manufacturing defects and ensures the quality and durability of your product. Please retain your purchase invoice as proof of purchase for warranty claims.

Customer Support

For any questions, installation guidance, or support regarding your GROHE Eurocube Kitchen Faucet, please contact our customer service team:

Toll-Free Installation Guidance: 1800 102 4475

You can also visit the official GROHE store for more product information and resources: GROHE Store on Amazon.in