

[Manuals.plus](#) /

› [CLEANmaxx](#) /

› CLEANmaxx Easymaxx Carpet Shampoo 500 ml User Manual

CLEANmaxx 01067

CLEANmaxx Easymaxx Carpet Shampoo 500 ml User Manual

Model: 01067

PRODUCT OVERVIEW

This special carpet shampoo is ideal for cleaning carpets with CLEANmaxx carpet cleaners. It is highly effective and provides your carpet with thorough cleanliness and a pleasant fresh scent. It is designed to remove even severe dirt and features a special stain formula and color refreshing properties. Please note: This product is not suitable for silk, coconut, and sisal materials.



Image: Front view of the Easymaxx Carpet Shampoo 500 ml bottle.

Key Features:

- Suitable for carpets, fitted carpets, rugs, and doormats.
- Features a special stain formula and color refreshing properties.
- Removes even severe dirt.
- Highly productive for effective cleaning.

SAFETY INSTRUCTIONS

Always read the entire label before use. Keep out of reach of children and pets. Avoid contact with eyes and skin. In case of contact, rinse thoroughly with water. If irritation persists, seek medical attention. Do not ingest. If swallowed, do not induce vomiting; seek medical attention immediately and show the product label.

Important Note: This carpet shampoo is *not suitable* for delicate materials such as silk, coconut fiber, or sisal. Always test the product on an inconspicuous area of the carpet first to ensure colorfastness and material compatibility.

Ingredients:

C10-C14 alkyl sulfate, C14-C16 alkyl hydroxy, C14-C16 alkene sulfonic acid salts.

SETUP

1. **Prepare the Carpet:** Before applying the shampoo, thoroughly vacuum the carpet using a standard vacuum cleaner to remove loose dirt and debris.
2. **Prepare the Cleaning Solution:** Refer to your CLEANmaxx carpet cleaner's manual for specific dilution ratios. Generally, fill the carpet cleaner's solution tank with the appropriate amount of clean water and then add the Easymaxx Carpet Shampoo according to the recommended dosage.
3. **Test Area:** Always perform a patch test on an inconspicuous area of the carpet (e.g., under furniture) to check for colorfastness and any adverse reactions before cleaning the entire area. Allow the test area to dry completely before proceeding.



Ideal
für den
CLEANmaxx
Teppich-
reiniger

Image: A red circular graphic indicating the shampoo is ideal for CLEANmaxx carpet cleaners.

OPERATING INSTRUCTIONS

- 1. Apply the Solution:** With the carpet cleaner filled with the prepared solution, begin cleaning by gliding the machine over the carpet in slow, overlapping strips. Follow the operating instructions of your specific CLEANmaxx carpet cleaner model.
- 2. Extract Dirty Water:** As you pull the carpet cleaner back, the dirty water will be absorbed into the machine's recovery tank. This process helps the carpet dry faster and ensures effective cleaning.
- 3. Repeat if Necessary:** For heavily soiled areas, you may need to repeat the cleaning process. Ensure the carpet is not oversaturated.
- 4. Drying:** Allow the carpet to dry completely before walking on it or placing furniture back. Good ventilation will aid in faster drying.

MAINTENANCE

- Storage:** Store the Easymaxx Carpet Shampoo in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the cap is tightly sealed after each use.
- Disposal:** Dispose of empty containers according to local regulations. Do not reuse the container.
- Carpet Cleaner Maintenance:** After each use, thoroughly clean your CLEANmaxx carpet cleaner according to its specific manual to prevent residue buildup and ensure optimal performance for future uses.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Carpet not clean enough.	Insufficient shampoo concentration, heavily soiled area, or improper cleaning technique.	Ensure correct dilution ratio. Pre-treat stubborn stains. Go over the area slowly and repeat if necessary.
Residue left on carpet.	Too much shampoo used, or insufficient extraction.	Ensure proper dilution. Make sure the carpet cleaner is effectively extracting water. You may need to go over the area with clean water only to rinse.
Carpet drying too slowly.	Oversaturation of carpet, poor ventilation.	Avoid oversaturating the carpet. Ensure good ventilation in the room (open windows, use fans).

SPECIFICATIONS

Brand	CLEANmaxx
Model Number	01067
Volume	500 Milliliters
Scent	Unscented
Product Dimensions (L x W x H)	23 x 17 x 17.6 cm (approx. 9.06 x 6.69 x 6.93 inches)
Package Dimensions	21.2 x 6.4 x 6.3 cm (approx. 8.35 x 2.52 x 2.48 inches)

Item Weight	540 grams (approx. 1.19 lbs)
International Article Code (EAN)	04016471010673
Country of Origin	Germany



Image: German flag indicating "Made in Germany".

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the documentation provided with your CLEANmaxx carpet cleaner or contact the manufacturer directly. Contact details can typically be found on the product packaging or the manufacturer's official website.

Manufacturer: CLEANmaxx

© 2025 CLEANmaxx. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

