

Noritz RC-B001M

Noritz RC-B001M Water Heater Kitchen Remote Instruction Manual

Model: **RC-B001M** | Brand: **Noritz**

[Introduction](#)

[Safety Information](#)

[Setup](#)

[Operating Instructions](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Noritz RC-B001M Water Heater Kitchen Remote. Please read these instructions thoroughly before installation and operation, and retain them for future reference. The Noritz RC-B001M is a simple type kitchen remote control designed for use with compatible Noritz water heaters. It allows for convenient control of your water heater from the kitchen area.



Figure 1: Noritz RC-B001M Water Heater Kitchen Remote. This image shows the compact design of the remote control unit.

2. SAFETY INFORMATION

Always observe the following safety precautions to reduce the risk of injury or damage.

- Installation should only be performed by a qualified professional in accordance with local codes and regulations.

- Do not attempt to repair or modify the remote control. Refer all servicing to qualified personnel.
- Keep the remote control away from water and excessive moisture.
- Ensure the power supply to the water heater is disconnected before any installation or maintenance work on the remote.

3. SETUP AND INSTALLATION

The Noritz RC-B001M is designed as a primary kitchen remote for compatible Noritz water heaters. It cannot be used as an additional remote control unit without proper system configuration.

3.1 Pre-Installation Checks

- Verify compatibility with your existing Noritz water heater model.
- Ensure the installation location in the kitchen is dry and free from direct heat or steam.
- Confirm that necessary wiring is available and accessible for connection to the water heater.

3.2 Installation Steps

1. **Power Disconnection:** Turn off the main power supply to the water heater at the circuit breaker.
2. **Mounting:** Securely mount the remote control unit to a suitable wall surface in the kitchen. Use appropriate fasteners for the wall material.
3. **Wiring Connection:** Connect the remote control wiring to the designated terminals on the water heater, following the wiring diagram provided with your water heater or by a qualified installer. Ensure all connections are secure and correctly polarized.
4. **Power Restoration:** Once all connections are verified, restore power to the water heater.
5. **Initial Test:** Perform an initial test to ensure the remote communicates correctly with the water heater.

4. OPERATING INSTRUCTIONS

The Noritz RC-B001M is a simple interface for controlling your water heater.

4.1 Basic Functions

- **Power On/Off:** Use the designated power button to turn the water heater on or off.
- **Temperature Adjustment:** Adjust the desired water temperature using the up/down or +/- buttons. The current temperature setting will be displayed.
- **Bath Fill (if applicable):** If your water heater supports automatic bath fill, a dedicated button may be present to initiate this function.

4.2 Important Notes

- This remote control **does not support eco-mode** functions.
- Refer to your main water heater manual for detailed information on advanced features and specific error codes.

5. MAINTENANCE

Regular maintenance ensures the longevity and proper functioning of your remote control.

- **Cleaning:** Wipe the surface of the remote control with a soft, damp cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the finish or internal components.
- **Inspection:** Periodically check the remote for any signs of damage or loose connections.

- **Environmental Conditions:** Ensure the remote is not exposed to extreme temperatures, direct sunlight for prolonged periods, or high humidity.

6. TROUBLESHOOTING

If you encounter issues with your Noritz RC-B001M remote, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Remote display is blank.	No power to the water heater or remote. Loose wiring connection.	Check the main power supply to the water heater. Verify all wiring connections are secure.
Remote not responding to button presses.	Communication error with the water heater. Internal fault.	Cycle power to the water heater (turn off, wait 30 seconds, turn on). If the problem persists, contact customer support.
Incorrect temperature displayed.	Sensor issue or communication error.	Ensure the remote is correctly connected. Consult your water heater manual for sensor troubleshooting.

For issues not listed here or if solutions do not resolve the problem, please contact Noritz customer support or a qualified service technician.

7. SPECIFICATIONS

Feature	Detail
Model Number	RC-B001M
Brand	Noritz
Type	Kitchen Remote (Simple Type)
Product Dimensions (H x W x D)	120 mm x 120 mm x 18 mm
Item Weight	300 g
Eco-Mode Support	No
Batteries Required	No
ASIN	B00841MPGO
First Available Date	May 17, 2012

8. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please contact Noritz customer service directly. Details regarding your product's warranty period and terms can typically be found in the documentation accompanying your main water heater unit or on the official Noritz website.

Noritz Official Website: www.noritz.com

When contacting support, please have your product model number (RC-B001M) and the serial number of your water heater readily available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question