

[Manuals.plus](#) /

› [Villeroy & Boch](#) /

› Villeroy & Boch Subway 9M55S1 Toilet Seat Instruction Manual

Villeroy & Boch 9M55S1

Villeroy & Boch Subway 9M55S1 Toilet Seat

INSTRUCTION MANUAL

Introduction

This instruction manual provides important information for the safe and correct installation, operation, and maintenance of your Villeroy & Boch Subway 9M55S1 toilet seat. This product features a modern D-shaped design, soft-closing hinges, and a quick-release function for easy cleaning. Please read this manual thoroughly before installation and retain it for future reference.

Safety Information

- Always ensure the toilet seat is securely installed before use to prevent injury.
- Do not stand on the toilet seat.
- Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the surface finish and hinge mechanisms.
- Keep small children supervised around the toilet to prevent accidents.

Package Contents

Verify that all components are present before beginning installation:

- Villeroy & Boch Subway 9M55S1 Toilet Seat (D-shaped, White Alpin)
- Stainless Steel Hinges with Soft-Closing Mechanism
- Quick-Release Fasteners
- Installation Hardware (washers, nuts)

Setup and Installation

Follow these steps for proper installation of your toilet seat:

1. **Prepare the Toilet Bowl:** Ensure the toilet bowl is clean and dry. Remove any old toilet seat and hardware.

2. **Position the Hinges:** Place the stainless steel hinges into the mounting holes on the toilet bowl. Ensure the quick-release mechanisms are facing the correct direction (typically towards the back of the bowl).
3. **Secure the Hinges:** From underneath the toilet bowl, attach the washers and nuts to the hinge bolts. Hand-tighten first, then use a wrench to gently secure them. Do not overtighten.
4. **Attach the Toilet Seat:** Align the mounting points on the underside of the toilet seat with the quick-release pins on the hinges. Press down firmly until the seat clicks into place.
5. **Adjust for Fit:** If necessary, the hinges may allow for minor adjustments to ensure the seat is centered on the bowl. Loosen the nuts slightly, adjust, and then re-tighten.
6. **Test Functionality:** Gently lower the seat and lid to confirm the soft-closing mechanism operates smoothly. Test the quick-release function by pressing the release buttons (if applicable) and lifting the seat off.



Image: Villeroy & Boch Subway 9M55S1 toilet seat installed. This image shows the D-shaped toilet seat securely mounted on a toilet bowl, illustrating the product's design and how it sits on the fixture.

Operating Instructions

- **Soft-Closing Function:** To engage the soft-closing feature, simply push the toilet seat or lid down gently. The integrated mechanism will lower it slowly and quietly, preventing slamming. Do not force the seat or lid down manually, as this can damage the soft-closing mechanism.
- **Quick-Release Function:** For thorough cleaning, the toilet seat can be easily removed. Locate the quick-release

buttons or levers near the hinges (specific design may vary). Press or lift these mechanisms, and then lift the entire seat straight up from the toilet bowl. To reattach, align the seat with the hinge pins and press down until it clicks securely into place.

Maintenance and Cleaning

Proper care will ensure the longevity and appearance of your Villeroy & Boch toilet seat:

- **Regular Cleaning:** Clean the toilet seat regularly with a soft cloth, warm water, and a mild, non-abrasive soap.
- **Avoid Harsh Chemicals:** Do not use abrasive powders, scouring pads, strong detergents, disinfectants containing chlorine or acid, or aerosol cleaners. These can damage the thermosetting plastic surface and the stainless steel hinges.
- **Hinge Care:** Periodically check the hinge connections for tightness. If they become loose, gently re-tighten the nuts underneath the toilet bowl.
- **Quick-Release Mechanism:** Ensure the quick-release mechanism is free of debris to function correctly.



Image: Villeroy & Boch Subway 9M55S1 toilet seat. This image displays the overall aesthetic of the toilet seat, emphasizing its modern design and white alpin color, suitable for regular cleaning.

Troubleshooting

Problem	Possible Cause	Solution
Toilet seat is loose or wobbly.	Mounting nuts are not tight enough.	Tighten the mounting nuts underneath the toilet bowl. Do not overtighten.
Soft-closing function is not working or is too fast.	Mechanism is damaged or obstructed.	Ensure no foreign objects are obstructing the hinges. If damaged, contact customer support.
Quick-release function is difficult to operate.	Mechanism is dirty or misaligned.	Clean the quick-release mechanism. Ensure the seat is aligned correctly before attempting to release.

Specifications

- **Model:** Subway 9M55S1
- **Part Number:** 9M55S101
- **Material:** Thermosetting Plastic (Seat), Stainless Steel (Hinges)
- **Color:** White Alpin
- **Style:** Modern
- **Shape:** D-Shaped
- **Product Dimensions:** Approximately 18.31"L x 14.76"W (46.5 cm L x 37.5 cm W)
- **Item Weight:** Approximately 7.48 pounds (3.4 kg)
- **Features:** Soft-Closing, Quick-Release

Warranty and Support

For warranty information or technical support, please contact Villeroy & Boch customer service. Refer to your purchase documentation for specific warranty terms and contact details. You can also visit the official Villeroy & Boch website for further assistance.

Villeroy & Boch Store: [Visit the Villeroy & Boch Store on Amazon](#)