

GROHE 36329000

GROHE Eurosmart E Single Hole Touchless Bathroom Faucet

Model: 36329000

Brand: GROHE

1. PRODUCT OVERVIEW

The GROHE Eurosmart E Touchless Bathroom Faucet with Concealed Temperature Control is designed for enhanced hygiene and water conservation. Activated by an infrared sensor, it provides automatic water flow, reducing contact and promoting a cleaner environment. The integrated temperature control lever allows for precise water temperature adjustment.

Key Features:

- **GROHE StarLight Finish:** A durable, scratch-resistant surface that is easy to clean and maintains its shine for years.
- **GROHE EcoJoy:** Engineered to optimize water and energy consumption, contributing to resource conservation.
- **GROHE QuickFix:** Designed for surprisingly easy and quick installation.
- Infrared electronic activation for touchless operation.
- Battery powered (includes CR-P2 lithium battery).
- Extended battery life: Approximately 7 years (based on 150 uses per day).
- Multi-stage battery life status display.
- Includes 7 programmable functions, such as 24/72-hour auto-flush for hygiene.

2. SETUP AND INSTALLATION

The GROHE Eurosmart E faucet is designed for single-hole, deck-mount installation. The GROHE QuickFix system simplifies the process, allowing for efficient setup.

Installation Steps:

1. Ensure the mounting surface is clean and prepared for a single-hole faucet.
2. Insert the faucet body into the mounting hole.
3. Secure the faucet from underneath the counter using the provided mounting hardware.
4. Connect the water supply lines to the appropriate hot and cold water feeds.
5. Install the CR-P2 lithium battery into the designated compartment.
6. Test for leaks and proper operation.

For a visual guide on the QuickFix installation process, please refer to the video below:

Your browser does not support the video tag.

Video: Demonstrates the GROHE QuickFix installation process for a faucet, highlighting the ease of securing the faucet to the sink.



Image: Side view of the GROHE Eurosmart E faucet held in a hand, illustrating its compact size and a height of 5.7 inches (14 cm).

3. OPERATING INSTRUCTIONS

The GROHE Eurosmart E faucet features intuitive touchless operation and a concealed temperature control for user convenience.

Touchless Activation:

The faucet is equipped with an infrared sensor located at the base. Simply place your hands within the sensor's detection range to activate the water flow. The water will automatically stop when your hands are removed.



Image: Front view of the GROHE Eurosmart E Single Hole Touchless Bathroom Faucet in Starlight Chrome, showcasing its sleek design and the infrared sensor at the base.

Temperature Control:

The temperature of the water is adjusted via a concealed lever, typically located on the side or rear of the faucet base. Rotate the lever to achieve the desired hot or cold water mix. This setting remains constant until manually changed.

Automatic Functions:

The faucet includes programmable features such as 24-hour or 72-hour auto-flush. These functions help maintain hygiene and prevent stagnation in the water lines by periodically flushing the system.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your GROHE Eurosmart E faucet.

Cleaning the Finish:

The GROHE StarLight chrome finish is designed for easy cleaning. Use a soft cloth and mild soap or a non-abrasive cleaner specifically designed for chrome surfaces. Avoid abrasive sponges, scouring pads, or harsh chemical cleaners, as these can damage the finish.

Sensor Maintenance:

Keep the infrared sensor clean and free from obstructions. Wipe it gently with a soft, damp cloth to remove any soap residue or water spots that might interfere with its operation.

Battery Replacement:

The faucet is powered by a CR-P2 lithium battery. The multi-stage battery life status display will indicate when the battery needs replacement. To replace, locate the battery compartment (refer to the installation diagram for exact location), remove the old battery, and insert a new one, ensuring correct polarity.

5. TROUBLESHOOTING

If you encounter issues with your GROHE Eurosmart E faucet, refer to the following common problems and solutions:

- **No Water Flow or Intermittent Flow:**

- Check the battery status. Replace the CR-P2 lithium battery if indicated by the status display or if the faucet is unresponsive.
- Ensure the water supply valves underneath the sink are fully open.
- Inspect the infrared sensor for any obstructions or dirt. Clean the sensor gently.
- Verify that the water pressure is adequate. Low water pressure can sometimes prevent proper sensor activation or flow.

- **Low Water Output:**

- Check the aerator at the faucet spout for mineral buildup or debris. Unscrew and clean the aerator if necessary.
- Confirm that the concealed temperature control lever is set to a position that allows sufficient flow.

- **Water Temperature Issues:**

- Adjust the concealed temperature control lever to the desired setting.
- Ensure both hot and cold water supply lines are connected and open.

- **Faucets Missing Parts Upon Arrival:**

- If any parts are missing from the original packaging, contact GROHE customer support immediately for assistance.

6. SPECIFICATIONS

Attribute	Detail
Brand	GROHE
Model Name	36329000
Mounting Type	Deck Mount
Finish Type	CHROME
Material	Metal
Color	GROHE CHROME
Number of Handles	1 (Concealed Temperature Control)
Hole Count	1
Special Features	ADA Compliant, WaterSense Certified, Infrared Electronic Activation
Power Source	Battery powered (CR-P2 lithium battery included)
Battery Life	Approx. 7 years (150 uses per day)
Item Weight	1 Pounds
Product Dimensions	14.17 x 8.66 x 3.94 inches

7. WARRANTY AND SUPPORT

The GROHE Eurosmart E Single Hole Touchless Bathroom Faucet comes with a limited warranty. For specific warranty terms and conditions, please refer to the documentation included with your product or visit the official GROHE website.

For further assistance, technical support, or to inquire about replacement parts, please contact GROHE customer service. You can find contact information on the official GROHE website or through your product retailer.