

[Manuals.plus](#) /

› [Sunbeam](#) /

› Sunbeam Electric Royal Mink Sherpa Heated Throw Blanket User Manual, Model TRT8WR-R608-25A00

Sunbeam TRT8WR-R608-25A00

Sunbeam Electric Royal Mink Sherpa Heated Throw Blanket

MODEL: TRT8WR-R608-25A00

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this heated throw.
- Do not use with an extension cord or power strip. Plug directly into a wall outlet.
- Do not use with generators, power converters, or inverters.
- Do not use with damaged cords or plugs. If the cord or plug is damaged, do not use the appliance.
- Do not use for infants, children, incapacitated persons, or anyone insensitive to heat.
- Do not use on areas of the body that are swollen, inflamed, or have open wounds.
- Do not use with pets.
- Do not use if wet.
- Do not use pins or other metallic objects with this appliance. They may damage electrical wiring.
- Do not tuck in or pinch the power cord.
- Do not dry clean this product. Dry cleaning solvents may damage the insulation of the heating element.
- Store the product properly when not in use, ensuring the cord is not tightly wrapped.
- This product is ETL certified for safety.

PRODUCT OVERVIEW

The Sunbeam Electric Royal Mink Sherpa Heated Throw provides warmth and comfort. It features a luxurious royal mink fabric on one side and soft sherpa on the reverse. The throw is designed with advanced heating technology for consistent warmth and includes safety features such as an auto shut-off.



Figure 1: Folded Sunbeam Heated Throw with attached controller.

Key Features:

- **Material:** Royal Mink and Sherpa (100% high-quality polyester)
- **Dimensions:** 50" x 60"
- **Heat Settings:** 4 adjustable heat settings (Warm, Low, Medium, High)
- **Auto Shut-Off:** 4-hour automatic shut-off for safety
- **Controller:** Easy-to-use push-button controller with LED indicator lights
- **Care:** Machine washable and dryer safe (controller must be detached)
- **Safety:** Overheat protection and cETLus Certified

SETUP

Unpacking and Initial Inspection:

1. Carefully remove the heated throw from its packaging.
2. Unfold the throw and lay it flat to inspect for any damage or visible defects. Ensure the heating wires are not kinked or bent.
3. Locate the controller and ensure it is securely attached to the throw's connector.

Connecting the Controller:

The controller is designed for easy connection. Ensure the connector on the throw is fully inserted into the controller's port until it clicks securely into place. Do not force the connection.



Figure 2: Push-button controller with LED indicators for heat settings and auto-off.

Power Connection:

Plug the power cord directly into a 120V AC electrical wall outlet. Do not use extension cords or power strips, as this may pose a fire hazard or reduce performance.

OPERATING INSTRUCTIONS

Turning On/Off:

- To turn on the heated throw, press the power button on the controller. The LED indicator lights will illuminate.
- To turn off the heated throw, press the power button until all LED lights are off.

Adjusting Heat Settings:

The controller features 4 adjustable heat settings: Warm, Low, Medium, and High. Each press of the power button cycles through the heat settings, indicated by the number of illuminated LED lights.

- **1 LED:** Warm
- **2 LEDs:** Low
- **3 LEDs:** Medium
- **4 LEDs:** High

Automatic Shut-Off:

For safety and energy conservation, the heated throw is equipped with a 4-hour automatic shut-off function. The throw will automatically turn off after 4 hours of continuous use. To restart, simply turn the throw off and then back on using the power button.

Your browser does not support the video tag.

Video 1: Sunbeam Royal Mink Sherpa Heated Throws - Demonstrates product features and use.

CARE AND MAINTENANCE

Proper care ensures the longevity and performance of your heated throw. Always follow these instructions carefully.

Before Washing:

1. Ensure the heated throw is turned off and unplugged from the wall outlet.
2. **Crucially, detach the controller from the throw by gently pulling the connector apart.** Do not immerse the controller or power cord in water.

EASY CARE

Washer and Dryer Safe



**Unplug
controller**



Figure 3: Detach the controller before washing the heated throw.

Washing Instructions:

- Machine wash on a gentle cycle in cold water.
- Do not bleach.
- Use a small amount of mild detergent.

Drying Instructions:

- Tumble dry on low heat.
- Remove promptly from the dryer to prevent wrinkles.
- Alternatively, hang dry. Ensure the throw is completely dry before reattaching the controller and using.
- Do not iron.

Storage:

When not in use, store the heated throw in its original bag or a breathable storage container in a cool, dry place. Avoid placing heavy objects on top of the throw, which could damage the internal wiring.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Throw is not heating.	Not properly plugged in; controller not connected; auto shut-off activated.	Ensure power cord is securely plugged into a wall outlet. Check controller connection. Turn the throw off and then back on.
Controller lights are blinking.	Connection issue or internal fault detected.	Unplug the throw from the wall outlet. Detach and reattach the controller firmly. Plug back into the wall outlet. If blinking persists, contact customer support.
Throw is not warm enough.	Heat setting is too low.	Increase the heat setting using the controller. Allow a few minutes for the throw to reach the desired temperature.

If you experience any issues not listed here or if the problem persists after attempting the solutions, please contact Sunbeam Customer Support.

SPECIFICATIONS

Feature	Detail
Model Number	TRT8WR-R608-25A00
Dimensions	50"L x 60"W
Material	100% Polyester (Royal Mink/Sherpa)
Heat Settings	4 (Warm, Low, Medium, High)
Auto Shut-Off	4 Hours
Power Source	120V AC
Certifications	cETLus Certified
Included Components	Heated Throw, Push-Button Controller

WARRANTY AND SUPPORT

This Sunbeam Electric Royal Mink Sherpa Heated Throw Blanket is covered by a **5-year limited warranty** from the date of purchase. This warranty covers defects in material and workmanship under normal household use. For warranty claims, technical support, or any questions regarding your product, please visit the official Sunbeam website or contact their customer service department. Please have your model number (TRT8WR-R608-25A00) and proof of purchase available.

ADDITIONAL RESOURCES


Your browser does not support the video tag.

Video 1: Sunbeam Royal Mink Sherpa Heated Throws - Demonstrates product features and use.

Your browser does not support the video tag.

Video 2: Sunbeam Heated Throws Royal Flannel Sherpa - Overview of a similar heated throw product.

SUNBEAM ADVANTAGE



**DOUBLE INSULATED
WIRE PROTECTION**

Figure 4: Illustration of Sunbeam's advanced wire technology for safe and even heat distribution.

© 2025 Sunbeam Products. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question