

- Manuals.plus /
- › Bulova /
 - › Bulova Men's Classic 3-Hand Quartz Watch Model 96A133 Instruction Manual

Bulova 96A133

Bulova Men's Classic 3-Hand Quartz Watch Model 96A133
Instruction Manual

Model: 96A133 | Brand: Bulova

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your Bulova Men's Classic 3-Hand Quartz Watch, Model 96A133. This timepiece features a classic design with Roman numeral markers, a 41mm stainless steel case, and a black leather strap, offering both elegance and reliable timekeeping.



Figure 1: Front view of the Bulova Men's Classic 3-Hand Quartz Watch.

2. SETUP

2.1 Unboxing and Initial Inspection

Carefully remove the watch from its packaging. Inspect the watch for any visible damage or defects. Ensure all protective films are removed from the crystal and case back before use.



Figure 2: The Bulova watch packaging box.

2.2 Setting the Time

1. Gently pull the crown (the small knob on the side of the watch case) out to its outermost position.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position against the watch case. This will start the watch movement.

2.3 Adjusting the Leather Strap

The watch features a black leather strap with a classic buckle closure. To adjust the fit, simply thread the strap through the buckle and secure the pin into the desired hole. Ensure the fit is snug but comfortable, allowing for proper blood circulation.



Figure 3: The Bulova watch worn on a wrist, showcasing the leather strap.

3. OPERATING THE WATCH

Your Bulova watch is equipped with a reliable 3-hand quartz movement, providing accurate timekeeping. Once the time is set, the watch will continuously display the current hour, minute, and second.

Your browser does not support the video tag.

Video 1: A brief overview of the Bulova Men's 96A133 Dress Watch, demonstrating its appearance and movement.

4. MAINTENANCE

4.1 Water Resistance

This watch is water resistant up to 30 meters (3 ATM). This means it is suitable for everyday use and can withstand splashes or brief immersion in water. However, it is **not recommended** for swimming, showering, or diving. Avoid operating the crown while the watch is wet.

4.2 Cleaning

To maintain the appearance of your watch, wipe the case and crystal with a soft, dry cloth. For the leather strap, avoid prolonged exposure to water, direct sunlight, and harsh chemicals, as these can cause damage or discoloration. Clean the leather strap with a damp cloth and mild soap if necessary, then dry thoroughly.

4.3 Battery Replacement

The watch is powered by one Lithium Metal battery (included). When the watch stops or the second hand begins to skip, it indicates that the battery needs replacement. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.

5. TROUBLESHOOTING

5.1 Watch Not Running

- Ensure the crown is fully pushed in against the watch case.
- If the watch still does not run, the battery may need to be replaced. Refer to Section 4.3.

5.2 Incorrect Time Display

- Check if the crown is accidentally pulled out. Push it back in if it is.
- Reset the time according to the instructions in Section 2.2.
- If the watch consistently loses or gains time significantly, it may require servicing.

6. SPECIFICATIONS

Feature	Detail
Model Number	96A133
Movement	Quartz, 3-Hand
Case Material	Stainless Steel
Case Diameter	41mm
Crystal Material	Mineral Crystal
Strap Material	Black Leather
Water Resistance	30 Meters (3 ATM)
Battery Type	1 Lithium Metal (included)
Product Dimensions	4.33 x 3.94 x 3.54 inches; 1.41 ounces

7. WARRANTY AND SUPPORT

Your Bulova watch comes with a 3-Year Limited Warranty. This warranty covers manufacturing defects under normal use. For detailed terms and conditions, please refer to the warranty card included with your purchase or visit the official Bulova website. For technical support, service, or warranty claims, please contact Bulova customer service or an authorized Bulova service center. Do not attempt to open or repair the watch yourself, as this may void the warranty.

© 2026 Bulova. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0088BMX44>

More documents and user manuals: <https://manuals.plus/>