



Manuals.plus /

› Proctor Silex /

› Proctor Silex Alex's Lemonade Stand Electric Citrus Juicer Machine and Squeezer, 34 oz, Model 66331 User Manual

Proctor Silex 66331

Proctor Silex Alex's Lemonade Stand Electric Citrus Juicer Machine and Squeezer (Model 66331)

User Instruction Manual

INTRODUCTION

Thank you for purchasing the Proctor Silex Alex's Lemonade Stand Electric Citrus Juicer. This appliance is designed to efficiently extract juice from various citrus fruits, including lemons, limes, and oranges. Its user-friendly design and easy-to-clean components make fresh juice preparation simple and convenient.



Image: The Proctor Silex Alex's Lemonade Stand Electric Citrus Juicer, yellow in color, with a clear pitcher and reamer.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not immerse cord, plug, or base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.

- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the appliance manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use appliance for other than intended use.

PARTS AND FEATURES

Familiarize yourself with the components of your juicer:

- **Large 34 oz. Pitcher:** Collects juice and features measurement markings.
- **2 Nesting Reamers:** One large for bigger fruits like oranges and grapefruits, one small for lemons and limes.
- **Pulp Control Dial:** Allows adjustment of pulp level in your juice.
- **Strainer:** Separates pulp from juice.
- **Clear Cover:** Protects the reamer when not in use.
- **Motor Base:** Houses the electric motor.

proctorsilex®



Alex's Lemonade Stand Electric Citrus Juicer

Image: Diagram showing the dimensions of the juicer and its main components.

SETUP

1. Ensure the juicer is unplugged from the power outlet.
2. Place the motor base on a clean, dry, and stable surface.
3. Position the 34 oz. pitcher onto the motor base, ensuring it is securely seated.
4. Place the strainer into the pitcher.
5. Select the appropriate reamer size (large for oranges/grapefruits, small for lemons/limes) and place it onto the central shaft of the strainer.
6. Place the clear cover over the reamer when not in use.

OPERATING INSTRUCTIONS

1. Cut your citrus fruit in half.
2. Plug the juicer into a standard electrical outlet.
3. Place one half of the fruit onto the reamer.
4. Press down firmly on the fruit. The reamer will automatically begin to rotate, extracting juice. The juicer features an auto-reversing function for maximum juice extraction.
5. Continue pressing and rotating the fruit until all juice is extracted.
6. Lift the fruit from the reamer to stop the motor.
7. Repeat with remaining fruit halves.



Image: A hand pressing a citrus fruit half onto the reamer of the electric juicer.

Pulp Control

The juicer includes a pulp control dial. To adjust the amount of pulp in your juice, simply slide the dial on the strainer left or right. This allows you to customize your juice to your preferred pulp level.

Serving

Once juicing is complete, the pitcher can be detached from the motor base for easy serving. The pitcher's spout allows for drip-free pouring.

Your browser does not support the video tag.

Video: Demonstration of the Proctor Silex Alex's Lemonade Stand Citrus Juicer in operation, showing how to extract juice and pour from the pitcher.

Your browser does not support the video tag.

Video: User demonstrating efficient orange juicing with the Proctor Silex juicer, highlighting thorough

CARE AND CLEANING

Proper cleaning ensures the longevity and hygiene of your juicer. All removable parts are dishwasher safe.

1. Unplug the juicer from the power outlet before cleaning.
2. Remove the clear cover, reamer, strainer, and pitcher from the motor base.
3. Wash these removable parts in warm, soapy water or place them on the top rack of your dishwasher.
4. Wipe the motor base with a damp cloth. Do not immerse the motor base in water.
5. Ensure all parts are completely dry before reassembling or storing.



Image: A hand removing the reamer from the juicer, demonstrating easy disassembly for cleaning.

Your browser does not support the video tag.

Video: User demonstrating the ease of disassembly and cleaning for the Alex's Citrus Juicer.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; power outage; loose connection.	Check power cord; ensure outlet is functional; check circuit breaker.
Motor stops during juicing.	Too much pressure applied; fruit lodged in reamer.	Reduce pressure; remove fruit and clear reamer.
Low juice yield.	Fruit not ripe; insufficient pressure; incorrect reamer size.	Use ripe fruit; apply firm, even pressure; ensure correct reamer size for fruit.
Excessive pulp in juice.	Pulp control dial set to high pulp.	Adjust pulp control dial to a lower setting.

SPECIFICATIONS

- **Model Number:** 66331
- **Product Dimensions:** 6.3"D x 8.5"W x 8.6"H
- **Weight:** 2.25 Pounds
- **Capacity:** 34 oz. (Pitcher)
- **Special Feature:** Auto-Reversing Reamer, Adjustable Pulp Control
- **Color:** Yellow
- **Manufacturer:** Hamilton Beach

WARRANTY AND SUPPORT

This Proctor Silex product is backed by a **Limited Three Year Warranty**. For detailed warranty information, product support, or to register your product, please refer to the official Proctor Silex website or contact customer service.

Customer Service: Please refer to the contact information provided in your product packaging or on the official Proctor Silex website for assistance.