

Timberland TBL13319JS/02

Timberland Hydroclimb Analog Multifunction Watch

Model: TBL13319JS/02

1. INTRODUCTION

Thank you for choosing the Timberland TBL-13319JS-02 Hydroclimb Analog Multifunction Watch. This timepiece is designed for durability and functionality, featuring a robust stainless steel case, a precise quartz chronograph movement, and specialized functions for date, tide, and moon phase tracking. Its water resistance makes it suitable for various outdoor activities.



Figure 1: Front view of the Timberland Hydroclimb Watch with a black dial and yellow silicone strap.

2. SETUP AND INITIAL USE

2.1 Setting Time and Date

1. **Pull the Crown:** Gently pull the crown (the knob on the side of the watch case) out to the first or second click position, depending on your model's specific functions.

2. **Adjust Time:** Rotate the crown to set the hour and minute hands. Ensure you set the correct AM/PM for the date change mechanism.
3. **Adjust Date:** If applicable, rotate the crown in the opposite direction or pull it to a different click position to adjust the date.
4. **Push Crown Back:** Once set, push the crown back in completely to start the watch movement and ensure water resistance.

2.2 Setting Tide and Moon Phase Functions

The Hydroclimb watch features dedicated tide and moon phase indicators. Specific adjustment procedures for these functions may vary. Typically, these are set using dedicated pushers or by manipulating the crown in specific positions. Refer to the detailed diagram in a comprehensive manual for precise instructions on calibrating these features based on your local tide and moon cycle data.

3. OPERATING THE WATCH

3.1 Chronograph Function

Your watch is equipped with a chronograph for measuring elapsed time.

- **Start:** Press the upper pusher (button) to start the chronograph.
- **Stop:** Press the upper pusher again to stop the chronograph.
- **Reset:** Press the lower pusher to reset the chronograph hands to zero.

3.2 Water Resistance

This watch is water resistant to 100 meters (330 feet). This makes it suitable for snorkeling and swimming. **It is not suitable for diving.** Ensure the crown is fully pushed in before any water exposure to maintain water resistance.



Figure 2: The Timberland Hydroclimb Watch displayed on a wrist, showing its size and fit.

4. MAINTENANCE AND CARE

- **Cleaning:** Clean the watch case and strap regularly with a soft, damp cloth. For silicone straps, mild soap and water can be used. Ensure the watch is dry before storing.
- **Avoid Extreme Temperatures:** Do not expose the watch to extreme temperatures (hot or cold) or sudden temperature changes, as this can affect its accuracy and seals.
- **Chemicals:** Avoid contact with solvents, detergents, perfumes, and cosmetic products, which can damage the case, strap, or seals.
- **Battery Replacement:** When the watch stops or the second hand jumps irregularly, the battery needs

replacement. This should be performed by a qualified watch technician to ensure proper sealing and function.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not running	Depleted battery	Replace battery (professional service recommended).
Incorrect time/date	Crown not fully pushed in; incorrect setting	Ensure crown is pushed in. Re-set time/date as per Section 2.1.
Condensation under crystal	Temperature change; seal compromise	Avoid sudden temperature changes. If persistent, seek professional service.

6. SPECIFICATIONS

- Model Number:** TBL13319JS/02
- Movement:** Quartz
- Case Diameter:** 43 Millimetres (approx. 44mm wide)
- Case Thickness:** 13 Millimetres (approx. 14mm thick)
- Case Material:** Solid Stainless Steel
- Crystal:** Mineral glass with sapphire coating
- Band Material:** Yellow Silicone Rubber
- Band Width:** 24mm
- Water Resistance:** 100 meters (330 feet)
- Functions:** Chronograph, Date, Tide, Moon Phase
- Weight:** 136.08 g
- Batteries:** 1 Product Specific battery (included)




Figure 3: General watch size comparison chart, illustrating various case diameters.

7. WARRANTY AND SUPPORT

This Timberland watch comes with a **2-year store warranty**, as stated in the product description. For warranty claims or technical support, please contact the seller of record or an authorized Timberland service center. Keep your purchase receipt as proof of purchase.





Figure 4: The original Timberland gift box in which the watch is packaged.

For more information or to explore other Timberland products, visit the official [Timberland Store on Amazon](#).

© 2023 Timberland. All rights reserved.

Related Documents - TBL13319JS/02

 2H / 2HDATE / 3H / 3HDATE INSTRUCTION MANUAL	<p><u>Timberland 2H / 2HDATE / 3H / 3HDATE Instruction Manual</u> Instruction manual for Timberland watches models 2H, 2HDATE, 3H, and 3HDATE, detailing time and date setting procedures.</p>
 Timberland TRAIL FORCE S1 INSTRUCTION MANUAL & WARRANTY	<p><u>Timberland Trail Force S1 GPS Smartwatch Instruction Manual & Warranty</u> User guide and warranty information for the Timberland Trail Force S1 GPS Smartwatch. Learn about setup, features, health monitoring, outdoor tools, care, and safety.</p>
 3H + EL BACKLIGHT INSTRUCTION MANUAL	<p><u>Timberland 3H + EL Backlight Watch Instruction Manual and Operation Guide</u> Learn how to operate your Timberland 3H + EL Backlight watch. This guide covers time setting, EL backlight activation, and product compliance information.</p>
 Timberland VX9J	<p><u>Timberland VX9J Instruction Manual</u> A comprehensive instruction manual for the Timberland VX9J watch, detailing how to set the time, date, and day of the week, along with features and water resistance information.</p>
 Timberland Kids' Shoe Sizing Guide: How to Measure Feet Accurately	<p><u>Timberland Kids' Shoe Sizing Guide: How to Measure Feet Accurately</u> Learn how to measure your child's feet correctly with Timberland's printable sizing guide. Follow simple steps and use the included foot outline and ruler for accurate shoe sizing for infants, toddlers, youth, and juniors.</p>
 SS22 TIMEPIECES JEWELLERY	<p><u>Timberland SS22 Timepieces & Jewellery Catalogue</u> Explore the Timberland SS22 Timepieces and Jewellery Catalogue. Discover stylish watches and accessories for men and women, crafted with eco-conscious 'Better Leather' and reflecting Timberland's commitment to sustainability and nature.</p>