

[Manuals.plus](#) /

› [Anne Klein](#) /

› Anne Klein Women's AK/1018BKBK Black Ceramic Bracelet Watch with Diamond Accent User Manual

Anne Klein AK/1018BKBK

Anne Klein Women's AK/1018BKBK Black Ceramic Bracelet Watch with Diamond Accent User Manual

Model: AK/1018BKBK

INTRODUCTION

Thank you for choosing the Anne Klein Women's Black Ceramic Bracelet Watch with Diamond Accent. This manual provides essential information for the proper setup, operation, maintenance, and care of your new timepiece. Designed for elegance and durability, this watch features a glossy black dial with a genuine diamond at 12 o'clock, gold-tone hands and markers, and a sophisticated black ceramic adjustable link bracelet.



Front view of the Anne Klein Women's Black Ceramic Bracelet Watch with Diamond Accent, showcasing the black dial, gold-tone accents, and diamond marker.

SETUP

Setting the Time

1. **Locate the Crown:** The crown is the small knob on the right side of the watch case.

2. **Pull Out the Crown:** Gently pull the crown outwards until you feel a click. This will stop the second hand (if present) and allow you to adjust the time.
3. **Adjust the Time:** Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time.
4. **Push In the Crown:** Once the time is set, push the crown back into its original position. The second hand will resume movement.





Side view of the watch, highlighting the crown used for time adjustment.

Adjusting the Bracelet

Your Anne Klein watch comes with an adjustable ceramic link bracelet and a jewelry clasp extender. The extender allows for a slightly looser fit. If further adjustment (removing or adding links) is needed, it is recommended to visit a professional jeweler to prevent damage to the ceramic links.

Video demonstrating the Anne Klein Women's AK/1018BKBK Black Ceramic Bracelet Watch with Diamond Accent, including how it looks on the wrist and the bracelet design.

OPERATING YOUR WATCH

This watch operates on a Japanese Quartz movement, ensuring accurate timekeeping. Once the time is set, the watch will continuously display the current time. The second hand provides continuous movement.

Water Resistance

Your watch is water resistant to 100 feet (30 meters). This means it is suitable for splashes, rain, and brief immersion in water. It is **not** recommended for swimming, diving, or prolonged water activities. Always ensure the crown is fully pushed in before any contact with water.

MAINTENANCE

Cleaning

- Wipe the watch case and ceramic bracelet regularly with a soft, dry cloth to remove dust and smudges.
- For more thorough cleaning, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid harsh chemicals or abrasive materials.
- Clean the mineral crystal lens with a soft, lint-free cloth.

Battery Replacement

The watch is powered by 1 CR2 battery (included). When the watch stops running or the second hand begins to skip, it indicates that the battery needs replacement. It is highly recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

Storage

When not in use, store your watch in its original box or a soft pouch to protect it from dust, moisture, and scratches. Avoid exposing the watch to extreme temperatures or direct sunlight for prolonged periods.

TROUBLESHOOTING

- **Watch Not Running:** Ensure the crown is fully pushed in. If it still doesn't run, the battery may need replacement.
- **Time Inaccuracy:** If the watch is consistently fast or slow, the movement may require servicing. Consult a professional watch repair service.
- **Bracelet Discomfort:** If the bracelet feels too tight or too loose, consider using the included extender or having links professionally adjusted.

SPECIFICATIONS

Model Number:	AK/1018BKBK
Brand:	Anne Klein
Material:	Ceramic
Display Type:	Analog
Watch Movement Type:	Japanese Quartz
Water Resistance Depth:	100 Feet (30 Meters)
Case Diameter:	30 Millimeters
Band Width:	16 Millimeters
Case Thickness:	8.5 Millimeters
Crystal:	Mineral
Power Source:	Battery Powered (1 CR2 battery included)
Item Weight:	68.04 Grams

WARRANTY AND SUPPORT

Manufacturer's Warranty

This Anne Klein watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. The warranty typically covers manufacturing defects.

Customer Support

For any questions, service requests, or further assistance, please contact Anne Klein customer support. You can often find contact information on the official Anne Klein website or through the retailer where the watch was purchased.

Video showcasing the Anne Klein Women's AK/1018BKBK Black Ceramic Bracelet Watch with Diamond Accent, providing a detailed view of its features and design.

© 2026 Anne Klein. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question